Go to www.vtechphones.com to

DISPLAY ICONS OVERVIEW

The handset battery is charging

Handset ringer is off.

Bluetooth device is active.

Bluetooth device is in use.

Answering system is on.

INSTALL THE BATTERY

Battery indicators

he screen is blank.

or shows **Place in**

The screen shows

Low battery and

LCD LANGUAGE SETTING

while the handset is not in use.

charger and

flashes.

Battery status

ne battery has no

charge or very little charge. The handset

The battery has enough

harge to be used for a

The battery is charged.

If you accidentally set the LCD language to Spanish or French, press **MENU**

and then enter **364**# to change the handset LCD language back to English

cannot be used.

short time.

Handset indicates the handset number

→II → III → **III** →

MEM

HS1

 \searrow

 $\mathbf{3}_1$

مه ا

ECO

The handset battery is low and needs charging

Option displayed above a softkey. Press - or - to select.

New voicemail received from your telephone service provider

The ECO mode activates automatically to reduce power

There are new caller ID log entries and/or new messages.

consumption when the handset is within range of the telephor

Charge without interruption

Charge without interruption

at least 30 minutes).

at least 30 minutes).


charged, place it in the

charger when not in use.

register your product for enhanced warranty support and latest VTech product

User's manual

DECT 6.0 accessory handset for use with VTech models |S8151/|S8151-2/|S8151-3/|S8151-4/|S8151-5/|S8152-5



Important safety instructions. This manual has instructions on how to set up and register your new handset. For instructions on using the handset, see the Quick start guide that came with your telephone base.

CONGRATULATIONS

on purchasing your new VTech product. Before

using this telephone, please read

You may also view or download the online user's manual for a full set of installation and operation instructions at www.vtechphones.com. In Canada, visit www.vtechcanada.com.



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.



CONNECT AND INSTALL

Connect the charger

Charge the battery

The ${\sf ENERGY\,STAR}^{"}$ program (www. energystar.gov) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to mark this product with the ENERGY STAR" label indicating it meets the latest energy efficiency guidelines.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by VTech Holdings Limited is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners

Install belt clip

To attach belt clip

To remove belt clip

Lift either of the belt clip tabs

outwards from the handset.

handset.

Snap the belt clip into the slots

on both sides of the cordless

IMPORTANT SAFETY

INSTRUCTIONS When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury,

- including the following: Read and understand all instructions.
- 2. Follow all warnings and instructions marked on the product. Unplug this product from the wall outlet before
- cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning. 4. Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub
- or a swimming pool, nor in a wet basement or
- 5. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- Avoid placing the telephone system in places with extreme temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and
- Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register This product should not be placed in any area where proper ventilation is not provided.
- This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power company.
- 9. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
- 10. Never push objects of any kind into this product through the slots in the telephone base or handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- 11. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.

You can add new **IS8101** handsets (purchased

separately) to your IS8151-1/IS8151-2/IS8151-3/

IS8151-4/IS8151-5/ IS8152-5 telephone system.

Your telephone system supports a maximum of

Each handset must be registered with the

purchased, each expansion handset displays

Charge the new handset without interruption for

To register a handset to IS8151 telephone base:

Put the handset you wish to register on the

Both the handset and the telephone base

show **Registering...** Please wait. When the

registration process completes, the handset

and the telephone base display **HANDSET**

the telephone base beep. The handset is

now registered with the telephone base.

The registration process takes about 90

Registered and both the handset and

Do not place

the handset in

the charger.

at least 30 minutes before registering it to the

telephone base before use. When first

BEFORE USE

Add and register a handset

To register HS, see manual.

telephone base cradle.

IS8151 base

seconds.

12 handsets.

□ Note

- 12. Do not overload wall outlets and extension cords.
- 13. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
- · When the power supply cord or plug is damaged or frayed. explode. · If liquid has been spilled onto the product.
- If the product has been exposed to rain or
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product
- to normal operation. If the product has been dropped and the telephone base and/or handset has been damaged.
- If the product exhibits a distinct change in performance.
- 14. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.
- 15. Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
- 16. Only put the handset of your telephone next to your ear when it is in normal talk mode.
- 17. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, underthe-table or cabinet outlet.
- 18. For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.

If registration fails, **Registration failed** appears

on both screens. The handset shows To register

HS, see manual. and the telephone base returns

to idle mode. This may take up to five minutes to

If you want to replace a handset or reassign the

handset, you must deregister all the handsets and

telephone base, you must deregister all handsets,

and then register each handset individually to the

To deregister all handsets from the telephone base:

base for about 10 seconds until the HOME

light on the telephone base turns on and

IS8151 base

must press **FIND HS** while the **HOME** light is

still flashing. The **HOME** light turns off, and

manual. when the deregistration process

completes. The deregistration process

2. Immediately press FIND HS again. You

3. All handsets display To register HS, see

you hear a confirmation tone.

takes about 10 seconds.

starts flashing. The telephone base screen

HS

1. Press and hold FIND HS on the telephone

shows Deregister all devices?.

designated handset number of a registered

then individually register each handset.

If you want to register a handset to another

occur. Please start again from Step 1.

Deregister handsets

desired telephone base.

- 19. A CAUTION: Use only the batteries indicated in this manual. There may be a risk of explosion if a wrong type of battery is used for the handset. Use only the supplied rechargeable batteries or replacement batteries (BT183342/BT283342) for the handset. Do not dispose of batteries in a fire. They may
- 20. Use only the adapter included with this product. Incorrect adapter polarity or voltage can seriously damage the product.

SAVE THESE INSTRUCTIONS

- CAUTION: Use Only Supplied Battery.
- · Do not dispose of the battery in a fire. Check with local waste management codes for special disposal instructions.
- · Do not open or mutilate the battery. Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
- · Exercise care in handling batteries in order not to create a short circuit with conductive
- Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.

Precautions for users of implanted cardiac

Cardiac pacemakers (applies only to digital cordless telephones):

Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians

Pacemaker patients

- Should keep wireless telephones at least six inches from the pacemaker.
- · Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- Should use the wireless telephone at the ear opposite the pacemaker.

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless telephones.

· If the deregistration process fails, you may

You cannot deregister the handsets if any

· Even if the battery is depleted, you can still

deregister the handsets by following the

This cordless telephone operates with the

maximum power allowed by the Federal

Communications Commission (FCC). Even

so, this handset and telephone base can

communicate over only a certain distance

- which can vary with the locations of the

and the layout of your home or office.

telephone base and handset, the weather,

displays Out of range OR no power at base.

If there is a call while the handset is out of

press Move closer to the telephone

range, it may not ring, or if it does ring, the

base, and then press to answer the call. If the handset moves out of range during

a telephone conversation, there may be

closer to the telephone base.

interference. To improve reception, move

of connect well when you

When the handset is out of range, the handset

steps. After the handset is charged for at least

10 minutes, the screen shows To register HS,

base and plug it back in.

Operating range

other system handset is in use.

need to reset the system and try again. To

reset, unplug the power from the telephone

WHAT'S IN THE BOX

CHARGER OVERVIEW

HANDSET OVERVIEW

1 - Charging pole

Your telephone package contains the following items. Save your sales receipt and original packaging in the event warranty service is 3 – PUSH TO TALK necessary

- · Press to initiate a one-to-one or one-togroup broadcast
- Press and hold to broadcast to a group of system devices.

4 – Softkeys (2)

- · Press to select the menu item displayed above the key
- While in a menu, press to select an item, save an entry or setting, cancel an operation, or back up to the previous menu.

5 – CELL 1/ CELL 2

- Press to make or answer a cell call.
- During a cell call, press to answer an incoming CELL 1/ CELL 2 call when you hear a call waiting alert.
- During message playback, press to call back the caller if the caller's number is available.

6 - WI/ NOLUME

- Press to show phonebook entries when the handset is not in use.
- Press to scroll up while in menus.
- Press to increase the listening volume when on a call or to increase the message playback
- While entering names or numbers, press to move the cursor to the right.

−CID/ VOLUME ✓

- Press CID to show caller ID log when the handset is not in use.
- · Press to scroll down while in menus. • Press to decrease the listening volume
- While entering names or numbers, press to

when on a call or to decrease the message

move the cursor to the left.

7 – OFF/CANCEL

- During a call, press to hang up.
- While in a menu, press to cancel an operation, back up to the previous menu, or exit the menu display; or
- press and hold this button to exit to idle
- When the handset is ringing, press to mute the ringer temporarily.
- <u>Press and hold</u> while the telephone is not in use to erase the missed call indicator.

- Press to display other dialing options when reviewing a caller ID log entry.
- <u>Press and hold</u> to enter the **QUIET** mode setting screen, or to deactivate QUIET mode.

9 – CALL BLOCK

• Press to enter Smart call blocker menu.

10 - REDIAL/PAUSE

Press to review the redial list.

• Press and hold to insert a dialing pause while

entering a number.

11 - CHARGE light

· On when the handset is charging in the telephone base or charger

12 – A HOME /FLASH

· Press to make or answer a home call.

 During message playback, press to call back the caller if the caller's number is available.

 During a call, press to answer an incoming home call when you receive a call waiting

13 - M |

While reviewing a caller ID log entry, press to add or remove 1 in front of the telephone number before dialing or saving it in the phonebook

• <u>Press and hold</u> to set or to dial your voicemail number.

14 – TONE **X**

- Press to switch to tone dialing temporarily during a call if you have pulse service.
- While entering names, press to change the next letter to upper or lower case.

15 – ◀》/SPEAKER Press to make or answer a home or cell call

- using the speakerphone
- Press to switch between the speakerphone and the handset.

16 – MUTE/DELETE

- During a call, press to mute the microphone. • When the handset is ringing, press to mute the ringer temporarily.
- While reviewing the caller ID log, the directory or the redial memory, press to delete an individual entry.
- · During message or announcement playback, press to delete the playing message or the recorded announcement.
- 17 Headset jack

2 – VOICE

1 – LCD display

Press to activate the voice-controlled application of connected cell phone.

For operations and guides to help you using your telephone, and for latest information and supports, go and check the online help topics and online FAQs

Use your smartphone or mobile device to access

- Go to https://help.vtechphones.com/is8101;
- Scan the QR code on the right. Launch the camera app or QR code scanner app on vour smartphone or tablet. Hold the device' camera up to the QR code and frame it. Tap the notification to trigger the redirection of the online help
- If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it

You can also call our Customer Support at (800) 595-9511 [in US] or 1 (800) 267-7377 [in Canada] for help.



ECO MODE

our online help

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.

GENERAL PRODUCT CARE

Taking care of your telephone

Your cordless telephone contains sophisticated electronic parts, so it must be treated with care. Avoid rough treatment

Place the handset down gently. Save the original

ever need to ship it. Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle

packing materials to protect your telephone if you

near a sink, bathtub or shower **Electrical storms** Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own

safety, take caution when using electrical appliances

it with wet hands. Do not install the telephone base

during storms. Cleaning your telephone

request.

user's manual

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use dampened cloth or cleaning solvents of any kind.

bottom of this equipment contains, among

other things, a product identifier in the format

provided to your telephone service provider upon

The plug and jack used to connect this equipment

to premises wiring and the telephone network

must comply with applicable Part 68 rules and

compliant telephone cord and modular plug is

provided with this product. It is designed to be

connected to a compatible modular jack that is also

compliant. An RJ11 jack should normally be used

for connecting to a single line and an RJ14 jack for

two lines. See the installation instructions in the

The Ringer Equivalence Number (REN) is used to

determine how many devices you may connect to

your telephone line and still have them ring when

as the 6th and 7th characters following the US: in

the product identifier (e.g., if ## is 03, the REN is

0.3). In most, but not all areas, the sum of all RENs

should be five (5.0) or less. For more information,

please contact your telephone service provider.

This equipment must not be used with Party

equipment connected to your telephone

Lines. If you have specially wired alarm dialing

line, ensure the connection of this equipment

have questions about what will disable alarm

If this equipment is malfunctioning, it must be

unplugged from the modular jack until the

problem has been corrected. Repairs to this

telephone equipment can only be made by the

manufacturer or its authorized agents. For repair

procedures, follow the instructions outlined under

If this equipment is causing harm to the telephone

network, the telephone service provider may

temporarily discontinue your telephone service.

notify you before interrupting service. If advance

notice is not practical, you will be notified as soon

as possible. You will be given the opportunity to

correct the problem and the telephone service

provider is required to inform you of your right

to file a complaint with the FCC. Your telephone

service provider may make changes in its facilities,

equipment, operation, or procedures that could

affect the proper functioning of this product. The

The telephone service provider is required to

equipment, consult your telephone service

provider or a qualified installer.

the **Limited warranty**.

does not disable your alarm equipment. If you

you are called. The REN for this product is encoded

technical requirements adopted by ACTA. A

US:AAAEQ##TXXXX. This identifier must be

 Privacy: The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones.

ABOUT CORDLESS

TELEPHONES

- **Electrical power:** The telephone base of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.
- Potential TV interference: Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR often reduces or eliminates the interference.
- Rechargeable batteries: Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.
- Nickel-metal hydride rechargeable batteries: Dispose of these batteries in a safe manner. Do not burn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.

telephone service provider is required to notify

If this product is equipped with a corded or

cordless handset, it is hearing aid compatible.

If this product has memory dialing locations,

numbers (e.g., police, fire, medical) in these

locations. If you do store or test emergency

you may choose to store emergency telephone

Remain on the line and briefly explain the reason

Perform such activities in off-peak hours, such as

This device contains licence-exempt transmitter(s)/

receiver(s) that comply with Innovation, Science

and Economic Development Canada's licence-

exempt RSS(s). Operation is subject to the

(1) This device may not cause interference.

(2) This device must accept any interference.

including interference that may cause undesired

Privacy of communications may not be ensured

number only signifies that the Industry Canada

The Ringer Equivalence Number (REN) for this

terminal equipment is 1.0. The REN indicates

the maximum number of devices allowed to

be connected to a telephone interface. The

combination of devices subject only to the

termination of an interface may consist of any

requirement that the sum of the RENs of all the

This product meets the applicable Innovation,

Science and Economic Development Canada

The term "IC:" before the certification/registration

you if such changes are planned.

for the call before hanging up

early morning or late evening.

following two conditions:

operation of the device.

when using this telephone.

devices not exceed five.

technical specifications.

technical specifications were met.

numbers, please:

Industry Canada

FOR C-UL COMPLIANCE

Mesures de sécurité importantes

Afin de réduire les risques d'incendie, de blessures corporelles ou d'électrocution, suivez toujours ces mesures préventives de base lorsque vous utilisez votre téléphone

- 1. Lisez et comprenez bien toutes les instructions. 2. Observez toutes les instructions et mises en garde inscrites sur l'appareil.
- Débranchez ce téléphone de la prise murale avant de le nettoyer. N'utilisez pas de nettoyeurs liquides ni en aérosol. N'utilisez
- qu'un chiffon doux et légèrement humecté 4. N'utilisez pas ce produit près de l'eau, tel que près d'un bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage ou d'une piscine, ou dans un sous-sol humide ou sous la douche.
- Ne déposez pas ce téléphone sur un chariot. support ou table chancelants. L'appareil pourrait tomber et être sérieusement endommagé.
- 6. Évitez d'installer le système téléphonique dans les endroits soumis à une température extrême. à la lumière directe du soleil ou à proximité immédiate d'autres appareils électriques ou électroniques. Protégez votre téléphone contre les sources d'humidité, la poussière, les vapeurs et les liquides corrosifs.
- 7. Le boîtier de l'appareil est doté de fentes et d'ouvertures d'aération situées à l'arrière ou en dessous. Afin d'empêcher la surchauffe, ces ouvertures ne doivent pas être obstruées en plaçant l'appareil sur un lit, divan, tapis ou autre surface similaires. Ne placez pas cet appareil à proximité d'un élément de chauffage ni d'une plinthe électrique. De plus, ne l'installez pas dans une unité murale ou un cabinet fermé qui ne possède pas d'aération adéquate.
- Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur les étiquettes de l'appareil. Si vous ne connaissez pas le voltage de votre maison, consultez votre marchand ou votre fournisseur d'électricité.
- 9. Ne déposez rien sur le cordon d'alimentation. Installez cet appareil dans un endroit sécuritaire, là où personne ne pourra trébucher sur la ligne d'alimentation ni le cordon téléphonique
- 10. N'insérez jamais d'objets à travers les fentes et ouvertures de cet appareil, car ils pourraient toucher à des points de tension dangereux ou court-circuiter des pièces, ce qui constituerait un risque d'incendie ou d'électrocution. N'échappez pas de liquides dans l'appareil.

CALIFORNIA ENERGY

11. Afin de réduire les risques d'électrocution, ne démontez pas l'appareil, mais apportez-le plutôt à un centre de service qualifié s'il doit être réparé. En enlevant le couvercle, vous vous exposez à des tensions dangereuses ou autres dangers similaires. Un remontage inadéquat peut être à l'origine d'une électrocution lors d'une utilisation ultérieure de l'appareil. Débranchez l'appareil avant de procéder au nettoyage. Utilisez un chiffon humide et doux.

- 12. Ne surchargez pas les prises de courant et les rallonges.
- 13. Débranchez cet appareil de la prise de courant et communiquez avec le département de service à la clientèle de VTech dans les cas
- Lorsque le cordon d'alimentation est endommagé ou écorché
- Si du liquide a été échappé dans l'appareil. • Si l'appareil a été exposé à une source
- d'humidité telle que la pluie ou l'eau.
- · Si le produit ne fonctionne pas normalement en respectant les instructions de fonctionnement. Réglez uniquement les commandes indiquées dans le les instructions de fonctionnement. Les réglages incorrects des autres commandes pourraient provoquer un dommage qui pourrait exiger un travail exhaustif de la part d'un technicien autorisé afin de rétablir le fonctionnement normal de l'appareil.
- Si le produit a été échappé et que le socle et/ ou le combiné a été endommagé.
- · Si le produit affiche une nette diminution de sa performance
- 14. Évitez d'utiliser un téléphone (autre qu'un sans fil) pendant un orage. Les éclairs peuvent être à l'origine d'une électrocution.
- 15. N'utilisez pas le téléphone pour rapporter une fuite de gaz à proximité de la fuite. En certaines circonstances, une flammèche pourrait être provoquée lorsque l'adaptateur est branché à une prise de courant, ou lorsque le combiné est déposé sur le socle. Ceci est un événement commun associé à la fermeture d'un circuit électrique. L'utilisateur ne devrait pas brancher le téléphone à une prise de courant, et ne devrait pas déposer le combiné chargé sur le socle, si le téléphone se trouve à proximité d'un endroit comportant des concentrations de gaz inflammables, à moins que la ventilation soit adéquate. Une flammèche dans un tel endroit pourrait provoquer un incendie ou une explosion. De tels environnements peuvent comprendre: des endroits où l'on utilise de

l'oxygène médical sans ventilation adéquate: des gaz industriels (dissolvants de nettoyage, des vapeurs d'essence, etc.); une fuite de gaz naturel, etc

- 16. Ne placez que le combiné de votre téléphone près de votre oreille lorsqu'en mode de
- 17. Ces adaptateurs ont été conçus pour être orientés en position verticale ou montés au sol. Les broches ne sont pas conçues pour maintenir l'adaptateur en place si celui-ci est barnché dans une prise au plafond ou sous une table/
- 18. Pour le MATERIEL RACCORDE PAR PRISE DE COURANT, le socle de prise de courant doit etre installe a proximite du materiel et doit etre aisement accessible.
- 19. A MISE EN GARDE: Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour le téléphone. N'utilisez que les piles rechargeable inclus ou les piles de rechange (BT183342/BT283342). N'incinérez pas les piles. Celles-ci risqueraient d'exploser.
- 20. 20N'utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril.

CONSERVEZ CES INSTRUCTIONS

- N'utilisez que la pile incluse ou l'équivalent. Ne jetez pas la pile au feu. Vérifiez les instructions spécifiques de mise aux rebus auprès des autorités locales.
- N'ouvrez pas et ne mutilez pas la pile. L'électrolyte qui s'en échapperait est corrosif et pourrait causer des brûlures ou des blessures aux yeux ou à la peau. L'électrolyte est toxique
- Soyez prudents lorsque vous manipulez les piles afin d'éviter les courts-circuits proyogués par des matériaux conducteurs.
- Rechargez la pile incluse avec cet appareil, selon les instructions et limites spécifiées dans ce guide d'utilisation.

Stimulateurs cardiaques implantés dans

Les simulateurs cardiaques (s'applique uniquement aux téléphones numériques sans fil):

L'organisme 'Wireless Technology Research, LLC (WTR)'. une firme de recherche indépendante, a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans fil portatifs

l'organisme. Appuyée par l'Administration des aliments et droques (FDA) des États-Unis, la firme WTR recommande aux médecins :

et les stimulateurs cardiaques implantés dans

Avis aux détenteurs de stimulateurs cardiaques

- Ils doivent tenir le téléphone sans fil à une distance d'au moins six pouces du stimulateur cardiaque
- Ils ne doivent PAS placer le téléphone sans fil directement sur le stimulateur cardiaque, tel que dans une poche de chemise, lorsque celuici est en marche.
- Ils doivent utiliser le téléphone sans fil en l'appuyant sur l'oreille qui se trouve dans la direction opposée au stimulateur cardiaque.

L'étude effectuée par l'organisme WRS n'a pas identifié de risque pour les détenteurs de simulateurs cardiaques causés par les gens qui utilisent un téléphone sans fil à proximité de ceux-

À propos des téléphones sans fil

Confidentialité: Les mêmes caractéristiques qui constituent des avantages pour les téléphones sans fil affichent également des restrictions. Les appels téléphoniques sont transmis entre le combiné sans fil et le socle par le biais d'ondes radio ; il y a donc la possibilité que vos conversations téléphoniques sans fil soient interceptées par des équipements de réception radio se trouvant dans la portée du combiné sans fil. Pour cette raison, vous ne devez pas percevoir les communications téléphoniques sans fil comme étant aussi confidentielles que celles des téléphones à cordons.

Alimentation électrique : Le socle de ce téléphone sans fil doit être branché à une prise électrique fonctionnelle. La prise électrique ne doit pas être contrôlée par un interrupteur mural. Les appels ne pourront pas être effectués du combiné sans fil si le socle est débranché ou mis hors tension ou si le courant est coupé

Possibilité d'interférences aux téléviseurs :

Certains téléphones sans fil fonctionnent sur des fréquences pouvant causer des interférences aux téléviseurs et aux magnétoscopes. Pour réduire ou prévenir de telles interférences, ne placez pas le socle du téléphone sans fil près ou sur un téléviseur ou magnétoscope. S'il y a présence de parasites, il est conseillé d'éloigner le téléphone sans fil du téléviseur ou du magnétoscope afin de réduire possiblement les interférences.

Piles rechargeables: Manipulez les piles avec soin afin de ne pas les court-circuiter avec des bagues, bracelets ou clés. Les piles ou le conducteur peut surchauffer et causer des blessures. Respectez la polarité adéquate entre la pile et le chargeur.

DISCLAIMER AND LIMITATION OF LIABILITY

assume no responsibility for any damage or loss resulting from the use of this user's manual. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.

Company: VTech Communications, Inc.

555 Tigard, OR 97223, United States

Phone: 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada

Les bloc-piles rechargeables à l'hydrure métallique de nickel: Jetez ces blocs-piles de manière écologique et sécuritaire. Ne les incinérez pas et ne les percez pas. Tel que les autres piles de ce type, elles pourraient dégager une matière toxique qui peut causer des blessures corporelles si elles sont brûlées ou percées.

THE RBRC® SEAL



The RBRC® seal on the nickel-metal hydride battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when

taken out of service within the United States and

The RBRC® program provides a convenient alternative to placing used nickel-metal hydride batteries into the trash or municipal waste, which may be illegal in your area.

VTech's participation in RBRC® makes it easy for you to drop off the spent battery at local retailers participating in the RBRC® program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY® for information on Ni-MH battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources RBRC® and 1 (800) 8 BATTERY® are registered trademarks of Rechargeable Battery Recycling

FCC, ACTA AND IC REGULATIONS FCC Part 15

NOTE: This equipment has been tested and

found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to ______

try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

is connected

- Increase the separation between the equipment
- and receiver Connect the equipment into an outlet on a

circuit different from that to which the receiver

• Consult the dealer or an experienced radio/TV technician for help

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this telephone

authority to operate the equipment.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The handset may be safely held against the ear of the user. For body worn operation, this handset has been tested and meets the FCC RF exposure guidelines when used with the accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more.

This Class B digital apparatus complies with Canadian requirement: CAN ICES-3 (B)/NMB-3(B).

For body worn operation, this handset has been tested and meets the FCC RF exposure guidelines when used with the accessories supplied or designated for this product. Use of other accessoriesmay not ensure compliance with FCC RF exposure guidelines.

FCC Part 68 and ACTA

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or

IECHNICAL SPECIFICATIONS

VTech Communications, Inc. and its suppliers

Address: 9020 SW Washington Square Road - Ste

Crystal controlled PLL synthesizer

Transmit Handset: 1921.536-1928.448 MHz frequency Channels DECT channel: 5

Ni-MH battery

vary according to environmer

conditions at the time of use.

Handset: 2.4 V DC, AAA×2,

Charger: 6V DC @ 400mA

Phonebook: 200 memory

Call block: 1000 entries

up to 30 digits and 15 characters

up to 24 digits and 15 characters

Caller ID log: 50 memory locations;

Maximum power allowed by FCC Nominal and IC. Actual operating range may effective

requirement

Memory

Specifications are subject to change without notice. © 2020 for VTech Communications, Inc. All rights reserved. 06/20. IS8101_CIB_V2.0 Document order number: 91-012013-020-100

confirmation tone. The **HOME** light turns off and all handsets display **To register HS, see manual**. Allow up to one minute for the process to

- 1. Unplug the telephone base power adapter from the power outlet, and then plug it back in. Then the telephone base is powered up as normal.
- to begin registration. 3. The telephone base shows **Registering... Please** wait, and the handset then shows Registering... Please wait. If the registration is successful, the

LIMITED WARRANTY COMMISSION BATTERY CHARGING What does this limited warranty cover?

TESTING INSTRUCTIONS This telephone is set up to comply with the energyconserving standards right out of the box. These instructions are intended for California Energy Commission (CEC) compliance testing only. When the CEC battery charging testing mode is activated, all telephone functions, except battery charging, will be disabled.

To activate the CEC battery charging testing

- 1. Unplug the telephone base power adapter from the power outlet. Make sure all handsets are plugged with charged batteries before
- proceeding. 2. While you press and hold FIND HS, plug the telephone base power adapter back to the power outlet.
- 3. After about 20 seconds, when the **HOME** light starts flashing, release **FIND HS** and then press it again within two seconds. You hear a complete.

If the phone fails to enter this mode, repeat all the steps mentioned above. The telephone base will be powered up as normal if you fail to press FIND HS within two seconds in Step 3.

To deactivate the CEC battery charging testing

- 2. Put the handsets on the telephone base cradle
- handset screen displays **HANDSET Registered** and beeps. The handset is registered with the telephone base.

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America

and Canada. What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective

Product")? During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment, Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will eturn the repaired or replacement Products to you in working condition. You should expect the repair or replacement to take approximately 30 days.

How long is the limited warranty period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original oneyear warranty; whichever is longer

What is not covered by this limited warranty? This limited warranty does not cover:

- 1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion.
- 2. Product that has been subjected to contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like; but then only to the extent the damage was not caused by incorrectly securing the waterproof

- handset's protective elements, for example, failing to properly close a seal), or such protective elements are damaged or missing (e.g. a cracked battery door), or subjecting a Product to conditions beyond its stated specifications or limits (e.g. 30 minutes in 1 meter of fresh water).
- alteration or modification by anyone other than an authorized service representative of VTech: Product to the extent that the problem
- caused by use with non-VTech accessories: Product whose warranty/quality stickers, product serial number plates or electronic
- Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes rental purposes);
- 8. Product returned without a valid proof of purchase (see item 2 below); or
- Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

How do you get warranty service? To obtain warranty service in the United States of America, please visit our website at

user's manual - a check of the Product's controls and features may save you a service call.

Except as provided by applicable law, you assume

the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited terms of this limited warranty, VTech will notify you

Product that has been damaged due to repair,

experienced is caused by signal conditions,

- network reliability, or cable or antenna systems; Product to the extent that the problem is
- serial numbers have been removed, altered or rendered illegible;
- (including but not limited to Products used for
- www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or dial 1 (800) 267-7377. NOTE: Before calling for service, please review the

warranty, or proof of purchase does not meet the

and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty

What must you return with the Product to get

- warranty service? Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
- 2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase o receipt; and
- 3. Provide your name, complete and correct mailing address, and telephone number.

Other limitations This warranty is the complete and exclusive

agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such

State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of

fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the damages, so the above limitation or exclusion may

exclusion or limitation of incidental or consequential

Please retain your original sales receipt as proof of