

Item	Brand Name	Model
1	Acer	Acer beTouch E210
2	Acer	acer E400
3	Acer	acer P400
4	Acer	DX650
5	Acer	E200
6	Acer	Liquid E
7	Acer	Liquid Mini (E310)
8	Acer	M900
9	Acer	S110
10	Acer	Smart handheld
11	Acer	Smart handheld
12	Acer	Smart handheld E100
13	Acer	Smart handheld E101
14	Adec & Partner AG	AG vegas
15	Alcatel	MISS SIXTY MSX10
16	Alcatel	OT-800/ OT-800A
17	Alcatel	OT-802/ OT-802A
18	Alcatel	OT-806/ OT-806A/ OT-806D/ OT-807/ OT-807A/ OT-807D
19	Alcatel	OT-808/ OT-808A
20	Alcatel	OT-880/ OT-880A
21	Alcatel	OT-980/ OT-980A
22	Altek	Altek A14
23	Amgoo Telecom Co LTD	AM83
24	Apple	Apple iPhone 4S
25	Apple	Apple iPhone 5
26	Apple	iPhone 2G
27	Apple	iPhone 3G
28	Apple	iPhone 3Gs
29	Apple	iPhone 4
30	Apple	iPhone 5C
31	Apple	iPHone 5S
32	Aramasmobile.com	ZX021
33	Ascom Sweden AB	3749
34	Asustek	1000846
35	Asustek	A10
36	Asustek	G60
37	Asustek	Galaxy3_L and Galaxy3_S
38	Asustek	Garmin-ASUS M10E
39	Asustek	P320
40	Asustek	P565c
41	BlackBerry	BlackBerry Q10
42	Broadcom Corporation	BTL-A
43	Casio Hitachi	C721
44	Cellnet 7 Inc.	DG-805
45	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2052,
46	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2053,
47	Cellon Communications Technology(Shenzhen) Co., Ltd.	C3031
48	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5030,
49	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5031,
50	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5136,
51	Cellon Communications Technology(Shenzhen) Co., Ltd.	C7519
52	Cellon Communications Technology(Shenzhen) Co., Ltd.	C8093,
53	Cellon Communications Technology(Shenzhen) Co., Ltd.	Claro ADR1105,
54	Cellon Communications Technology(Shenzhen) Co., Ltd.	PCD ADR1105,
55	Chi Mei	AQ4
56	Chi Mei	P300
57	Chi Mei Communication Systems, Inc.	VIZIO (VPHN1044G)
58	China Bird (HK) Limited	Carisma 150
59	Cisco	Cius
60	Cisco	CP-7926G VoIP Telephone
61	Dell Computer Corporation	M01M
62	Dell Computer Corporation	V03B
63	Dell Computer Corporation	V03B, V03B001, V03B002
64	Doro AB	Doro PhoneEasy@ 610
65	Doro AB	Doro PhoneEasy@ 615
66	ecom instruments GmbH	Ex-Handy 07 .0 -A
67	ecom instruments GmbH	Ex-Handy 07 .0 -E
68	ecom instruments GmbH	Ex-Handy 07 .2 -A
69	ecom instruments GmbH	Ex-Handy 07 .2 -E
70	FIH	FM600
71	FIH	N700
72	FIH	PDA Phone
73	FIH	test_RM-383
74	FIH	ViewPad7
75	FIH CO., LTD	FAD
76	FIH CO., LTD	VS14034
77	Fujitsu	T-01C
78	Fujitsu Limited	F-12C

Item	Brand Name	Model
79	Fusion Garage Pte Ltd	Grid4
80	Garmin asus	G60
81	Global High Tech	GHT Maestro
82	Google	Google Nexus 5
83	Google	Google Nexus S
84	HAUS	JS100
85	Hewlett-Packard	HSTNH-P21C
86	HP	iPAD912
87	HTC	ADR6200VW
88	HTC	ADR6300
89	HTC	ADR6300
90	HTC	ADR6330VW
91	HTC	ADR6400L
92	HTC	ADR6425 LVW
93	HTC	ADR6425LVW
94	HTC	CDMA HT111
95	HTC	CEDA100 Series
96	HTC	CEDA100 Series
97	HTC	CEDA100 Series (WM6.5)
98	HTC	Dash 3G
99	HTC	Droid Eris
100	HTC	EVO
101	HTC	Evo 4G
102	HTC	FUZE (TM) P4600
103	HTC	G1
104	HTC	HD2
105	HTC	HD7
106	HTC	Hero
107	HTC	HERO200
108	HTC	HTC 7 Pro
109	HTC	HTC Amaze 4G
110	HTC	HTC ChaCha
111	HTC	HTC Droid DNA
112	HTC	HTC Droid Incredible 4G LTE
113	HTC	HTC First
114	HTC	HTC HD mini
115	HTC	HTC Hero
116	HTC	HTC One
117	HTC	HTC One Mini
118	HTC	HTC One X
119	HTC	HTC One X+
120	HTC	HTC Rezound
121	HTC	HTC Snap
122	HTC	HTC Tattoo
123	HTC	HTC Titan 2
124	HTC	HTC Touch Diamond 2 T5353
125	HTC	HTC Touch Diamond2
126	HTC	HTC Touch2
127	HTC	HTC Wildfire
128	HTC	HTC Wildfire A3333
129	HTC	HTC Windows Phone 8X
130	HTC	Incredible
131	HTC	MyTouch 3g
132	HTC	Nexus One
133	HTC	Nexus One
134	HTC	Ozone
135	HTC	PB00 Series
136	HTC	PB65 series
137	HTC	PB76100
138	HTC	PB81 Series
139	HTC	PB92100
140	HTC	PB92110
141	HTC	PB92110 series
142	HTC	PB99 (CDMA)
143	HTC	PB99 Android 2.2 series
144	HTC	PB99400
145	HTC	PC10100
146	HTC	PC10xxx
147	HTC	PC36100
148	HTC	PC36100
149	HTC	PC36XXX
150	HTC	PC40100
151	HTC	PC402XX
152	HTC	PC402XX
153	HTC	PC57 Series
154	HTC	PC63xxx Android 2.2
155	HTC	PC70 series
156	HTC	PC92xxx
157	HTC	PC931XX
158	HTC	PC96 Series
159	HTC	PC991XX
160	HTC	PC992XX
161	HTC	PD051XX
162	HTC	PD06100
163	HTC	PD11 Series
164	HTC	PD112xx
165	HTC	PD15xxx

Item	Brand Name	Model
166	HTC	PD2610000
167	HTC	PD261XX
168	HTC	PD29xxx
169	HTC	PD421XX
170	HTC	PD42XXX
171	HTC	PD67100
172	HTC	PD98xxx(A9192)
173	HTC	PG05XXX
174	HTC	PG061XX
175	HTC	PG06XXX
176	HTC	PG321XX
177	HTC	PG321XX
178	HTC	PG32XXX
179	HTC	PG32XXX
180	HTC	PG41xxx
181	HTC	PG58100
182	HTC	PG59xxx
183	HTC	PG7624000
184	HTC	PG762XX
185	HTC	PG76XXX
186	HTC	PG86xxx
187	HTC	PG88xxx
188	HTC	PH11xxx
189	HTC	PH39xxx
190	HTC	PH44XXX
191	HTC	PH85xxx
192	HTC	PI06XXX
193	HTC	PI391XX
194	HTC	PI39XXX
195	HTC	PI42XXX
196	HTC	PI46xxx
197	HTC	PI86XXX
198	HTC	PJ03XXX
199	HTC	Pure
200	HTC	RHOD100 Series
201	HTC	RHOD50000 Series
202	HTC	SHADOW
203	HTC	Shadow 2009
204	HTC	SMT 5800
205	HTC	Snap
206	HTC	Surround
207	HTC	Tilt 2
208	HTC	Touch Diamond
209	HTC	Touch Dual
210	HTC	Touch HD
211	HTC	Touch Pro
212	HTC	Touch Pro 2
213	HTC	Touch Pro2
214	HTC	TWIN10000 Series
215	HTC	WHIT10000 Series
216	HUAWEI	007HW
217	HUAWEI	C5120
218	HUAWEI	C8150
219	HUAWEI	C8150-1
220	HUAWEI	D51-1
221	HUAWEI	G5510
222	HUAWEI	G6050
223	HUAWEI	G6609
224	HUAWEI	G7300
225	HUAWEI	GM Ultimate Slim/ HUAWEI U8510-1/ U8510-1
226	HUAWEI	HUAWEI C8500
227	HUAWEI	HUAWEI C8600/ HUAWEI M860
228	HUAWEI	HUAWEI C8850
229	HUAWEI	HUAWEI G5500
230	HUAWEI	HUAWEI G6008
231	HUAWEI	HUAWEI G6151
232	HUAWEI	HUAWEI G6605
233	HUAWEI	HUAWEI G6608
234	HUAWEI	HUAWEI G6620
235	HUAWEI	HUAWEI G6626
236	HUAWEI	HUAWEI G7050
237	HUAWEI	HUAWEI G7205
238	HUAWEI	HUAWEI G7210 / PANAMA CU
239	HUAWEI	HUAWEI M615
240	HUAWEI	HUAWEI M635
241	HUAWEI	HUAWEI M835/ M835
242	HUAWEI	HUAWEI M865, M865, HUAWEI M865 MUVE
243	HUAWEI	HUAWEI M886/ M886/ HUAWEI C8860/ C8860
244	HUAWEI	HUAWEI T2251
245	HUAWEI	HUAWEI T2281
246	HUAWEI	HUAWEI T2311
247	HUAWEI	HUAWEI T2361
248	HUAWEI	HUAWEI T5900
249	HUAWEI	HUAWEI T6300
250	HUAWEI	HUAWEI T8300
251	HUAWEI	HUAWEI T8600
252	HUAWEI	HUAWEI U2800
253	HUAWEI	HUAWEI U5200
254	HUAWEI	HUAWEI U5300

Item	Brand Name	Model
255	HUAWEI	HUAWEI U6150
256	HUAWEI	HUAWEI U8160/ U8160/ Vodafone 858 Smart/ Vodafone 858/ VF858
257	HUAWEI	HUAWEI U8160-U/ U8160-U/ Vodafone 858 Smart/ Vodafone 858/ VF858
258	HUAWEI	HUAWEI U8180-1/ U8180-1/ HUAWEI U8180/ U8180/ Stockholm/ T-Mobile Rapport/ Android Edition™ StarShine
259	HUAWEI	HUAWEI U8180-7/ U8180-7
260	HUAWEI	HUAWEI U8300/ U8300
261	HUAWEI	HUAWEI U8350/ U8350/ U8350-1/ Barcelona/ Boulder
262	HUAWEI	HUAWEI U8350-3/ U8350-3
263	HUAWEI	HUAWEI U8350-51/ U8350-51
264	HUAWEI	HUAWEI U8500/ U8500/ HUAWEI U8500-6/ U8500-6
265	HUAWEI	HUAWEI U8520-51/ U8520-51
266	HUAWEI	HUAWEI U8650-1/ U8650-1
267	HUAWEI	HUAWEI U8650NFC-1/ U8650NFC-1
268	HUAWEI	HUAWEI U8652/ U8652/ Huawei U8652/ U8652-51
269	HUAWEI	HUAWEI U8800 Pro/ U8800 Pro
270	HUAWEI	HUAWEI U8800-51/ U8800-51
271	HUAWEI	HUAWEI U8820/ U8820/ Titan
272	HUAWEI	HUAWEI U8850-1
273	HUAWEI	HUAWEI U8860/ U8860/ Honor
274	HUAWEI	MTC 752
275	HUAWEI	PCDM650KT/ HUAWEI M650/ M650/ HUAWEI C8350/ C8350
276	HUAWEI	S31HW/ U8150-92/ HUAWEI U8150-92
277	HUAWEI	S7-105
278	HUAWEI	S7-201c
279	HUAWEI	S7-201u
280	HUAWEI	S7-202c
281	HUAWEI	S7-202u
282	HUAWEI	U2801-34
283	HUAWEI	U5110h-1
284	HUAWEI	U8150-A
285	HUAWEI	U8150-D
286	HUAWEI	U8520/ HUAWEI U8520-1/ HUAWEI U8520/ U8520-1
287	HUAWEI	UM840
288	INQ Mobile	T2-219U/ T2-218U
289	inventec	S42HW
290	inventec	T-101
291	iWOW	Libero
292	JRD Communication (ShenZhen)	one touch 678G
293	KT Tech	EV-S100
294	KT Tech	KM-S120
295	KT Tech	KM-S200
296	KT Tech	KM-S220
297	KT Tech	KM-S220H
298	KT Tech	KM-S300
299	Kyocera	C4700
300	Kyocera	CLIP
301	Kyocera	Glide-M1400
302	Kyocera	ISW11K
303	Kyocera	K50
304	Kyocera	M2000
305	Kyocera	M6000
306	Kyocera	Mobile Phone 16 (E76)
307	Kyocera	S1310
308	Kyocera	S1350
309	Kyocera	S2300
310	Kyocera	S2410
311	Kyocera	SANYO SCP-3810
312	Kyocera	SCP-2700
313	Kyocera	SCP-8600
314	Kyocera	SCP-8600
315	Kyocera	Taho E4100
316	Kyocera	Torino
317	LG	BL20df/ BL20cf
318	LG	BL20v
319	LG	BL40
320	LG	BL40/ BL40g/ BL40f
321	LG	BL40e
322	LG	BL42/ BL42e/ BL42v/ BL42k/ BL42N/ BL20/ BL20e/ BL20v/ BL20k/ BL20N
323	LG	CD02/ VER-01
324	LG	CF360
325	LG	Chocolate Touch
326	LG	CT520
327	LG	Dare VX9700
328	LG	enV3
329	LG	enV3 VX9200
330	LG	eXpo (GW820)
331	LG	GB250
332	LG	GC900
333	LG	GC900/ GC900F
334	LG	GC900e
335	LG	GC970/ GC970h
336	LG	GD 580 Lollipop
337	LG	GD310 Ice Cream 2
338	LG	GD510
339	LG	GD510 Pop
340	LG	GD510N
341	LG	GD550
342	LG	GD550e
343	LG	GD570
344	LG	GD570AW, GD570AV
345	LG	GD880/ GC970

Item	Brand Name	Model
346	LG	GD880f, GD880g
347	LG	GD900
348	LG	GD900/ GD900e
349	LG	Glance
350	LG	GM210
351	LG	GM360i
352	LG	GM600
353	LG	GM730/ GM730f/ GM735/ GM730e
354	LG	GM750
355	LG	GM750h
356	LG	GM750Q
357	LG	GR700
358	LG	GS290
359	LG	GS390
360	LG	GS500
361	LG	GS500f for PCL
362	LG	GS500f, GS500g, GS500k, GS500v
363	LG	GS500gX
364	LG	GS505
365	LG	GT350
366	LG	GT350F
367	LG	GT350i
368	LG	GT360
369	LG	GT370
370	LG	GT400/ GT405
371	LG	GT500/ GT505
372	LG	GT540
373	LG	GT550
374	LG	GT620
375	LG	GT950Q
376	LG	GU230
377	LG	GU280, GU285, GU285f, GU285g
378	LG	GU280f
379	LG	GU282
380	LG	GU285
381	LG	GU290/ GU290f
382	LG	GU290v
383	LG	GU295/ GU292
384	LG	GU295f, GU295g
385	LG	GU297 , GU297a
386	LG	GW300, LG900G
387	LG	GW300FD, GW305
388	LG	GW380/ GW370B/ GW375/ GW382f/ GW380f/ GW380g
389	LG	GW520
390	LG	GW525gX
391	LG	GW550
392	LG	GW550h
393	LG	GW620
394	LG	GW820, GW825, GW825v
395	LG	GX200
396	LG	GX500
397	LG	GX500
398	LG	INCITE
399	LG	IS11LG
400	LG	KC910
401	LG	KC910, KC910Q, KC910Qa, KC910e, KC910i
402	LG	KM553
403	LG	KM555
404	LG	KM555
405	LG	KM555e
406	LG	KM555R
407	LG	KM570
408	LG	KM900
409	LG	KP275
410	LG	KP500
411	LG	KP500N
412	LG	KP501/ KP502/ KP550
413	LG	KP505
414	LG	KS360
415	LG	KS365
416	LG	KT770, KT770f
417	LG	L-01D
418	LG	L-02D, PR-01D
419	LG	L-04C
420	LG	L-07C
421	LG	LG 3G Mobile Phone (GD910)
422	LG	LG 3G Mobile Phone (GT950)
423	LG	LG 3G Mobile Phone (LG- GT540/ GT540f/ GT540g)
424	LG	LG 3G Mobile Phone (LG-A340)
425	LG	LG 3G Mobile Phone (LG-A350 / LG-A355 / LG-A360)
426	LG	LG 3G Mobile phone (LG-C550 / LG-C550f)
427	LG	LG 3G Mobile Phone (LG-C800)
428	LG	LG 3G Mobile Phone (LG-C800G)
429	LG	LG 3G Mobile Phone (LG-E300)
430	LG	LG 3G Mobile Phone (LG-E510 / LG-E510f / LG-E510g)
431	LG	LG 3G Mobile Phone (LG-GB258)
432	LG	LG 3G Mobile Phone (LG-P350)
433	LG	LG 3G Mobile Phone (LG-P690 / LG-P692 / LG-P690f / LG-P690g)
434	LG	LG 3G Mobile Phone (LG-P690b)

Item	Brand Name	Model
435	LG	LG 3G Mobile Phone (LG-P698 / LG-P698f)
436	LG	LG 3G Mobile Phone (LG-P699)
437	LG	LG 3G Mobile Phone(GM730E)
438	LG	LG 3G Mobile Phone(GW820)
439	LG	LG 3G Mobile Phone(KB770, KB775, KB775f)
440	LG	LG 3G Mobile Phone(LG-A353)
441	LG	LG 3G Mobile Phone(LG-KU3800)
442	LG	LG 3G Mobile Phone(LG-T320, LG-T320e, LG-T320g, LG-T320v, LG-T320k, LG-T320gv)
443	LG	LG A340
444	LG	LG CDMA Mobile Phone (LG-CX7100)
445	LG	LG CDMA Mobile Phone (LG-LG5500X for Koodo)
446	LG	LG CDMA Mobile Phone (LG-LS700/ LG-VS700/ LG-US700/ LG-AS700/ LG-CS700/ LG-LG701/ LG-VM701)
447	LG	LG CDMA Mobile Phone (LG-MN180)
448	LG	LG CDMA Mobile Phone (LG-SV850)
449	LG	LG CDMA Mobile Phone (LG-SV850)
450	LG	LG CDMA Mobile Phone (LG-UN200/ LG501C/ AN200/ VM200 / CM200 / BM200/ LW200/ MN200 / CX200B / CX200)
451	LG	LG CDMA Mobile Phone (LG-VN251/ LG-UN251/ LG-MN251/ LG251)
452	LG	LG CDMA Mobile Phone (LG-VS910)
453	LG	LG CDMA Mobile Phone (VX7100)
454	LG	LG CDMA Mobile Phone (VX8575/ AX8575)
455	LG	LG CDMA Mobile Phone(LG LN510)
456	LG	LG CDMA Mobile Phone(LG- LN510)
457	LG	LG CDMA Mobile Phone(LG220C)
458	LG	LG CDMA Mobile Phone(LG-CX9200)
459	LG	LG CDMA Mobile Phone(LG-CX9600)
460	LG	LG CDMA Mobile Phone(LGL85C)
461	LG	LG CDMA Mobile Phone(LG-LS855/ LG-US855/ LG-AS855/ LG-LG855/ LG-VM855)
462	LG	LG CDMA mobile phone(LG-UX700, LG-AX700, MT700, LW700, LG700, CX700, MV700, MX700, MD700, VM700)
463	LG	LG CDMA Mobile Phone(LG-VN271/ LG-AN271/ LG-UN271)
464	LG	LG CDMA Phone (LG-SU780)
465	LG	LG Escape™
466	LG	LG GSM Mobile Phone (LG-A290)
467	LG	LG GSM Mobile Phone (LG-C320i)
468	LG	LG GSM Mobile Phone (LG-C330i)
469	LG	LG GSM Mobile Phone (LG-T565/ LG-T575/ LG-T650)
470	LG	LG GSM/ GPRS/ EDGE Mobile Phone (GM360)
471	LG	LG Intuition
472	LG	LG KM900, LG KM900e, LG KM900f, LG KM900g
473	LG	LG- LG265X
474	LG	LG Lucid 2
475	LG	LG Mach
476	LG	LG Optimus G
477	LG	LG Optimus G Pro
478	LG	LG Spectrum 2
479	LG	LG TD-SCDMA Mobile Phone (GT910s)
480	LG	LG TD-SCDMA Mobile Phone(LG KT878)
481	LG	LG WCDMA Mobile Phone (LG-SU550)
482	LG	LG WCDMA Mobile Phone (LG-SU920, LG-KU9200)
483	LG	LG WCDMA Mobile Phone(LG-SU130)
484	LG	LG WCDMA Mobile Phone(LG-SU630)
485	LG	LG WCDMA Mobile Phone(LG-SU900/ LG-KU9000/ LG-LU9000)
486	LG	LG Xpression™
487	LG	LG230(CX230), LG231(CX231), LG231C(CX231C)
488	LG	LG370
489	LG	LG-3G Mobile phone (LG-C555)
490	LG	LG430G
491	LG	LG670
492	LG	LG700V, CX700V
493	LG	LG-A200
494	LG	LG-A230/ LG-A235/ LG-A225
495	LG	LG-A250 / LG-A255
496	LG	LG-A258
497	LG	LG-A310/ LG-A310f/ LG-A310k/ LG-A315/ LG-A315v
498	LG	LG-AS680
499	LG	LG-AX265
500	LG	LG-AX265 [Not Approved by SIG]
501	LG	LG-AX8370
502	LG	LG-AX840
503	LG	LG-C320
504	LG	LG-C330
505	LG	LG-C375/ LG-C370/ LG-C365/ LG-C360
506	LG	LG-C395
507	LG	LG-C510/ C510
508	LG	LG-C570f
509	LG	LG-C570g
510	LG	LG-C660/ LG-C660h/ LG-C660R
511	LG	LG-C710h/ LG-C710
512	LG	LG-C729
513	LG	LG-C900
514	LG	LG-C900N, LG-C900k, LG-C900B
515	LG	LG-CX5500X
516	LG	LG-CX670/ LGCX670
517	LG	LG-E500
518	LG	LG-E720, LG-E720b, LG-E720k
519	LG	LG-E730
520	LG	LG-E730f
521	LG	LG-E739
522	LG	LG-E900, LG-E900h
523	LG	LG-E906
524	LG	LG-F100S/ LG-F100L

Item	Brand Name	Model
525	LG	LG-GB250
526	LG	LG-GD970
527	LG	LG-GM310/ LG-GM310f/ LG-GM310g
528	LG	LG-GW370
529	LG	LG-GW520/ LG-GW525/ GW525f/ GW525g
530	LG	LG-GW610
531	LG	LG-GW820, LG-GW825
532	LG	LG-JN240
533	LG	LG-JS750, LG-JS750g
534	LG	LG-KH3400
535	LG	LG-KH3400
536	LG	LG-KH3900
537	LG	LG-KH8000
538	LG	LG-KS720
539	LG	LG-KU2100, LG-SU210, LG-LU2100
540	LG	LG-KU2200
541	LG	LG-KU2800
542	LG	LG-KU5900
543	LG	LG-KU9300
544	LG	LG-KV700 (Lollipop2)
545	LG	LG-KV700T
546	LG	LG-KW730
547	LG	LGL45C
548	LG	LGL55C
549	LG	LG-L95G
550	LG	LG-LB4400
551	LG	LG-LG265T
552	LG	LG-LG8575/ LG-MX8575
553	LG	LG-LN272 / LG272 / LG272c
554	LG	LG-LS685
555	LG	LG-LS696
556	LG	LG-LS831/ LG-T130L/ LG-US831/ LG-AS831
557	LG	LG-LS840
558	LG	LG-LU2700
559	LG	LG-LU3000
560	LG	LG-LU4500
561	LG	LG-LU6500
562	LG	LG-LU6800
563	LG	LG-LU9400
564	LG	LG-LU9400W
565	LG	LG-LX295/ LG-LX290
566	LG	LG-MS695
567	LG	LG-MS840
568	LG	LG-MS910
569	LG	LG-MT375
570	LG	LG-P500/ LG-P509/ LG-P509TN
571	LG	LG-P500/ LG-P509TN/ LG-P509BK/ LG-P509MZ/ LG-P500h/ LG-P503/ LG-P505/ LG-P504/
572	LG	LG-P500h
573	LG	LG-P501
574	LG	LG-P503
575	LG	LG-P504
576	LG	LG-P505
577	LG	LG-P505R/ LG-P505CH
578	LG	LG-P506
579	LG	LG-P920/ LG-P925/ LG-P929
580	LG	LG-P925g, LG-P920h
581	LG	LG-P930
582	LG	LG-P935
583	LG	LG-P940, LG-SU540, LG-KU5400, LG-LU5400, L-02D
584	LG	LG-P970
585	LG	LG-P970G
586	LG	LG-P970h
587	LG	LG-P990
588	LG	LG-P990h
589	LG	LG-P999
590	LG	LG-P999DW
591	LG	LG-S365/ LG-S360
592	LG	LG-S367
593	LG	LG-SB210
594	LG	LG-SB260
595	LG	LG-SH560/ LG-KH5800
596	LG	LG-SH840, LG-KH8400
597	LG	LG-SU310, LG-LU3100
598	LG	LG-SU370/ LG-KU3700/ LG-LU3700
599	LG	LG-SU410
600	LG	LG-SU420/ LG-KU4200
601	LG	LG-SU430/ LG-KU4300/ LG-LU4300
602	LG	LG-SU540/ LG-KU5400/ LG-LU5400
603	LG	LG-SU640/ LG-LU6200
604	LG	LG-SU660
605	LG	LG-SU760
606	LG	LG-SU880
607	LG	LG-SU910/ LG-KU9100/ LG-LU9100
608	LG	LG-SU950/ KU9500
609	LG	LG-SU960, LG-KU9600
610	LG	LG-SV400
611	LG	LG-SV770
612	LG	LG-T325 , LG-T325f, LG-T325g
613	LG	LG-T500/ LG-T505/ LG-T507/ LG-T510/ LG-T515/ LG-T520/ LG-T530
614	LG	LG-T565b
615	LG	LG-UN150/ LG-VN150/ LG221C/ LG235C/ LG-MN150/ LW150/ LG-VP150/ LG150

Item	Brand Name	Model
616	LG	LG-UN270
617	LG	LG-UN430
618	LG	LG-UN431/ AN431/ LG431
619	LG	LG-US760
620	LG	LG-UX310, AX310, MT310(MetroPCS), LP310, LW310(LeapWireless(Cricket)), G310, CX310, MV310, MX310, MD310
621	LG	LG-V150
622	LG	LGVN270/ LN270/ UN270/ LG270/ LG270C/ LW270/ CX270/ MN270/ TN270/ AN270/ VM270
623	LG	LG-VN530
624	LG	LG-VS660/ LS670/ US670/ LG670C/ MS690/ LW690/ VM670/ AS670
625	LG	LG-VS740/ US740/ MS740/ AS740
626	LG	LG-VS750
627	LG	LG-VS760
628	LG	LG-VS761
629	LG	LG-VS840
630	LG	LG-VS920
631	LG	LG-VX11000
632	LG	LG-VX8576
633	LG	LG-VX9200
634	LG	LN240/ MN240/ LW240/ UN240/ AN240/ VN240/ CX240
635	LG	Lotus LX600
636	LG	LU2300
637	LG	LW375
638	LG	LX290
639	LG	LX370
640	LG	LX610/ UX610/ CX610/ LG610/ VM610/ AX610/ UN610/ CN610/ VN610/ AN610
641	LG	MT375
642	LG	Neon (TM) GT365
643	LG	New LG 3G Mobile Phone(GD710)
644	LG	New LG CDMA Mobile Phone(LG-LG290C)
645	LG	Rumor 2
646	LG	Scoop / AX-260
647	LG	Shine 2
648	LG	Shine II GD710 AT&T
649	LG	Shine KE970
650	LG	UX220
651	LG	UX370
652	LG	VER-01
653	LG	Versa
654	LG	VN250
655	LG	Vortex
656	LG	Voyager VX10000
657	LG	VX5500
658	LG	VX5600
659	LG	VX8360
660	LG	VX8370
661	LG	VX8610
662	LG	X350
663	LG	Xenon (TM) GR500
664	LG	LX400
665	MediaTek	Mediatek Bluetooth® Host SW 4.0 + HS
666	MediaTek	MediaTek BlueZ (2.1+EDR)
667	MediaTek	Mediatek WM6.5 (EDR2.0)
668	MediaTek	Phone
669	Microsoft	Windows Phone 7
670	Moto	Backflip ME600
671	Moto	EM35
672	Moto	Z9N
673	Motorola	A3300c
674	Motorola	A853
675	Motorola	A855
676	Motorola	A955
677	Motorola	Amphora-i897
678	Motorola	Athens-i9 R2
679	Motorola	Backflip MB300
680	Motorola	Banfi-i856
681	Motorola	Bei Hai TD
682	Motorola	Blackstone-R2
683	Motorola	Brightwater
684	Motorola	Castle
685	Motorola	Cliq
686	Motorola	Cliq MB200
687	Motorola	Clutch (i465)
688	Motorola	Cordova
689	Motorola	Creekside-i886
690	Motorola	CRUSH
691	Motorola	Droid
692	Motorola	Droid 2
693	Motorola	Droid Pro
694	Motorola	Droid X
695	Motorola	E1
696	Motorola	E1070
697	Motorola	E398
698	Motorola	E8
699	Motorola	EM30
700	Motorola	EWP3100
701	Motorola	Fairbanks
702	Motorola	Finch
703	Motorola	FR6070, FR6076
704	Motorola	FR6874
705	Motorola	Halo
706	Motorola	Heartland

Item	Brand Name	Model
707	Motorola	i296-Gallo
708	Motorola	i365
709	Motorola	i410(Nevadacity)
710	Motorola	i576
711	Motorola	i686-Brightwater-2
712	Motorola	i776
713	Motorola	i786w (Mantra)
714	Motorola	I9
715	Motorola	K3
716	Motorola	Karma QA1
717	Motorola	MB200 refresh
718	Motorola	MB300 Backflip refresh
719	Motorola	MB501 refresh
720	Motorola	MB502
721	Motorola	MB508
722	Motorola	MB511
723	Motorola	MB520
724	Motorola	MB525
725	Motorola	MB810
726	Motorola	ME811
727	Motorola	Milestone XT720
728	Motorola	MOTO (TM) Z9
729	Motorola	Moto A3000
730	Motorola	Motorola Atrix 2
731	Motorola	Motorola Atrix HD
732	Motorola	Motorola Droid 4
733	Motorola	Motorola Droid Razr
734	Motorola	Motorola Droid Razr HD
735	Motorola	Motorola Droid Razr Maxx HD
736	Motorola	Motorola Moto X
737	Motorola	Motosurf A3000
738	Motorola	Motosurf A3100
739	Motorola	MT716
740	Motorola	Muscardini
741	Motorola	Oaknoll
742	Motorola	Q11
743	Motorola	Q9H
744	Motorola	Quailhurst iDEN-i786
745	Motorola	RAZR V3
746	Motorola	RAZR V3xx Pink
747	Motorola	RAZR2 V9
748	Motorola	Rival
749	Motorola	RIVAL (TELUS)
750	Motorola	Rush
751	Motorola	SLVR L72
752	Motorola	U9
753	Motorola	V1100
754	Motorola	V360
755	Motorola	V365
756	Motorola	V3i
757	Motorola	V3x
758	Motorola	V500
759	Motorola	V550
760	Motorola	V551
761	Motorola	V6
762	Motorola	V750
763	Motorola	V80
764	Motorola	V860
765	Motorola	V9
766	Motorola	V950
767	Motorola	V9x
768	Motorola	VE20
769	Motorola	VE440
770	Motorola	VE66
771	Motorola	VoWLAN Single Mode Smartphone
772	Motorola	VU30
773	Motorola	W418G
774	Motorola	W510
775	Motorola	W755
776	Motorola	W766
777	Motorola	W766
778	Motorola	WX345
779	Motorola	WX404
780	Motorola	XT502
781	Motorola	XT610
782	Motorola	XT701
783	Motorola	XT701 Milestone
784	Motorola	XT702
785	Motorola	XT711
786	Motorola	XT720
787	Motorola	XT800
788	Motorola	XT800+
789	Motorola	XT800c
790	Motorola	XT800W
791	Motorola	XT806
792	Motorola	Z3
793	Motorola	Z6w
794	Motorola	ZN300
795	Motorola	ZN4
796	Motorola	ZN5

Item	Brand Name	Model
797	Motorola	A953
798	Motorola	A955
799	Motorola	A956
800	Motorola	A956
801	Motorola	A957
802	Motorola	Birdstone i475,
803	Motorola	Brea
804	Motorola	BRIDGEVIEW iDEN
805	Motorola	DominoV
806	Motorola	EX108
807	Motorola	EX109
808	Motorola	EX118
809	Motorola	EX130
810	Motorola	EX132
811	Motorola	EX139
812	Motorola	EX212
813	Motorola	EX223
814	Motorola	EX232
815	Motorola	Fawnridge i940
816	Motorola	GSM mobile phone
817	Motorola	Hallcrest (WX 430)
818	Motorola	i475 (Birdstone)
819	Motorola	Jorian-xt605
820	Motorola	MB508
821	Motorola	MB520
822	Motorola	MB525
823	Motorola	MB611
824	Motorola	MB612
825	Motorola	MB810
826	Motorola	MB810 UR
827	Motorola	MB861
828	Motorola	MB870
829	Motorola	ME860
830	Motorola	MOSAIC-i440
831	Motorola	MT620
832	Motorola	MT810LX
833	Motorola	MT870
834	Motorola	Style
835	Motorola	Titanium
836	Motorola	W409G
837	Motorola	WX292
838	Motorola	WX294
839	Motorola	WX346
840	Motorola	WX445
841	Motorola	XT300
842	Motorola	XT301
843	Motorola	XT311
844	Motorola	XT311
845	Motorola	XT317
846	Motorola	XT530
847	Motorola	XT531
848	Motorola	XT532
849	Motorola	XT610
850	Motorola	XT610
851	Motorola	XT615
852	Motorola	XT860
853	Motorola	XT862
854	Motorola	XT865
855	Motorola	XT875
856	Motorola	XT882
857	NEC CASIO	C781
858	NEC CASIO	CA-01C
859	NEC CASIO	G'zOne
860	NEC CASIO	G'zOne
861	NEC CASIO	IS11CA
862	NEC CASIO	KMP7N4AB-1A
863	NEC CASIO	N-02D
864	NEC CASIO	N-04C
865	NEC CASIO	N-05C
866	NEC CASIO	N-06C
867	NEC CASIO	KMP7N4Y1-2A
868	Nokia	200
869	Nokia	201
870	Nokia	300
871	Nokia	303
872	Nokia	2000
873	Nokia	2010
874	Nokia	2605
875	Nokia	2705
876	Nokia	2705
877	Nokia	2730
878	Nokia	2760
879	Nokia	3000
880	Nokia	3030
881	Nokia	3555
882	Nokia	3711
883	Nokia	5220
884	Nokia	5230
885	Nokia	5310
886	Nokia	5320
887	Nokia	5530

Item	Brand Name	Model
888	Nokia	5610
889	Nokia	5800
890	Nokia	6085
891	Nokia	6086
892	Nokia	6103
893	Nokia	6133
894	Nokia	6205
895	Nokia	6263
896	Nokia	6301
897	Nokia	6350
898	Nokia	6555
899	Nokia	6600
900	Nokia	6650
901	Nokia	6700
902	Nokia	6730
903	Nokia	6788
904	Nokia	7205
905	Nokia	7310
906	Nokia	7510
907	Nokia	7705
908	Nokia	7705
909	Nokia	8800
910	Nokia	2332c
911	Nokia	2600C
912	Nokia	2680s
913	Nokia	2720 Fold
914	Nokia	2730 Classic
915	Nokia	3710 fold
916	Nokia	5130 XpressMusic
917	Nokia	5230 Nuron
918	Nokia	5330TV
919	Nokia	5630Xpress
920	Nokia	6220c
921	Nokia	6303C
922	Nokia	6500 Slide
923	Nokia	6600i Slide
924	Nokia	6700 Clasic
925	Nokia	6700 slide
926	Nokia	6788i
927	Nokia	702T
928	Nokia	7100 Supernova
929	Nokia	7210 Supernova
930	Nokia	7610s
931	Nokia	C1-03
932	Nokia	C2-00
933	Nokia	C2-02
934	Nokia	C2-02.1
935	Nokia	C2-03
936	Nokia	C2-05
937	Nokia	C2-05.1
938	Nokia	C2-06
939	Nokia	C2-07
940	Nokia	C2-08
941	Nokia	C3-00.2
942	Nokia	C3-01.5
943	Nokia	C5-00
944	Nokia	C5-00.03
945	Nokia	C5-00.2
946	Nokia	C5-01
947	Nokia	C5-04.1
948	Nokia	C5-05
949	Nokia	C5-06
950	Nokia	E52
951	Nokia	E63
952	Nokia	E66
953	Nokia	E71
954	Nokia	E71x
955	Nokia	E75
956	Nokia	E90
957	Nokia	Mural (6750)
958	Nokia	N73
959	Nokia	N78
960	Nokia	N79
961	Nokia	N8
962	Nokia	N85
963	Nokia	N86
964	Nokia	N9
965	Nokia	N96
966	Nokia	N97
967	Nokia	N97 Mini
968	Nokia	Nokia 1006
969	Nokia	Nokia 2705
970	Nokia	Nokia 3208c
971	Nokia	Nokia 3720c-2
972	Nokia	Nokia 500
973	Nokia	Nokia 5132
974	Nokia	Nokia 5611
975	Nokia	Nokia 5730s-1
976	Nokia	Nokia 600
977	Nokia	Nokia 603
978	Nokia	Nokia 6303c

Item	Brand Name	Model
979	Nokia	Nokia 6316s, 6316s-1
980	Nokia	Nokia 6350-1b
981	Nokia	Nokia 6350-1d
982	Nokia	Nokia 6600f-1c
983	Nokia	Nokia 6700c
984	Nokia	Nokia 6700c-1
985	Nokia	Nokia 6750-1b
986	Nokia	Nokia 6750-1c
987	Nokia	Nokia 6760s-1
988	Nokia	Nokia 6790s-1b
989	Nokia	Nokia 6790s-1c
990	Nokia	Nokia 700
991	Nokia	Nokia 701
992	Nokia	Nokia 7205
993	Nokia	Nokia 7208
994	Nokia	Nokia 7208
995	Nokia	Nokia 7505 CDMA Mobile Phone
996	Nokia	Nokia 7705
997	Nokia	Nokia 801T
998	Nokia	Nokia 8208
999	Nokia	Nokia C7-00.1
1000	Nokia	Nokia C7-00s
1001	Nokia	Nokia E6-00
1002	Nokia	Nokia E71x
1003	Nokia	Nokia E75-1
1004	Nokia	Nokia E75-2
1005	Nokia	Nokia Lumia 1020
1006	Nokia	Nokia Lumia 1020
1007	Nokia	Nokia Lumia 521
1008	Nokia	Nokia Lumia 800
1009	Nokia	Nokia Lumia 810
1010	Nokia	Nokia Lumia 820
1011	Nokia	Nokia Lumia 822
1012	Nokia	Nokia Lumia 900
1013	Nokia	Nokia Lumia 920
1014	Nokia	Nokia Lumia 928
1015	Nokia	Surge (TM) 6790
1016	Nokia	T7-00
1017	Nokia	Vertu ASCENT X
1018	Nokia	Vertu Constellation F
1019	Nokia	Vertu CONSTELLATION T
1020	Nokia	Vertu Signature SC
1021	Nokia	X2-02
1022	Nokia	X2-03
1023	Nokia	X2-05
1024	Nokia	X3
1025	Nokia	X3-01
1026	Nokia	X3-02.5
1027	Nokia	X3-02i
1028	Nokia	X5-00
1029	Nokia	X6
1030	Nokia	X6
1031	Nokia	X7
1032	Nokia	Z730C
1033	Palm	Centro
1034	Palm	P100EWW
1035	Palm	P100UNA/ P100UEU
1036	Palm	P101EWW
1037	Palm	P101UNA, P101UEU
1038	Palm	P120EWW
1039	Palm	P121EWW
1040	Palm	P121UNA, P121UEU
1041	Palm	Pixi
1042	Palm	Pixi Plus CDMA
1043	Palm	Pre
1044	Palm	Pre Plus CDMA
1045	Palm	Treo 680
1046	Palm	Treo 800w
1047	Palm	Treo Pro
1048	Palm	Treo Pro, T850EWW
1049	Panasonic	003P
1050	Panasonic	101P
1051	Panasonic	EB-3236
1052	Panasonic	EB-4054
1053	Panasonic	EB-4057
1054	Panasonic	KX-TU311
1055	Panasonic	P-01D
1056	Panasonic	P-02D
1057	Panasonic	P-07C
1058	Pantech	ADR8995
1059	Pantech	CDM8992
1060	Pantech	CDM8992
1061	Pantech	CDM8999**
1062	Pantech	CDMA PTI06 (IS06)
1063	Pantech	CDMA EIS01PT(EIS01PT)
1064	Pantech	CDMA PTI11(PTI11)
1065	Pantech	IM-A600S
1066	Pantech	IM-A630K (SP33K)
1067	Pantech	IM-A630K (SP33K)
1068	Pantech	IM-A650S

Item	Brand Name	Model
1069	Pantech	IM-A690L
1070	Pantech	IM-A690L
1071	Pantech	IM-A690S
1072	Pantech	IM-A690S
1073	Pantech	IM-A710K
1074	Pantech	IM-A710K
1075	Pantech	IM-A720L
1076	Pantech	IM-A720L
1077	Pantech	IM-A725L
1078	Pantech	IM-A730S
1079	Pantech	IM-A730S
1080	Pantech	IM-A740S
1081	Pantech	IM-A750K
1082	Pantech	IM-A760S
1083	Pantech	IM-A770K
1084	Pantech	IM-A775C
1085	Pantech	IM-A780L
1086	Pantech	IM-A800S
1087	Pantech	IM-A810K
1088	Pantech	IM-A810S
1089	Pantech	IM-T100K
1090	Pantech	Matrix Pro (TM)
1091	Pantech	MD Cube
1092	Pantech	P2000
1093	Pantech	P2020
1094	Pantech	P2030
1095	Pantech	P5000
1096	Pantech	P6010
1097	Pantech	P6020
1098	Pantech	P7000
1099	Pantech	P7040
1100	Pantech	P8000
1101	Pantech	P8000
1102	Pantech	P9020
1103	Pantech	P9050
1104	Pantech	Pantech Breeze III™
1105	Pantech	Pantech Burst™
1106	Pantech	Pantech Discover
1107	Pantech	Pantech Discover™
1108	Pantech	Pantech Flex
1109	Pantech	Pantech P9070
1110	Pantech	Pantech Pocket™
1111	Pantech	Pantech Renee™
1112	Pantech	Pantech Swift™
1113	Pantech	PantechP7050
1114	Pantech	PantechP9060
1115	Pantech	PIVOT **
1116	Pantech	PIVOT/ TXT8030##
1117	Pantech	Show(TXT8040, VZW-1026)
1118	Pantech	TXT8035PP
1119	Pantech	TXT8040##
1120	Pantech	TXT8045US
1121	Pantech	TXT8045VW
1122	Pantech	WP8990
1123	PCD	Razzle TXT8060
1124	Pharos	PTL117
1125	Pharos	PTL127
1126	RIM	BlackBerry 8120
1127	RIM	Blackberry 8220
1128	RIM	Blackberry 8350i
1129	RIM	Blackberry 8530
1130	Rim	Blackberry 8820
1131	RIM	Blackberry 9300
1132	RIM	Blackberry 9500
1133	RIM	Blackberry 9530
1134	RIM	Blackberry 9630
1135	RIM	Blackberry 9700
1136	Rim	Blackberry Bold 9000
1137	RIM	BlackBerry Curve (8520)
1138	RIM	BlackBerry Curve 3G 9300
1139	RIM	Blackberry Curve 3G 9330
1140	Rim	Blackberry Curve 8310
1141	Rim	Blackberry Curve 8320
1142	Rim	Blackberry Curve 8900
1143	Rim	Blackberry Pearl 8100
1144	Rim	Blackberry Pearl 8110
1145	RIM	Blackberry Storm 2
1146	RIM	BlackBerry Storm 9550 (Storm 2)
1147	RIM	BlackBerry Style (9670)
1148	RIM	BlackBerry Torch (9800)
1149	RIM	BlackBerry Z10
1150	RIM	BlackBerry® Bold™ 9790
1151	RIM	BlackBerry® Bold™ 9900
1152	RIM	BlackBerry® Bold™ 9900 Smartphone
1153	RIM	BlackBerry® Bold™ 9930 Smartphone
1154	RIM	BlackBerry® Curve™ 8980
1155	RIM	BlackBerry® Curve™ 9350 Smartphone
1156	RIM	BlackBerry® Curve™ 9360
1157	RIM	BlackBerry® Curve™ 9360 Smartphone
1158	RIM	BlackBerry® Curve™ 9370

Item	Brand Name	Model
1159	RIM	BlackBerry® Curve™ 9380
1160	RIM	BlackBerry® Torch™ 9810
1161	RIM	BlackBerry® Torch™ 9810 Smartphone
1162	RIM	BlackBerry® Torch™ 9850 Smartphone
1163	RIM	BlackBerry® Torch™ 9860 Smartphone
1164	RIM	BlackBerryR 8530 Smartphone
1165	RIM	BlackBerryR 8910 Curve? Smartphone
1166	RIM	BlackBerryR Bold? 9000
1167	RIM	BlackBerryR Bold? 9650 Smartphone
1168	RIM	BlackBerryR Bold? 9650 Smartphone
1169	RIM	BlackBerryR Bold? 9700
1170	RIM	BlackBerryR Bold? 9780 smartphone
1171	RIM	BlackBerryR Curve? 8330
1172	RIM	BlackBerryR Curve? 8350i
1173	RIM	BlackBerryR Curve? 8520 Smartphone
1174	RIM	BlackBerryR Curve? 8900
1175	RIM	BlackBerryR Curve? 9300
1176	RIM	BlackBerryR Curve? 9330 Smartphone
1177	RIM	BlackBerryR Pearl? 8230
1178	RIM	BlackBerryR Pearl? 9100 Smartphone
1179	RIM	BlackBerryR Pearl? 9105 Smartphone
1180	RIM	BlackBerryR Storm? 9500
1181	RIM	BlackBerryR Storm? 9530
1182	RIM	BlackBerryR Storm2? 9520
1183	RIM	BlackBerryR Storm2? 9550
1184	RIM	BlackBerryR Style? 9670 Smartphone
1185	RIM	BlackBerryR Torch? 9800
1186	RIM	BlackBerryR Tour? 9630 Smartphone
1187	RIM	RDL61TC
1188	Samsung	A237
1189	Samsung	a727
1190	Samsung	A737
1191	Samsung	a747
1192	Samsung	A767 Propel
1193	Samsung	A777
1194	Samsung	A827
1195	Samsung	Alias 2 U750
1196	Samsung	B2100
1197	Samsung	B7300
1198	Samsung	Behold 2 (T939)
1199	Samsung	Behold T919
1200	Samsung	BlackJack (TM) II (i617)
1201	Samsung	C3050
1202	Samsung	C3050
1203	Samsung	C3050
1204	Samsung	C3110
1205	Samsung	C3110H
1206	Samsung	C5130
1207	Samsung	C5212
1208	Samsung	C5510
1209	Samsung	C6625
1210	Samsung	Captivate (I897)
1211	Samsung	CDMA SCI11
1212	Samsung	Continuum (I400)
1213	Samsung	D780
1214	Samsung	D880
1215	Samsung	D900i
1216	Samsung	D988
1217	Samsung	E3010
1218	Samsung	E390
1219	Samsung	Epic 4G (D700)
1220	Samsung	Eternity A867
1221	Samsung	F110
1222	Samsung	F330
1223	Samsung	F480
1224	Samsung	F490
1225	Samsung	Fascinate (I500)
1226	Samsung	Flight
1227	Samsung	Galaxy Spica GT-i5700
1228	Samsung	Gravity 2 (T469)
1229	Samsung	Gravity T459
1230	Samsung	GT- S8500
1231	Samsung	GT-B2710
1232	Samsung	GT-B2710D
1233	Samsung	GT-B3210
1234	Samsung	GT-B3310
1235	Samsung	GT-B3310i
1236	Samsung	GT-B3313i
1237	Samsung	GT-B3410
1238	Samsung	GT-B3410R
1239	Samsung	GT-B3410W
1240	Samsung	GT-B5210U
1241	Samsung	GT-B5310
1242	Samsung	GT-B5310B
1243	Samsung	GT-B5310L
1244	Samsung	GT-B5310R
1245	Samsung	GT-B5310U
1246	Samsung	GT-B5510
1247	Samsung	GT-B5510B
1248	Samsung	GT-B5510L
1249	Samsung	GT-B5512

Item	Brand Name	Model
1250	Samsung	GT-B5512B
1251	Samsung	GT-B6520
1252	Samsung	GT-B6520L
1253	Samsung	GT-B7300
1254	Samsung	GT-B7300B
1255	Samsung	GT-B7300C
1256	Samsung	GT-B7320
1257	Samsung	GT-B7320L
1258	Samsung	GT-B7330
1259	Samsung	GT-B7330B
1260	Samsung	GT-B7330D
1261	Samsung	GT-B7330R
1262	Samsung	GT-B7350
1263	Samsung	GT-B7350T
1264	Samsung	GT-B7510
1265	Samsung	GT-B7510B
1266	Samsung	GT-B7510L
1267	Samsung	GT-B7610
1268	Samsung	GT-B7620
1269	Samsung	GT-B7620U
1270	Samsung	GT-C3010
1271	Samsung	GT-C3011
1272	Samsung	GT-C3013
1273	Samsung	GT-C3050
1274	Samsung	GT-C3050C
1275	Samsung	GT-C3053
1276	Samsung	GT-C3060
1277	Samsung	GT-C3200
1278	Samsung	GT-C3222W
1279	Samsung	GT-C3300
1280	Samsung	GT-C3300D
1281	Samsung	GT-C3300i
1282	Samsung	GT-C3300K
1283	Samsung	GT-C3303K
1284	Samsung	GT-C3310
1285	Samsung	GT-C3312
1286	Samsung	GT-C3322
1287	Samsung	GT-C3330
1288	Samsung	GT-C3332
1289	Samsung	GT-C3350
1290	Samsung	GT-C3500
1291	Samsung	GT-C3503
1292	Samsung	GT-C3510
1293	Samsung	GT-C3510T
1294	Samsung	GT-C3518
1295	Samsung	GT-C3520
1296	Samsung	GT-C3530
1297	Samsung	GT-C3560
1298	Samsung	GT-C3750
1299	Samsung	GT-C3752
1300	Samsung	GT-C5180
1301	Samsung	GT-C5510
1302	Samsung	GT-C5510H
1303	Samsung	GT-C5510U
1304	Samsung	GT-C6712
1305	Samsung	GT-E1232B
1306	Samsung	GT-E2152i
1307	Samsung	GT-E2220
1308	Samsung	GT-E2222
1309	Samsung	GT-E2222L
1310	Samsung	GT-E2230
1311	Samsung	GT-E2230L
1312	Samsung	GT-E2232
1313	Samsung	GT-E2330B
1314	Samsung	GT-E2530
1315	Samsung	GT-E2600
1316	Samsung	GT-E2652
1317	Samsung	GT-E2652W
1318	Samsung	GT-E3210
1319	Samsung	GT-E3210B
1320	Samsung	GT-E3210L
1321	Samsung	GT-E3210O
1322	Samsung	GT-E3213K
1323	Samsung	GT-E3217B
1324	Samsung	GT-I5500
1325	Samsung	GT-I5500M
1326	Samsung	GT-I5503T
1327	Samsung	GT-I5508
1328	Samsung	GT-I5510
1329	Samsung	GT-I5510 (GB)
1330	Samsung	GT-I5510B
1331	Samsung	GT-I5510L
1332	Samsung	GT-I5510M
1333	Samsung	GT-I5510T
1334	Samsung	GT-I5700
1335	Samsung	GT-I5700
1336	Samsung	GT-I5700L
1337	Samsung	GT-I5700U
1338	Samsung	GT-I5800
1339	Samsung	GT-I5801
1340	Samsung	GT-I6220

Item	Brand Name	Model
1341	Samsung	GT-I6230
1342	Samsung	GT-I6410
1343	Samsung	GT-I6500U
1344	Samsung	GT-I6500U
1345	Samsung	GT-I6712
1346	Samsung	GT-I7410
1347	Samsung	GT-I7500U
1348	Samsung	GT-I7680
1349	Samsung	GT-I8000H
1350	Samsung	GT-I8000L
1351	Samsung	GT-I8000T
1352	Samsung	GT-I8150
1353	Samsung	GT-I8150B
1354	Samsung	GT-I8150T
1355	Samsung	GT-I8180C
1356	Samsung	GT-I8320
1357	Samsung	GT-I8330
1358	Samsung	GT-I8350
1359	Samsung	GT-I8350T
1360	Samsung	GT-I8520
1361	Samsung	GT-I8910L
1362	Samsung	GT-I8910U
1363	Samsung	GT-I9000
1364	Samsung	GT-I9000
1365	Samsung	GT-I9000B
1366	Samsung	GT-I9000L
1367	Samsung	GT-I9000M
1368	Samsung	GT-I9000M
1369	Samsung	GT-I9000T
1370	Samsung	GT-I9001
1371	Samsung	GT-I9003
1372	Samsung	GT-I9003
1373	Samsung	GT-I9003
1374	Samsung	GT-I9003L
1375	Samsung	GT-I9003L
1376	Samsung	GT-I9008
1377	Samsung	GT-I9008L
1378	Samsung	GT-I9008L
1379	Samsung	GT-I9010
1380	Samsung	GT-I9018
1381	Samsung	GT-I9020
1382	Samsung	GT-I9020
1383	Samsung	GT-I9020A
1384	Samsung	GT-I9020A
1385	Samsung	GT-I9020T
1386	Samsung	GT-I9020T
1387	Samsung	GT-I9023
1388	Samsung	GT-I9023
1389	Samsung	GT-I9070
1390	Samsung	GT-I9088
1391	Samsung	GT-I9100
1392	Samsung	GT-I9100
1393	Samsung	GT-I9100G
1394	Samsung	GT-I9100M
1395	Samsung	GT-I9100M
1396	Samsung	GT-I9100P
1397	Samsung	GT-I9100T
1398	Samsung	GT-I9100T
1399	Samsung	GT-I9103
1400	Samsung	GT-I9108
1401	Samsung	GT-I9188
1402	Samsung	GT-I9210
1403	Samsung	GT-I9220
1404	Samsung	GT-I9228
1405	Samsung	GT-I9250
1406	Samsung	GT-I9250M
1407	Samsung	GT-I9250T
1408	Samsung	GT-I9250W
1409	Samsung	GT-M2510C
1410	Samsung	GT-M2513
1411	Samsung	GT-M2520
1412	Samsung	GT-M3710
1413	Samsung	GT-M7500C
1414	Samsung	GT-M7600B
1415	Samsung	GT-M7600H
1416	Samsung	GT-M7600L
1417	Samsung	GT-M7603
1418	Samsung	GT-M8910
1419	Samsung	GT-M8910B
1420	Samsung	GT-M8910U
1421	Samsung	GT-N7000
1422	Samsung	GT-N7000
1423	Samsung	GT-P1000
1424	Samsung	GT-P1000L
1425	Samsung	GT-P1000N
1426	Samsung	GT-P1000T
1427	Samsung	GT-P6200L
1428	Samsung	GT-P6201
1429	Samsung	GT-S3100
1430	Samsung	GT-S3310i
1431	Samsung	GT-S3350

Item	Brand Name	Model
1432	Samsung	GT-S3353
1433	Samsung	GT-S3370
1434	Samsung	GT-S3370B
1435	Samsung	GT-S3370C
1436	Samsung	GT-S3370E
1437	Samsung	GT-S3370L
1438	Samsung	GT-S3500i
1439	Samsung	GT-S3501C
1440	Samsung	GT-S3550
1441	Samsung	GT-S3600i
1442	Samsung	GT-S3601C
1443	Samsung	GT-S3650
1444	Samsung	GT-S3650C
1445	Samsung	GT-S3650W
1446	Samsung	GT-S3653
1447	Samsung	GT-S3653W
1448	Samsung	GT-S3770
1449	Samsung	GT-S3770B
1450	Samsung	GT-S3770K
1451	Samsung	GT-S3770L
1452	Samsung	GT-S3770M
1453	Samsung	GT-S3770Y
1454	Samsung	GT-S3778
1455	Samsung	GT-S3778V
1456	Samsung	GT-S3850
1457	Samsung	GT-S3970
1458	Samsung	GT-S5150
1459	Samsung	GT-S5220
1460	Samsung	GT-S5222
1461	Samsung	GT-S5230
1462	Samsung	GT-S5230C
1463	Samsung	GT-S5230G
1464	Samsung	GT-S5230N
1465	Samsung	GT-S5233A
1466	Samsung	GT-S5233S
1467	Samsung	GT-S5233T
1468	Samsung	GT-S5233W
1469	Samsung	GT-S5250
1470	Samsung	GT-S5260
1471	Samsung	GT-S5260P
1472	Samsung	GT-S5270K
1473	Samsung	GT-S5270L
1474	Samsung	GT-S5270Y
1475	Samsung	GT-S5273L
1476	Samsung	GT-S5330
1477	Samsung	GT-S5333
1478	Samsung	GT-S5350
1479	Samsung	GT-S5350L
1480	Samsung	GT-S5360
1481	Samsung	GT-S5360B
1482	Samsung	GT-S5360L
1483	Samsung	GT-S5360T
1484	Samsung	GT-S5363
1485	Samsung	GT-S5368
1486	Samsung	GT-S5369
1487	Samsung	GT-S5380
1488	Samsung	GT-S5380B
1489	Samsung	GT-S5380D
1490	Samsung	GT-S5380K
1491	Samsung	GT-S5380L
1492	Samsung	GT-S5510
1493	Samsung	GT-S5510T
1494	Samsung	GT-S5511T
1495	Samsung	GT-S5520
1496	Samsung	GT-S5530
1497	Samsung	GT-S5560
1498	Samsung	GT-S5560C
1499	Samsung	GT-S5560i
1500	Samsung	GT-S5570
1501	Samsung	GT-S5570B
1502	Samsung	GT-S5570I
1503	Samsung	GT-S5570L
1504	Samsung	GT-S5571
1505	Samsung	GT-S5578
1506	Samsung	GT-S5580
1507	Samsung	GT-S5600
1508	Samsung	GT-S5600B
1509	Samsung	GT-S5600H
1510	Samsung	GT-S5600L
1511	Samsung	GT-S5600T
1512	Samsung	GT-S5600V
1513	Samsung	GT-S5603
1514	Samsung	GT-S5603T
1515	Samsung	GT-S5608U
1516	Samsung	GT-S5610
1517	Samsung	GT-S5620
1518	Samsung	GT-S5620B
1519	Samsung	GT-S5620L
1520	Samsung	GT-S5628
1521	Samsung	GT-S5628i
1522	Samsung	GT-S5660

Item	Brand Name	Model
1523	Samsung	GT-S5660B
1524	Samsung	GT-S5660L
1525	Samsung	GT-S5660M
1526	Samsung	GT-S5660V
1527	Samsung	GT-S5670
1528	Samsung	GT-S5670B
1529	Samsung	GT-S5670L
1530	Samsung	GT-S5690
1531	Samsung	GT-S5690L
1532	Samsung	GT-S5690L
1533	Samsung	GT-S5750E
1534	Samsung	GT-S5780
1535	Samsung	GT-S5820
1536	Samsung	GT-S5830
1537	Samsung	GT-S5830B
1538	Samsung	GT-S5830C
1539	Samsung	GT-S5830i
1540	Samsung	GT-S5830L
1541	Samsung	GT-S5830M
1542	Samsung	GT-S5830T
1543	Samsung	GT-S5838
1544	Samsung	GT-S6102
1545	Samsung	GT-S6102B
1546	Samsung	GT-S6700T
1547	Samsung	GT-S6703T
1548	Samsung	GT-S6888
1549	Samsung	GT-S7070
1550	Samsung	GT-S7070C
1551	Samsung	GT-S7220U
1552	Samsung	GT-S7230
1553	Samsung	GT-S7230B
1554	Samsung	GT-S7230E
1555	Samsung	GT-S7230L
1556	Samsung	GT-S7233E
1557	Samsung	GT-S7250
1558	Samsung	GT-S7250D
1559	Samsung	GT-S7350i
1560	Samsung	GT-S7350U
1561	Samsung	GT-S7500
1562	Samsung	GT-S7510
1563	Samsung	GT-S8000B
1564	Samsung	GT-S8000C
1565	Samsung	GT-S8000C
1566	Samsung	GT-S8000H
1567	Samsung	GT-S8000L
1568	Samsung	GT-S8000U
1569	Samsung	GT-S8500
1570	Samsung	GT-S8500
1571	Samsung	GT-S8500B
1572	Samsung	GT-S8500C
1573	Samsung	GT-S8500L
1574	Samsung	GT-S8500M
1575	Samsung	GT-S8500R
1576	Samsung	GT-S8530
1577	Samsung	GT-S8530B
1578	Samsung	GT-S8530L
1579	Samsung	GT-S8600
1580	Samsung	Highlight
1581	Samsung	i200
1582	Samsung	I450
1583	Samsung	i520
1584	Samsung	i640v
1585	Samsung	i7500 Galaxy
1586	Samsung	i780
1587	Samsung	i8000 Omnia
1588	Samsung	i8510
1589	Samsung	i8910 HD
1590	Samsung	i907 Epix
1591	Samsung	i910
1592	Samsung	Impression (A877)
1593	Samsung	Instinct HD (M850)
1594	Samsung	Instinct S30
1595	Samsung	Intensity
1596	Samsung	Intrepid (I350)
1597	Samsung	J200
1598	Samsung	J700
1599	Samsung	J758
1600	Samsung	J808
1601	Samsung	Jack i637
1602	Samsung	L708
1603	Samsung	L760
1604	Samsung	L770
1605	Samsung	M220
1606	Samsung	M310
1607	Samsung	M320
1608	Samsung	M330
1609	Samsung	M5650
1610	Samsung	M630
1611	Samsung	M7600
1612	Samsung	M8910
1613	Samsung	Magnet A257

Item	Brand Name	Model
1614	Samsung	Marcel Reloaded
1615	Samsung	Moment
1616	Samsung	Mythic A897
1617	Samsung	Pixon M8800
1618	Samsung	Propel (TM) Pro i627
1619	Samsung	Rant M540
1620	Samsung	Reclaim (M560)
1621	Samsung	Renown
1622	Samsung	Rogue
1623	Samsung	Rugby (A837)
1624	Samsung	S3030 Tobi
1625	Samsung	S3110C
1626	Samsung	S3500C
1627	Samsung	S3600H
1628	Samsung	S3650 Corby
1629	Samsung	S5230
1630	Samsung	S5500
1631	Samsung	S5550 Shark
1632	Samsung	S5560
1633	Samsung	S5600
1634	Samsung	S5628 Monte
1635	Samsung	S7070 Diva
1636	Samsung	S7350
1637	Samsung	S7350B
1638	Samsung	S7350C
1639	Samsung	S7350L
1640	Samsung	S8000
	Samsung	S8000
1641	Samsung	S8300
1642	Samsung	S8300C
1643	Samsung	S8300T
1644	Samsung	S8300V
	Samsung	Samsung Captivate™ Glide
1645	Samsung	Samsung Exhilarate
1646	Samsung	Samsung Focus® 2
1647	Samsung	Samsung Focus™ S
1648	Samsung	Samsung Galaxy Exhilarate™
1649	Samsung	Samsung Galaxy Express
1650	Samsung	Samsung Galaxy Express™
1651	Samsung	Samsung Galaxy Nexus
1652	Samsung	Samsung Galaxy Note
1653	Samsung	Samsung Galaxy Note 2
1654	Samsung	Samsung Galaxy Note 3
1655	Samsung	Samsung Galaxy Rugby Pro
1656	Samsung	Samsung Galaxy Rugby Pro™
1657	Samsung	Samsung Galaxy S2 Skyrocket
1658	Samsung	Samsung Galaxy S3
1659	Samsung	Samsung Galaxy S4
1660	Samsung	Samsung Galaxy S5
1661	Samsung	Samsung Galaxy Stratosphere 2
1662	Samsung	Samsung GT-I5500B
1663	Samsung	Samsung GT-I5500L
1664	Samsung	Samsung GT-I5800L
1665	Samsung	Samsung Mobile Phone (GT-M2510)
1666	Samsung	Samsung Mobile Phone (SCH-R311)
1667	Samsung	Samsung Mobile Phone (SCH-U350)
1668	Samsung	Samsung Mobile Phone (SCH-U450)
1669	Samsung	Samsung Mobile Phone (SCH-U960)
1670	Samsung	Samsung Mobile Phone (SPH-M550)
1671	Samsung	Samsung Mobile Phone (SPH-M560)
1672	Samsung	Samsung Mobile Phone (SPH-M850)
1673	Samsung	Samsung Mobile Phone(GT-I8000)
1674	Samsung	Samsung Mobile Phone(I8910)
1675	Samsung	Samsung Mobile Phone(M7600)
1676	Samsung	Samsung Mobile Phone(SCH-R560)
1677	Samsung	Samsung Mobile Phone(SCH-U430)
1678	Samsung	Samsung Mobile Phone(SCH-U640)
1679	Samsung	Samsung Rugby 3
1680	Samsung	Samsung Rugby® Smart (Refurbished)
1681	Samsung	Samsung Stratosphere
1682	Samsung	SC-01B
1683	Samsung	SC-01C
1684	Samsung	SC-02B
1685	Samsung	SC-02C
1686	Samsung	SC-02C
1687	Samsung	SC-03D
1688	Samsung	SC-04D
1689	Samsung	SCH-F809
1690	Samsung	SCH-F859
1691	Samsung	SCH-I100
1692	Samsung	SCH-I110
1693	Samsung	SCH-i220
1694	Samsung	SCH-i220(MPCS)
1695	Samsung	SCH-i225
1696	Samsung	SCH-i329
1697	Samsung	SCH-I400
1698	Samsung	SCH-I405
1699	Samsung	SCH-I500

Item	Brand Name	Model
1700	Samsung	SCH-i509
1701	Samsung	SCH-I510
1702	Samsung	SCH-I515
1703	Samsung	SCH-I520
1704	Samsung	SCH-I559
1705	Samsung	SCH-I569
1706	Samsung	SCH-I579
1707	Samsung	SCH-I579i
1708	Samsung	SCH-I589
1709	Samsung	SCH-I800
1710	Samsung	SCH-I809
1711	Samsung	SCH-i889
1712	Samsung	SCH-i899
1713	Samsung	SCH-I909
1714	Samsung	SCH-I909L
1715	Samsung	SCH-i919
1716	Samsung	SCH-i920
1717	Samsung	SCH-I929
1718	Samsung	SCH-M710
1719	Samsung	SCH-M715
1720	Samsung	SCH-M720
1721	Samsung	SCH-M828C
1722	Samsung	SCH-P739
1723	Samsung	SCH-P739
1724	Samsung	SCH-R100
1725	Samsung	SCH-R220
1726	Samsung	SCH-R250
1727	Samsung	SCH-R260
1728	Samsung	SCH-R260
1729	Samsung	SCH-R260
1730	Samsung	SCH-R260
1731	Samsung	SCH-R261
1732	Samsung	SCH-R312
1733	Samsung	SCH-R330
1734	Samsung	SCH-R330
1735	Samsung	SCH-R335
1736	Samsung	SCH-R350
1737	Samsung	SCH-R351
1738	Samsung	SCH-R360
1739	Samsung	SCH-R380
1740	Samsung	SCH-R455
1741	Samsung	SCH-R520
1742	Samsung	SCH-R570
1743	Samsung	SCH-R580
1744	Samsung	SCH-R630
1745	Samsung	SCH-R631
1746	Samsung	SCH-R631 2Thumb
1747	Samsung	SCH-R640
1748	Samsung	SCH-R641
1749	Samsung	SCH-R680
1750	Samsung	SCH-R700
1751	Samsung	SCH-R710
1752	Samsung	SCH-R720
1753	Samsung	SCH-R730
1754	Samsung	SCH-R760
1755	Samsung	SCH-R850
1756	Samsung	SCH-R860
1757	Samsung	SCH-R880
1758	Samsung	SCH-R880
1759	Samsung	SCH-R900
1760	Samsung	SCH-R910
1761	Samsung	SCH-R915
1762	Samsung	SCH-R920
1763	Samsung	SCH-R930
1764	Samsung	SCH-R940
1765	Samsung	SCH-U350
1766	Samsung	SCH-U360
1767	Samsung	SCH-U365
1768	Samsung	SCH-U370
1769	Samsung	SCH-U380
1770	Samsung	SCH-U450
1771	Samsung	SCH-U450
1772	Samsung	SCH-U450(Verizon)
1773	Samsung	SCH-U460
1774	Samsung	SCH-U480
1775	Samsung	SCH-U660
1776	Samsung	SCH-U820
1777	Samsung	SCH-W279
1778	Samsung	SCH-W309
1779	Samsung	SCH-W689
1780	Samsung	SCH-W899
1781	Samsung	SCH-W999
1782	Samsung	SGH-A967
1783	Samsung	SGH-C414
1784	Samsung	SGH-C414M
1785	Samsung	SGH-C414R
1786	Samsung	SGH-C414V
1787	Samsung	SGH-C414W
1788	Samsung	SGH-C414Y
1789	Samsung	SGH-I577
1790	Samsung	SGH-i677

Item	Brand Name	Model
1791	Samsung	SGH-I717
1792	Samsung	SGH-I717D
1793	Samsung	SGH-I717M
1794	Samsung	SGH-I717R
1795	Samsung	SGH-I727
1796	Samsung	SGH-I727R
1797	Samsung	SGH-I757
1798	Samsung	SGH-I777
1799	Samsung	SGH-I777
1800	Samsung	SGH-I807
1801	Samsung	SGH-I807
1802	Samsung	SGH-I827
1803	Samsung	SGH-i847
1804	Samsung	SGH-I857
1805	Samsung	SGH-I896
1806	Samsung	SGH-I897
1807	Samsung	SGH-I897
1808	Samsung	SGH-i917
1809	Samsung	SGH-I917R
1810	Samsung	SGH-I927
1811	Samsung	SGH-I927R
1812	Samsung	SGH-i937
1813	Samsung	SGH-I937
1814	Samsung	SGH-I997
1815	Samsung	SGH-I997
1816	Samsung	SGH-I997R
1817	Samsung	SGH-J600E
1818	Samsung	SGH-S425G
1819	Samsung	SGH-T245G
1820	Samsung	SGH-T249R
1821	Samsung	SGH-T259
1822	Samsung	SGH-T269
1823	Samsung	SGH-T330G
1824	Samsung	SGH-T369R
1825	Samsung	SGH-T379
1826	Samsung	SGH-T499
1827	Samsung	SGH-T499W
1828	Samsung	SGH-T499Y
1829	Samsung	SGH-T589
1830	Samsung	SGH-T589R
1831	Samsung	SGH-T669V
1832	Samsung	SGH-T669V
1833	Samsung	SGH-T669Y
1834	Samsung	SGH-T669Y
1835	Samsung	SGH-T679
1836	Samsung	SGH-T679M
1837	Samsung	SGH-T759
1838	Samsung	SGH-T769
1839	Samsung	SGH-T839
1840	Samsung	SGH-T869
1841	Samsung	SGH-T939
1842	Samsung	SGH-T959
1843	Samsung	SGH-T959
1844	Samsung	SGH-T959D
1845	Samsung	SGH-T959D
1846	Samsung	SGH-T959D
1847	Samsung	SGH-T959P
1848	Samsung	SGH-T959V
1849	Samsung	SGH-T959W
1850	Samsung	SGH-T989
1851	Samsung	SGH-T989D
1852	Samsung	SHC-Z120L
1853	Samsung	SHV-E110S
1854	Samsung	SHV-E110S
1855	Samsung	SHV-E120K
1856	Samsung	SHV-E120L
1857	Samsung	SHV-E120S
1858	Samsung	SHV-E150S
1859	Samsung	SHV-E160K
1860	Samsung	SHV-E160L
1861	Samsung	SHV-E160S
1862	Samsung	SHW-A280K
1863	Samsung	SHW-A280L
1864	Samsung	SHW-A280S
1865	Samsung	SHW-A300K
1866	Samsung	SHW-A300S
1867	Samsung	SHW-A310S
1868	Samsung	SHW-M100S
1869	Samsung	SHW-M110S
1870	Samsung	SHW-M110S
1871	Samsung	SHW-M110S
1872	Samsung	SHW-M110S
1873	Samsung	SHW-M115S
1874	Samsung	SHW-M120S
1875	Samsung	SHW-M130K
1876	Samsung	SHW-M130K
1877	Samsung	SHW-M130L
1878	Samsung	SHW-M130L
1879	Samsung	SHW-M135K
1880	Samsung	SHW-M135L

Item	Brand Name	Model
1881	Samsung	SHW-M180K
1882	Samsung	SHW-M180L
1883	Samsung	SHW-M180S
1884	Samsung	SHW-M180W
1885	Samsung	SHW-M185S
1886	Samsung	SHW-M190S
1887	Samsung	SHW-M200K
1888	Samsung	SHW-M200S
1889	Samsung	SHW-M210S
1890	Samsung	SHW-M220L
1891	Samsung	SHW-M240K
1892	Samsung	SHW-M240S
1893	Samsung	SHW-M250K
1894	Samsung	SHW-M250K
1895	Samsung	SHW-M250L
1896	Samsung	SHW-M250L
1897	Samsung	SHW-M250S
1898	Samsung	SHW-M250S
1899	Samsung	SHW-M290K
1900	Samsung	SHW-M290S
1901	Samsung	SHW-M340K
1902	Samsung	SHW-M340L
1903	Samsung	SHW-M340S
1904	Samsung	SHW-M410K
1905	Samsung	SHW-M410S
1906	Samsung	SHW-M420K
1907	Samsung	SHW-M420S
1908	Samsung	Smooth
1909	Samsung	Solstice (TM) (A887)
1910	Samsung	SPH-D600
1911	Samsung	SPH-D600
1912	Samsung	SPH-D700
1913	Samsung	SPH-D705
1914	Samsung	SPH-D710
1915	Samsung	SPH-D710
1916	Samsung	SPH-D720
1917	Samsung	SPH-i350
1918	Samsung	SPH-L700
1919	Samsung	SPH-M260
1920	Samsung	SPH-M330
1921	Samsung	SPH-M340
1922	Samsung	SPH-M350
1923	Samsung	SPH-M360
1924	Samsung	SPH-M370
1925	Samsung	SPH-M380
1926	Samsung	SPH-M380
1927	Samsung	SPH-M560
1928	Samsung	SPH-M570
1929	Samsung	SPH-M575
1930	Samsung	SPH-M580
1931	Samsung	SPH-M580
1932	Samsung	SPH-M580 BST
1933	Samsung	SPH-M7200
1934	Samsung	SPH-M7350
1935	Samsung	SPH-M820
1936	Samsung	SPH-M8400
1937	Samsung	SPH-M900
1938	Samsung	SPH-M900
1939	Samsung	SPH-M910
1940	Samsung	SPH-M930
1941	Samsung	SPH-M930
1942	Samsung	SPH-P100
1943	Samsung	Steel U900
1944	Samsung	SWD-S500
1945	Samsung	t229
1946	Samsung	t239
1947	Samsung	t349
1948	Samsung	T559 Comeback
1949	Samsung	T659
1950	Samsung	t819
1951	Samsung	T929 Memoir
1952	Samsung	Trance
1953	Samsung	u440
1954	Samsung	U808
1955	Samsung	X01SC
1956	Samsung	A637
1957	Samsung	A657
1958	Samsung	Galaxy S i9000
1959	Samsung	M520
1960	Samsung	T339
1961	Samsung	u430
1962	Samsung	Wave S8500
1963	Sanyo	Incognito (SCP-6760)
1964	Sanyo	Katana Eclipse
1965	Sanyo	Katana LX
1966	Sanyo	PRO-700
1967	Sanyo	SCP-2700
1968	Sanyo	SCP-3810
1969	Seals Technologies Limited	VR7
1970	Sharp	102SH
1971	Sharp	ADS1

Item	Brand Name	Model
1972	Sharp	P1FD50C
1973	Sharp	P1FD52C
1974	Sharp	SH-01D
1975	Sharp	Sharp® FX™ PLUS
1976	Shenzhen Sang Fei Consumer Com	Philips E122
1977	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W527
1978	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W625
1979	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W626
1980	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W715
1981	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W725
1982	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W727
1983	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W820
1984	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X525
1985	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X526
1986	Shenzhen Sang Fei Consumer Com	Philips X528
1987	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X623
1988	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips Xenium X325
1989	Shenzhen Sang Fei Consumer Com	Philips W920
1990	Shenzhen Tinno Mobile Technology Corp.	T521
1991	SK telesys	SK-S150
1992	Sonim	Sonim XP1300-A-R1 (Type: P25B005AA)
1993	Sonim	Sonim XP1300-E-R1 (Type: P24B005AA)
1994	Sonim	Sonim XP1301-A-R1 (Type: P25B005AN)
1995	Sonim	Sonim XP1301-E-R1 (Type: P24B005AN)
1996	Sonim	Sonim XP3300-A-R1 (Type: P25C005AA)
1997	Sonim	Sonim XP3300-A-X1 (Type: P25C005AJ)
1998	Sonim	Sonim XP3300-A-Y1 (Type: P25C005AJ)
1999	Sonim	Sonim XP3300-E-R1 (Type: P24C005AA)
2000	Sonim	Sonim XP3300-E-X1 (Type: P24C005AJ)
2001	Sonim	Sonim XP3300-E-Y1 (Type: P24C005AJ)
2002	Sonim	Sonim XP3340-E-R1 (Type: P24C005AA)
2003	Sonim	Sonim XP3400-A-R1 (Type: C21F007AA)
2004	Sonim	Sonim XP5300-A-R1 (Type: P35F006AA)
2005	Sonim	Sonim XP5300-E-R1 (Type: P34F006AA)
2006	Sony	Equinox
2007	Sony	Sony Xperia Advance
2008	Sony	Sony Xperia TL
2009	Sony	Sony Xperia™ TL
2010	Sony	Xperia™ ion by Sony
2011	Sony Ericsson	Aino
2012	Sony Ericsson	Aino/ U10
2013	Sony Ericsson	ASPEN
2014	Sony Ericsson	C510 Black
2015	Sony Ericsson	C510, C510a
2016	Sony Ericsson	C901
2017	Sony Ericsson	C901, C901a
2018	Sony Ericsson	C902
2019	Sony Ericsson	C903, C903a
2020	Sony Ericsson	C905 Black
2021	Sony Ericsson	CDMA S0111
2022	Sony Ericsson	Cedar?
2023	Sony Ericsson	Elm
2024	Sony Ericsson	F100i
2025	Sony Ericsson	F305
2026	Sony Ericsson	G502
2027	Sony Ericsson	G700
2028	Sony Ericsson	G705
2029	Sony Ericsson	G900
2030	Sony Ericsson	Hazel
2031	Sony Ericsson	J105 (Naite?)
2032	Sony Ericsson	J105i
2033	Sony Ericsson	Live with Walkman
2034	Sony Ericsson	Mix Walkman
2035	Sony Ericsson	S302
2036	Sony Ericsson	S51SE
2037	Sony Ericsson	Satio/ U1
2038	Sony Ericsson	SO-01C
2039	Sony Ericsson	SO-01D
2040	Sony Ericsson	SO-03C
2041	Sony Ericsson	Sony Ericsson A8i
2042	Sony Ericsson	Sony Ericsson R800
2043	Sony Ericsson	Sony Ericsson txt
2044	Sony Ericsson	T650i
2045	Sony Ericsson	T700
2046	Sony Ericsson	T707, T707a
2047	Sony Ericsson	T715
2048	Sony Ericsson	T715
2049	Sony Ericsson	TM506
2050	Sony Ericsson	TM717

Item	Brand Name	Model
2051	Sony Ericsson	txt pro™
2052	Sony Ericsson	U10
2053	Sony Ericsson	Vivaz?
2054	Sony Ericsson	Vivaz? pro
2055	Sony Ericsson	W300i
2056	Sony Ericsson	W302
2057	Sony Ericsson	W350 (Refurbished)
2058	Sony Ericsson	W350a
2059	Sony Ericsson	W508, W508a
2060	Sony Ericsson	W518a
2061	Sony Ericsson	W518a
2062	Sony Ericsson	W580i
2063	Sony Ericsson	W595
2064	Sony Ericsson	W660i
2065	Sony Ericsson	W705
2066	Sony Ericsson	W705, W705u, W705a
2067	Sony Ericsson	W715
2068	Sony Ericsson	W760a
2069	Sony Ericsson	W810i
2070	Sony Ericsson	W850i
2071	Sony Ericsson	W960i
2072	Sony Ericsson	W980
2073	Sony Ericsson	W995, W995a
2074	Sony Ericsson	WT18
2075	Sony Ericsson	Xperia acro
2076	Sony Ericsson	Xperia arc
2077	Sony Ericsson	Xperia mini
2078	Sony Ericsson	Xperia mini pro
2079	Sony Ericsson	Xperia neo V
2080	Sony Ericsson	Xperia PLAY
2081	Sony Ericsson	Xperia pro
2082	Sony Ericsson	Xperia Pureness/ X5
2083	Sony Ericsson	Xperia X1
2084	Sony Ericsson	Xperia X10
2085	Sony Ericsson	Xperia X10
2086	Sony Ericsson	Xperia? X10 mini (Rev 2)
2087	Sony Ericsson	Xperia? X10 mini pro (Rev2)
2088	Sony Ericsson	Xperia? X8
2089	Sony Ericsson	Xperia™ acro
2090	Sony Ericsson	Xperia™ active
2091	Sony Ericsson	Xperia™ arc S
2092	Sony Ericsson	Xperia™ neo
2093	Sony Ericsson	Xperia™ ray
2094	Sony Ericsson	Yari
2095	Sony Ericsson	Z310a
2096	Sony Ericsson	Z750a
2097	Sony Ericsson	Z770i
2098	Sony Ericsson	Zylo?
2099	Sony Ericsson	Aion U10
2100	Sony Ericsson	C903
2101	Sony Ericsson	Elm J10
2102	Sony Ericsson	F100
2103	Sony Ericsson	Hazel J20
2104	Sony Ericsson	K510a
2105	Sony Ericsson	K660i
2106	Sony Ericsson	Satio U1i
2107	Sony Ericsson	Vivaz U5
2108	Sony Ericsson	W395
2109	Sony Ericsson	W902
2110	Sony Ericsson	W995
2111	Sony Ericsson	X10
2112	Sony Ericsson	X10 mini
2113	Sony Ericsson	X10 mini pro
2114	Sony Ericsson	X2
2115	Sony Ericsson	Yari U100
2116	Sony Ericsson	Z550a
2117	Sony Ericsson	Z555
2118	TCT Mobile Suzhou Limited	JukeB
2119	TCT Mobile Suzhou Limited	MOVE/ one touch 908/ one touch 908A/ one touch 908S/ one touch 908M/ one touch 908F
2120	TCT Mobile Suzhou Limited	one touch 318D
2121	TCT Mobile Suzhou Limited	one touch 506/ one touch 506D / one touch 506A
2122	TCT Mobile Suzhou Limited	one touch 536
2123	TCT Mobile Suzhou Limited	one touch 585/ 585D/ 585A
2124	TCT Mobile Suzhou Limited	one touch 602/ 602D/ 602A
2125	TCT Mobile Suzhou Limited	one touch 632D
2126	TCT Mobile Suzhou Limited	one touch 665/ one touch 665A
2127	TCT Mobile Suzhou Limited	one touch 678G
2128	TCT Mobile Suzhou Limited	one touch 803/ one touch 803A/ one touch 813/ one touch 813D/ one touch 813A/ one touch 819/ one touch 819A/ one touch 819D
2129	TCT Mobile Suzhou Limited	one touch 810/ one touch 810A/ one touch 810D
2130	TCT Mobile Suzhou Limited	one touch 818/ one touch 818A/ one touch 818D
2131	TCT Mobile Suzhou Limited	one touch 888/ one touch 888A/ one touch 888D
2132	TCT Mobile Suzhou Limited	one touch 890/ one touch 890D
2133	TCT Mobile Suzhou Limited	one touch 891
2134	TCT Mobile Suzhou Limited	one touch 900M/ one touch 900/ one touch 901A/ one touch 901S/ one touch 901N/ one touch 901D/ one touch 900A
2135	TCT Mobile Suzhou Limited	one touch 905/ 905A/ 907N/ 905M
2136	TCT Mobile Suzhou Limited	one touch 906/ one touch 906Y
2137	TCT Mobile Suzhou Limited	one touch 909B
2138	TCT Mobile Suzhou Limited	one touch 910/ one touch 909A/ one touch 909M/ one touch 909S/ one touch 910A
2139	TCT Mobile Suzhou Limited	one touch 913D/ one touch 913K/ one touch 913N
2140	TCT Mobile Suzhou Limited	one touch 918/ one touch 918A/ one touch 918D/ one touch 918N/ one touch 918M/ TCL A919/ OT 918
2141	TCT Mobile Suzhou Limited	one touch 985/ one touch 985A/ one touch 985S/ one touch 985N/ TCL A966/ OT 985

Item	Brand Name	Model
2142	TCT Mobile Suzhou Limited	one touch 990/ one touch 990A/ one touch 990S/ one touch 990M/ Vodafone 958
2143	TCT Mobile Suzhou Limited	OT-799/ OT-799A
2144	TCT Mobile Suzhou Limited	S by SFR 3440
2145	TCT Mobile Suzhou Limited	TCL-7110
2146	TCT Mobile Suzhou Limited	TCL-8107
2147	TCT Mobile Suzhou Limited	Vodafone 355
2148	TCT Mobile Suzhou Limited	Vodafone 455
2149	TCT Mobile Suzhou Limited	Vodafone 555 Blue
2150	T-Mobile	G2
2151	T-Mobile	MyTouch 3G Slide
2152	T-Mobile	MyTouch 4G
2153	T-Mobile	T-Mobile Wing (S730)
2154	Tsb Plus Deal Corp	EYO DESERT 6
2155	Tsb Plus Deal Corp	EYO E97
2156	Tsb Plus Deal Corp	X95
2157	UT Starcom	CDM8950
2158	UT Starcom	GZ1 C711
2159	ZTE	003Z
2160	ZTE	a5
2161	ZTE	Android Edition Starnaute
2162	ZTE	BJK1903
2163	ZTE	F160
2164	ZTE	F870
2165	ZTE	F870E
2166	ZTE	F930
2167	ZTE	F950
2168	ZTE	F951
2169	ZTE	F951E
2170	ZTE	Jack 3G
2171	ZTE	San Francisco
2172	ZTE	T870
2173	ZTE	T930
2174	ZTE	Tactile internet 2
2175	ZTE	Venus
2176	ZTE	Vodafone 945
2177	ZTE	XCD35
2178	ZTE	ZTE F870
2179	ZTE	ZTE F951
2180	ZTE	ZTE F952 UM KP
2181	ZTE	ZTE-1001
2182	ZTE	ZTE-BLADE
2183	ZTE	ZTE-C F350
2184	ZTE	ZTE-U X990
2185	ZTE	ZTE-U X991
2186	ZTE	008Z
2187	ZTE	008Z
2188	ZTE	009Z
2189	ZTE	Android edition by sfr STARADDICT
2190	ZTE	Android Edition Star Text
2191	ZTE	Android Edition StarTrail
2192	ZTE	Arizona
2193	ZTE	BASE Lutea 2
2194	ZTE	BLADE II
2195	ZTE	Blade S
2196	ZTE	CARL/ ZTE-U V852
2197	ZTE	E821
2198	ZTE	F451
2199	ZTE	KPN Smart 200
2200	ZTE	Light Tab 2W
2201	ZTE	MEDION Smartphone LIFE P4310
2202	ZTE	MEDION Smartphone LIFE P4310
2203	ZTE	Monte Carlo
2204	ZTE	Movistar One
2205	ZTE	Movistar Vega
2206	ZTE	RacerII
2207	ZTE	RacerII
2208	ZTE	S by SFR 116
2209	ZTE	S by SFR 344
2210	ZTE	San Francisco II
2211	ZTE	San Francisco II
2212	ZTE	Skate4.3 H
2213	ZTE	T28
2214	ZTE	T28
2215	ZTE	T50
2216	ZTE	T60
2217	ZTE	tmn smart a7
2218	ZTE	TQ150
2219	ZTE	V871
2220	ZTE	V875
2221	ZTE	Vivacity
2222	ZTE	Vodafone 351
2223	ZTE	Vodafone 550
2224	ZTE	webphones Android™ by sfr STARTEXT II
2225	ZTE	Windows Phone-Internet 7
2226	ZTE	X500
2227	ZTE	X500
2228	ZTE	X500M
2229	ZTE	Z331
2230	ZTE	Z431
2231	ZTE	Z990
2232	ZTE	ZTE E821S

Item	Brand Name	Model
2233	ZTE	ZTE F116/ F116/ ZTE-U F116
2234	ZTE	ZTE Libra
2235	ZTE	ZTE N285
2236	ZTE	ZTE N850
2237	ZTE	ZTE N860
2238	ZTE	ZTE Skate/ ZTE SKATE/ ZTE-SKATE
2239	ZTE	ZTE T12
2240	ZTE	ZTE U6100
2241	ZTE	ZTE V6000
2242	ZTE	ZTE V860
2243	ZTE	ZTE V960
2244	ZTE	ZTE-Atrial
2245	ZTE	ZTE-C D930
2246	ZTE	ZTE-C D980
2247	ZTE	ZTE-C F450
2248	ZTE	ZTE-C X769
2249	ZTE	ZTE-G N285
2250	ZTE	ZTE-G N292
2251	ZTE	ZTE-G N295/ Sydney/ Affinity
2252	ZTE	ZTE-G R228
2253	ZTE	ZTE-G R230
2254	ZTE	ZTE-G R235
2255	ZTE	ZTE-G R236
2256	ZTE	ZTE-G R250
2257	ZTE	ZTE-G R252
2258	ZTE	ZTE-G R260
2259	ZTE	ZTE-G X730
2260	ZTE	ZTE-SKATE/ ZTE Skate
2261	ZTE	ZTE-Tureis
2262	ZTE	ZTE-Tureis
2263	ZTE	ZTE-U E850
2264	ZTE	ZTE-U F110
2265	ZTE	ZTE-U F953 / MIMOSA
2266	ZTE	ZTE-U V857
2267	ZTE	ZTE-U V859
2268	ZTE	ZTE-U V875m
2269	ZTE	ZTE-U V960
2270	ZTE	ZTE-U X720
2271	ZTE	ZTE-U5100
2272	ZTE	ZTR-G V821