Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news.

BC821⁻

Safe & Sound Portable Soother Myla the Monkey





Congratulations

on purchasing your new VTech product. Before using this product, please read Important safety instructions.

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature rich VTech product.

For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com

What's in the box





User's manual

Charge the battery

This portable soother has a built-in rechargeable battery for cordless usage.

To charge the battery, connect the soother with the USB cable provided to power sources with USB port, e.g. computers, USB LPS power adapters, portable LPS chargers, etc.

NOTES

- Make sure the soother and the USB cable are out of reach of children while charging.
- The soother battery is fully charged after 12 hours of continuous charging.
- The USB port is for charging only.



* The USB LPS power adapter is not provided in the package.

strap to tighten it.





User's manual

• •

. .

[] [≋]

vtech

0

•	Keep the s Never place baby's crit
a	ou can us dditional s

Using the tail



Position the soother

()CAUTIONS

- This is not a toy. Do not let your baby play with the product.
 - soother out of the reach of your baby. ce or attach the soother inside the b or playpen.
- se the tail on the soother or the strap provided to hang and attach the soother to almost anywhere, e.g. stroller handle, doorknob, diaper bag straps, etc.
- Use the tail to hook the soother on a desired object to keep it in position.

Using the additional strap

1. To attach the additional strap provided onto the soother, pinch the end of the string and insert it into the slot on the top of the soother. Insert the other end of the strap through the loop of the string, then pull the



2. Wrap the two tapes of the additional strap around a desired object. Adhere the tape with hooks onto the tape with loops, then press the two tapes against each other to close the loop and fix the strap.



Overview





1	J Lullaby
	Press to play or stop the lullaby.
2	vol-
	Press to decrease the speaker volume.
3	 Auto-off timer Press to turn on a 60-minute timer while playing lullaby or soothing sound. It will automatically stop the lullaby or soothing sound after playing for 60 minutes.

4		
4	 Skip Press to skip to the next lullaby or 	
	soothing sound.	
5	Tail	
	Hook the soother on an object.	
6	Dimmable soft-glow night light	
7	pprox Soothing sound	
	 Press to play or stop the soothing sound. 	
8	vol+	
	 Press to increase the speaker volume. 	
9	`ģ' Dimmable soft-glow night light	
	Press to turn on the night light in	
	dim light or bright light mode.	
10	ப் on/off switch	
	• Slide to power on or off the soother.	
11	USB port for battery charging only	
12	Slot for the additional strap	
13	Speaker	
14	O Auto-off timer light indicator	
	• On when the auto-off timer feature is turned on.	
	 Off when the auto-off timer feature is 	
	turned off.	
15	Battery status light indicator	
	• On when the battery is being charged.	
	• Flashes when the battery is low and	
	needs charging.	
	 Off when the battery is not being charged; or the battery is fully charged. 	

Use the soother

Power on or off the soother

• Slide the **on/off** switch on the right-hand side of the soother to on or off.

• Make sure the soother is on before using other features.

Play the lullaby

The soother has five lullables for you to comfort your baby.

- 1. Hush Little Baby 4. Twinkle Twinkle
- 2. Brahms' Lullaby
- 3. Rock a Bye Baby 5. Minuet in G, Bach
- Press b to skip to the next lullaby.
- While a lullaby is playing, press **J** again to stop the lullaby.

- The soother will play the lullables continuously unless you manually stop the lullabies or turn on the auto-off timer feature.
- When a lullaby ends, the soother automatically skips to the next lullaby. After the soother plays the fifth lullaby, it restarts playing from the first lullaby again.

Play the soothing sound

The soother has five soothing sounds for you to comfort your baby.

- 1. White noise 4. Vacuum cleaner 2. Stream 5. Heartbeat
- 3. Crickets
- Press ≈ to start playing soothing sounds.
- Press be to skip to the next soothing sound.
- While a soothing sound is playing, press \approx again to stop the soothing sound.

- The soother will play the soothing sounds continuously unless you manually stop the soothing sounds or turn on the auto-off timer feature.
- The soother will repeat the same soothing sound again and again unless you skip to the other soothing sounds.

Little Star

Adjust the speaker volume

• Press vol- or vol+ at any time.

• The soother beeps to notify you when the speaker volume is already at the highest or lowest setting while adjusting.

Turn on or off the auto-off timer

While the soother is playing a lullaby or soothing sound, the auto-off timer feature helps you automatically stop the lullaby or soothing sound after playing for 60 minutes

- 1. While a lullaby or soothing sound is playing, press () to turn on the auto-off timer feature.
- The soother starts counting down 60 minutes. The auto-off timer light indicator on the left-hand side of the soother turns on.
- 2. After 60 minutes, the soother will automatically stop any lullaby or soothing sound. The auto-off timer feature and the corresponding light indicator will turn off.

ONOTES

- You can only turn on the auto-off timer feature when the soother is playing a lullaby or soothing sound.
- The auto-off timer feature will not power off the soother after the 60-minute countdown.
- You can press 🕑 again to turn off the auto-off timer feature during the 60-minute countdown.
- If you manually stop the lullaby or soothing sound while the auto-off timer is counting down, the auto-off timer will turn off.

Turn on or off the dimmable soft-glow night light

When the soother is on, press or repeatedly to choose from below night light options:

- Turn on the night light in dim light mode, or
- Turn on the night light in bright light mode, or
- Turn off the night light.

• The night light will be automatically off after 15 minutes.

General product care

To keep this soother working well and looking good, follow these auidelines:

- Avoid putting the soother near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- Avoid dropping the soother or treating it roughly.
- DO NOT expose the soother to direct sunlight or moisture
- DO NOT use the soother in the rain, or handle it with wet hands.
- Clean with a soft cloth.
- DO NOT immerse the soother in water and do not clean it under the tap.
- DO NOT use cleaning spray or liquid cleaners.
- Make sure the soother is dry before you connect it to the any power sources.

Frequently asked questions

Below are the questions most frequently asked about the soother. If you cannot find the answer to your question, visit our website at www.vtechphones.com, or contact 1 (800) 595-9511 for customer service. In Canada. visit our website at www.vtechcanada.com or call 1 (800) 267-7377.

The soother does not play sounds. / The night light does not turn on.	 Make sure the soother is turned on. Make sure the battery has enough charge. Connect the soother to USB power if necessary.
Why does the Battery status light indicator flash?	The soother battery is low and needs charging. Connect the soother to USB power to charge the battery.
When I press To turn on the auto-off timer, the soother beeps. The O light indicator doesn't turn on.	The auto-off timer feature is not turned on. Make sure you press ⑦ when the soother is playing a lullaby or soothing sound.
Why doesn't my computer detect the soother when they are connected via USB cable?	The USB port on the soother is for charging only. It does not support data transfer.

mportant safety instruction

When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- 1. Follow all warnings and instructions marked on the product.
- 2. Adult setup is required.
- 3. Do not use this product near water. For example, do not use it next to a bath tub, wash bowl, kitchen sink, laundry tub or swimming pool, or in a wet basement or shower.
- 4. **CAUTION:** Use only the batteries indicated in this manual. There may be a risk of explosion if a wrong type of battery is used for the product. Use only the supplied rechargeable battery or replacement battery pack (BT166342/ BT266342) for the product. Do not dispose of batteries in a fire. They may explode. Dispose of used battery according to the information in The RBRC[®] seal.
- . Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- 6. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register.
- Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the product other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently
- 9. Periodically examine all components for damage.
- 10. Children should be supervised to ensure that they do not play with the product.
- 11. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SAVE THESE INSTRUCTIONS

Cautions

- 1. Use and store the product at a temperature between 32°F and 104°F.
- 2. Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source.
- . Make sure the product and the USB cable are always out of reach of the baby, at least 3 feet away from the baby or crib, to avoid a possible strangulation hazard.
- Never place the product inside the baby's crib or playpen. Never cover the product with anything such as a towel or a blanket.

The RBRC[®] seal

The RBRC[®] seal on the nickel-metal hydride battery indicates that VTech Communications. Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada.

The RBRC® program provides a convenient alternative to placing used nickel-metal hydride batteries into the trash or municipal waste, which may be illegal in your area.

VTech's participation in RBRC[®] makes it easy for you to drop off the spent battery at local retailers participating in the RBRC[®] program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY[®] for information on Ni-MH battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.



RBRC[®] and 1 (800) 8 BATTERY[®] are registered trademarks of the Rechargeable Battery Recycling Corporation.

FCC and IC regulations

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The soother shall be installed and used such that parts of all persons' body are maintained at a distance of approximately 8 in (20 cm) or more.

This Class B digital apparatus complies with Canadian requirement: CAN ICES-3 (B)/NMB-3(B)

Industry Canada

exempt RSS standard(s).

operation.

technical specifications.

RF radiation exposure statement

Humans to RF Fields.

California Energy Commission Dattery charging testing mode

- This device complies with Industry Canada licence-
- Operation is subject to the following two conditions: (1) this device may not cause harmful interference. and (2) this device must accept any interference, including interference that may cause undesired
- The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.
- This product meets the applicable Industry Canada
- The soother complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The soother should be installed and operated with a minimum distance of 8 in (20 cm) between the soother and all persons' body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposure of
- This soother meets the California Energy Commission (CEC) regulations for energy consumption. Your soother is set up to comply with the energy-conserving standards right out of the box. The CEC battery charging testing mode is activated while the soother is powered off and charging.

For cETL compliance only

Mesures de sécurité importantes

Lorsque vous utilisez votre appareil, vous devriez toujours suivre certaines mesures de précaution de base afin de réduire les risques d'incendie, d'électrocution et de blessures corporelles, dont ceux qui suivent

- 1. Observez toutes les instructions et mises en garde inscrites sur l'appareil.
- L'installation par un adulte est reguise.
- 3. N'utilisez pas cet appareil près de l'eau ni de toute autre source d'humidité, par exemple, près d'une baignoire, cuve à lessive, évier de cuisine, dans un sous-sol humide ni près d'une piscine, dans un soussol humide ou une douche.
- MISE EN GARDE: N'utilisez que les piles indiquées dans le guide d'utilisation. Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour le produit. N'utilisez que le bloc-piles rechargeable inclus ou le blocpiles de rechange (BT166342/BT266342) pour le produit. N'incinérez pas les piles. Celles-ci risqueraient d'exploser. Jetez les piles usées selon les renseignements suivant le sceau du RBRC^{MD}.
- 5. Ne placez pas cet appareil sur un chariot, meuble, trépied, support de montage ni table chancelants.
- 5. Les trous et ouvertures du boîtier, situés à l'arrière de l'appareil ou sous celui-ci, servent à aérer l'appareil. Pour l'empêcher de surchauffer, ne bloquez sous aucun prétexte ces ouvertures et n'empêchez pas l'aération adéquate de l'appareil en le placant sur un lit, divan, tapis ou toute autre surface similaire. De même, ne le positionnez pas à proximité ni au-dessus d'une source de chaleur ou d'un calorifère. De plus, ne placez pas l'appareil dans un endroit avant de vous assurer qu'il y ait une bonne circulation d'air.
- 7. N'enfoncez jamais d'objets à travers les ouvertures de cet appareil, car ils pourraient entrer en contact avec des points de tension dangereux ou causer des courts-circuits qui peuvent dégénérer en incendies ou en risques d'électrocution. Ne renversez jamais de liquide dans ce produit.
- 8. Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, mais apportez-le dans un centre de service autorisé. L'ouverture du boîtier ou le retrait de toutes pièces que contient cet appareil, à l'exception de l'accès autorisé à certaines portes ou ouvertures, risque de vous exposer à des points de tension dangereux ou d'autres dangers. Un remontage incorrect peut par la suite présenter des risques d'électrocution.

- 9. Examinez les composantes afin de vérifier si celles-ci ne sont pas endommagées.
- 10. Les enfants devraient être supervisés afin de vous assurer qu'ils ne jouent pas avec l'appareil.
- 11. Le produit n'est pas conçu pour être utilisé par des personnes (incluant des enfants) aux capacités physiques, sensorielles ou mentales réduites ou qui manquent d'expérience et de connaissances, à moins qu'on leur ait donné suffisamment de supervision ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité.

CONSERVEZ CES INSTRUCTIONS

Mises en garde

- 1. Utilisez et entreposez le produit à une température entre 0° C (32°F) et 40°C (104° F).
- 2. N'exposez pas cet appareil à des froids ou des chaleurs extrêmes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas près d'une source de chauffage.
- Assurez-vous que le produit et le câble USB se trouvent hors de portée d'un bébé, à au moins trois pieds du bébé ou du berceau, afin d'écouter les risques d'étranglement.
- 4. Ne placez jamais le produit à l'intérieur du berceau ou du parc de bébé. Ne couvrez jamais le produit d'une serviette ou une couverture.

Limited warranty

What does this limited warranty cover?

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "vou") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?

During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or replacement to take approximately 30 days.

How long is the limited warranty period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective Product under the terms of this limited warranty. this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer

What is not covered by this limited warranty?

This limited warranty does not cover:

- 1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
- 2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech: or
- 3. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems: or

- 4. Product to the extent that the problem is caused by use with non-VTech accessories: or
- 5. Product whose warranty/guality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or
- 6. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
- 7. Product returned without a valid proof of purchase (see item 2 on the next page); or
- 8. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

How do you get warranty service?

To obtain warranty service in the USA, please visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.

What must you return with the Product to get warranty service?

- 1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty: and
- 2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- Provide your name, complete and correct mailing address, and telephone number.

Other limitations

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There

are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please retain your original sales receipt as proof of purchase.

echnical specifications

Power

Built-in rechargeable 750mAH requirements Ni-MH battery

> Charging via USB to computer or LPS power adapter

Credits:

The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license.

The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license. The Crickets At Night sound file was created by Mike

Koenig, and is used under the Creative Commons license.

The 20121230 vacuum.cleaner.working.01 sound file was created by dobroide, and is used under the Creative Commons license.

The *Heartbeat 5sec Int* sound file was created by Benboncan, and is used under the Creative Commons license





Specifications are subject to change without notice. © 2016 VTech Communications, Inc. All rights reserved. 08/16. BC8211 CIB V3 Document order number: 91-010106-030-100