

Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news.

VM350
VM350-2

Full Color Video Monitor

BC



vtech
User's manual


CONGRATULATIONS

on purchasing your new VTech product. Before using this product, please read **Important safety instructions**.

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature-rich VTech product.

For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com.

WHAT'S IN THE BOX



Power requirements		Parent unit: 3.7V Li-polymer battery Baby unit power adapter: Output: 5V DC @ 600mA Parent unit power adapter: Output: 5V DC @ 1A
Nominal effective range		(Maximum power allowed by FCC and IC; Actual operating range may vary according to environmental conditions at the time of use.) (WVGA 480x272 pixel)
LCD		5" Color LCD
Channels		32
Transmit frequency		Baby unit: 2405 - 2475 MHz Parent unit: 2405 - 2475 MHz
Frequency control		Crystal controlled PLL synthesizer

Credits:
The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license.
The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license.
The Crickets At Night sound file was created by Mike Koenig, and is used under the Creative Commons license.
The Heart Beat sound file was created by Zarabedou, and is used under the Creative Commons license.


1 CONNECT AND CHARGE THE BATTERY

Install the parent unit battery

The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, keep the parent unit connected to AC power. With the battery alone, the parent unit can cordlessly run for a short time only.

NOTES

- Use only the battery supplied with this product.
- If the parent unit will not be used for a long time, disconnect and remove the battery to prevent possible leakage.




Replace the battery

To replace the battery, press down on the battery compartment cover and pull it out, then follow the steps above to install the battery.

Connect the baby monitor

NOTES

- Use only the power adapters supplied with this product.
- Make sure the baby monitor is not connected to a switch-controlled electric outlet.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby units and the power adapter cords are out of reach of children.



Charge the parent unit battery

When you have connected the parent unit and installed its battery for the first time or after power outage, the parent unit powers on automatically. The battery icon indicates the battery status (see the following table).

NOTES

- The parent unit battery is fully charged after 3 hours of continuous charging.
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging.
- The standby time varies depending on the sensitivity level you set, your actual use and the age of the battery.

BATTERY INDICATORS	BATTERY STATUS	ACTION
The battery icon is off and displays	No battery is installed but operates using AC power, or the battery has been installed incorrectly.	Install the parent unit battery. Charge without interruption (at least 30 minutes).
The screen displays Battery low at Parent unit and The light flashes.	The battery has very little charge and may be used for only a short time.	Charge without interruption (about 30 minutes).
The battery icon becomes solid	The battery is fully charged.	To keep the battery charged, connect it to AC power when not in use.

2 BEFORE USE

NOTE

- This baby monitor is intended as an aid. It is not a substitute for proper adult supervision, and should not be used as such.

Test your baby monitor

You may test the baby monitor before initial use, and at regular times thereafter.

CAUTION

- For hearing protection, make sure the parent unit is more than 3 feet (1 meter) away from both baby units. If you hear any high-pitched noise, move the parent unit further until the noise stops. You can also press VOL on the parent unit to reduce the noise.

- Make sure your baby units and parent unit are on.
- The parent unit displays images from the baby unit.
 - Speak towards the microphone of the baby unit. You will hear the sound at the parent unit.
- Press **VIEW** on your parent unit. The screen switches to the other baby unit. Then, repeat step 2.

NOTE

- When the parent unit displays and then **No Link to CAM #** (# represents the baby unit number), and the **LINK** LED light flashes, move the parent unit closer to the baby units (observe the minimum distance of 3 feet / 1 meter).

TIP

- Increase the speaker volume of the parent unit if you cannot hear the sounds transmitted from the baby units.

Positioning the baby monitor


CAUTION

- Keep the baby units out of the reach of your baby. Never place or mount the baby units inside the baby's crib or playpen.

NOTE

- To avoid interference from other electronic devices, place your baby monitor away from devices such as wireless routers, microwaves, cell phones and computers.

- Place the baby units more than 3 feet (1 meter) away from your baby.
- Adjust the angle of the baby units camera to aim at your baby.
- Place the parent unit more than 3 feet (1 meter) away from the baby units.



CAUTION

- The default volume of your parent unit is level 4, and the maximum volume is level 7. If you experience high-pitched screeching noise from your baby monitor while positioning:
 - Make sure your baby units and parent unit are more than 3 feet (1 meter) apart, OR
 - Lower the volume of your parent unit.

Operating range

The operating range of the baby monitor is up to 1000 feet (300 meters) outdoors or 160 feet (50 meters) indoors. The actual operating range may vary depending on the environmental conditions and other interferences such as walls, doors and other obstructions.

3 USING THE BABY MONITOR

Power on or off the baby unit

- Slide the **ON/OFF** switch to **ON** to turn on the baby unit. The **POWER** LED light turns on.
- Slide the **ON/OFF** switch to **OFF** to turn off the baby unit. The **POWER** LED light turns off.

Power on or off the parent unit

- Press and hold **POWER** to turn on the parent unit. The screen turns on.
- Press and hold **POWER** again to turn off the parent unit. The screen turns off.

Turn on or off the parent unit screen

You can turn on or off the parent unit screen without powering off the parent unit. You can still hear sound from the baby units.

- Press and hold **LCD ON/OFF** on the parent unit to turn off the screen.
- Press any keys on the parent unit to turn on the screen again.

Adjust speaker volume

For parent unit:

- Press **VOL** or VOL on the parent unit at any time when viewing images.

For baby unit:

The baby unit speaker volume determines the lullaby volume and talkback volume transmitted from parent unit. It can be adjusted in the parent unit.

- Press **MENU** when the parent unit is idle.
- Press or to choose **Volume on CAM**, then press **SELECT**.
- Press or to choose the desired volume level, Level 1 is the softest while Level 5 is the loudest. Then, press **SELECT** to confirm your selection.

NOTE

- Volume adjustment with the parent unit menu is available in **Single CAM** and **Patrol** mode only.

3 USING THE BABY MONITOR (CON'T)

Adjust LCD brightness

You can change the brightness of the parent unit screen from **Level 1** to **Level 5**. The LCD brightness is preset to **Level 3**.

- Press **MENU** when the parent unit is idle.
- Press or to choose **LCD**, then press **SELECT**.
- Press **SELECT** again to choose **Brightness**.
- Press or to choose the desired level of brightness, then press **SELECT** to confirm your selection.

Turn on and off the dim mode

The dim mode is preset to on to help you save the parent unit power. Your parent unit display will dim automatically after 10 minutes of inactivity, in which there is neither key pressed nor alert received from the baby units.

- Press **MENU** when the parent unit is idle.
- Press or to choose **LCD**, then press **SELECT**.
- Press or to choose **Dim Mode**, then press **SELECT**.
- Press or to choose **On** or **Off**, then press **SELECT** to confirm your selection.

NOTE

- While the screen is dimmed, any keypress or alert message will trigger the screen to return to the preset brightness level. After 10 minutes of inactivity, it will dim again.

Monitoring mode * for VM350-2 only

Every time the parent unit is turned on, it displays a baby unit in **Single CAM** mode. You can also monitor your baby in **Patrol** or **Split** mode.

Single CAM	The screen displays image of a single baby unit in full screen.
Patrol	A single cam view that transitions to a different baby unit every 10 seconds.
Split	The screen displays both baby units.

You can choose the desired monitoring mode.

- Press **MENU** when the parent unit is idle.
- Press or to choose **Monitoring Mode**, then press **SELECT**.
- Press or to choose **Single CAM**, **Patrol** or **Split**, then press **SELECT**.

In Single CAM or Patrol mode:


- Press **VIEW** to view the next baby unit.

In Split mode:

- Press or to select a baby unit.
- Press or **VIEW** to view the selected baby unit temporarily in **Single CAM** mode. It returns to **Split** mode after 10 seconds.

NOTE

- The parent unit is muted while in **Split** mode.



Adjust the sound sensitivity of the baby unit

You can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. The VOX sensitivity level is preset to **Highest**.

VOX SENSITIVITY LEVEL	Highest	High	Medium	Low	Lowest
DESCRIPTION	The parent unit speaker is constantly on, and you will hear all sounds (including background noises) from your baby's room.	The parent unit speaker turns on for soft babbling and louder sounds from your baby. It remains quiet when your baby sleeps soundly.	The parent unit speaker turns on for loud babbling and louder sounds from your baby. It remains quiet when your baby makes soft sounds.	The parent unit speaker turns on for crying and louder sounds from your baby. It remains quiet when your baby makes soft sounds.	The parent unit speaker turns on for loud crying or screeching sounds from your baby. It remains quiet when your baby makes soft sounds.

- Press **MENU** when the parent unit is idle.
- Press or to choose **VOX Sensitivity**, then press **SELECT**.
- Press or to choose **ALL CAM** or **CAM #**, then press **SELECT**.
- Press or to choose the desired sensitivity level, then press **SELECT** to confirm your selection.

NOTE

- As long as the **Sound-activated Screen** setting is **On**, the screen will turn on automatically when VOX sensitivity is triggered, despite it was off earlier.

TIPS

- You can adjust the baby unit placement to improve the sound detection.
- If you want to use a sound machine or white noise machine for natural white noise while using this baby monitor to check on your baby, you can:
 - Lower the volume of your sound machine or white noise machine; or
 - Lower the sensitivity level of your baby monitor to **Medium** or below. Default level is the highest level.

Turn on or off the sound activation

When sound activation is on, as long as no sound is detected within 50 seconds, the parent unit screen will turn off automatically to save power.

When your baby unit detects a sound, which exceeds the selected sensitivity level, the sound activation triggers the parent unit screen to turn on automatically. When no sound is detected within 50 seconds, the screen will be off again.

- Press **MENU** when the parent unit is idle.
- Press or to choose **Sound-activated Screen**, then press **SELECT**.
- Press or to choose **On** or **Off**, then press **SELECT** to confirm your selection. The screen returns to main menu.

NOTES

- Sound activation is available in **Single CAM** and **Patrol** mode only.
- If the sound sensitivity is set to **Highest**, the parent unit screen may remain on continuously even though sound activation is on. This depends on whether the baby unit detects any sounds.

Lullaby

The baby monitor has five lullabies and four soothing sounds for you to comfort your baby. You can play lullabies or soothing sounds on the baby unit by controlling remotely with the parent unit.

To play lullabies:

- Press **MENU** when the parent unit is idle.
- Press or to choose **Lullaby on CAM**, then press **SELECT**.
- Press or to choose **Play Melodies**, then press **SELECT**.
- Press or to choose a lullaby, or choose **Play All**, then press **SELECT**.
 - If **Play All** is selected, the five lullabies will be played one after the other, until all of them are played.
- When the desired lullaby is selected, press or to choose **Play**, then press **SELECT**.

To play soothing sounds:

- Press **MENU** when the parent unit is idle.
- Press or to choose **Lullaby on CAM**, then press **SELECT**.
- Press or to choose **Play Soothing Sounds**, then press **SELECT**.
- Press or to choose a soothing sound, then press **SELECT**.
- Press or to choose **Play**, then press **SELECT**.

NOTES

- Lullaby playback control is available in **Single CAM** and **Patrol** mode only.
- The lullaby playback on the baby unit will be paused when receiving talkback from the parent unit.

To stop lullabies or soothing sounds:

- Press **MENU** when the parent unit is idle.
- Press or to choose **Lullaby on CAM**, then press **SELECT**.
- Press or to choose **Stop**, then press **SELECT**.

To set auto timer for lullabies:

While the baby unit is playing a lullaby or soothing sound, the auto timer feature automatically stops the lullaby or soothing sound after playing for 15/30/45/60 minutes. You can set auto timer for lullabies with the parent unit.

- Press **MENU** when the parent unit is idle.
- Press or to choose **Lullaby on CAM**, then press **SELECT**.
- Press or to choose **Auto Timer**, then press **SELECT**.
- Press or to choose the desired lullabies duration, then press **SELECT** to confirm your selection.


After 15/30/45/60 minutes, the lullaby or soothing sound will stop automatically.

Set the language

You can select a language (English, French or Spanish) to be used in all screen displays.

- Press **MENU** when the parent unit is idle.
- Press or to choose **Language**, then press **SELECT**.
- Press or to choose **English**, **Français** or **Español**, then press **SELECT** to confirm your selection.

BABY UNIT OVERVIEW



1

Pair hole

- Your baby units and parent unit provided are already paired.

2

POWER LED light

- On when the baby unit is turned on and is paired to the parent unit.
- Flashes when the baby unit is not being viewed; or when the link to the parent unit is lost.

3

Microphone

4

Camera

5

Infrared LEDs

6

Light sensor

7

ON/OFF switch

- Slide to turn on or off the baby unit.

8

Speaker


9

Power jack

10

Wall mount holes

PARENT UNIT OVERVIEW



1

LED lights
Indicate the different statuses of the parent unit. For details, refer to **Parent unit lights**.

2

LCD display

- VOL**
- VOL**

STORAGE

When you are not going to use the baby monitor for some time, remove the rechargeable battery from the parent unit. Store the parent unit, the baby unit and the adapters in a cool and dry place.

FREQUENTLY ASKED QUESTIONS

Below are the questions most frequently asked about the baby monitor. If you cannot find the answer to your question, visit our website at www.vtechphones.com, or contact **1 (800) 595-9511** for customer service.

Why does the baby monitor not respond normally?	<div>Try the following (in the order listed) for common cure:</div> <div><div>1</div><div>Disconnect the power to the baby units and the parent unit.</div></div> <div><div>2</div><div>Remove the batteries in the parent unit. Then, install the batteries again.</div></div> <div><div>3</div><div>Wait a few seconds before connecting power back to the baby units and the parent unit.</div></div> <div><div>4</div><div>Turn on the baby units and the parent unit.</div></div> <div><div>5</div><div>Wait for the parent unit to synchronize with the baby units. Allow up to one minute for this to take place.</div></div>
Why don't the porch-on light of the baby unit and parent unit go on when I switch on the units?	<div>Perhaps the parent unit is not connected to the mains. Insert the appliance plug into the parent unit and put the adapter in a wall socket. Then, press and hold POWER to switch on the parent unit and to establish connection with the baby unit.</div> <div>Perhaps the baby unit is not connected to the mains. Connect the baby unit to the mains. Then, slide the ON/OFF switch to ON to switch on the baby unit and to establish connection with the parent unit.</div>
Why doesn't my parent unit charge while connected to AC power?	<div>Make sure the power is not controlled by a wall switch.</div> <div>Make sure the battery is correctly installed in your parent unit.</div> <div>You may have used the battery for a long time. Replace a new battery.</div>
Why is my screen in black and white?	<div>The screen is in black and white during night-time or in a dark room when the night vision feature is activated. This is normal.</div>
Why do I get glare or blurry display on my screen when viewing my baby at night?	<div>During night-time or in a dark room, the surroundings and other interfering factors, like lightnings, objects, colors and backgrounds may affect the image quality on your parent unit screen. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.</div>
Why does the baby monitor produce a high-pitched noise?	<div>The parent unit and baby units may be too close to each other.</div> <div><div><div>•</div><div>Move the parent unit away from the baby units until the noise stops; OR</div></div><div><div>•</div><div>Lower the volume of your parent unit.</div></div></div>
Why does the parent unit beep?	<div>The baby units may be out of range. Move the parent unit closer to the baby units (but not less than 3 feet).</div>

If the parent unit is powered by the provided battery, it may not have enough charge for the parent unit to perform normally. Charge the battery in the parent unit for up to 3 hours.
If your parent unit is in Split mode, some of your baby units may detect sounds.
The temperature of your baby's room may be too high or too low.

Why does the parent unit beep frequently in Split mode?	You may have set the VOX sensitivity level to Highest when the sound alert feature is turned on. The parent unit notifies you of all sounds including background noise with beeps. Adjust the VOX sensitivity to a lower level.
--	--

Why does the parent unit react too quickly to other sounds?	The baby unit also picks up other sounds than those of your baby. Adjust the VOX sensitivity level to a lower level or lower the parent unit speaker volume.
---	--

Why don't I hear a sound/ Why can't I hear my baby cry?	The parent unit speaker volume may be too low. Press VOL to increase the volume.
---	---

Why can't I establish a connection? Why is the connection (or even my own and their) Why are there sound interruptions?	<div>The baby units may be out of range. Move the parent unit closer to the baby units (observe the minimum distance of 3 feet/ 1 meter).</div> <div>Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible.</div>
---	---

If you power on only one baby unit, your parent unit may display and No link to CAM # , and the LINK LED light flashes. Press VIEW to switch to the baby unit you have powered on.
--

PARENT UNIT OVERVIEW (Con't)

5

Zoom

- Press to zoom in or out.

6

VIEW / LCD ON/OFF

7

Microphone

8

POWER

9

TALK

- Press and hold to talk to the selected baby unit.

10

Navigation icons

- While in a menu, press to return to the main menu or idle screen.
- While viewing zoomed image, press and hold to move the zoomed image leftward.
- While in **Split** mode, press to move the selection box leftward.

11

Up arrow icon

- While in a menu, press to scroll up.
- While viewing zoomed image, press and hold to move the zoomed image upward.

12

Right arrow icon

- While in a menu, press to choose an item.
- While viewing zoomed image, press and hold to move the zoomed image rightward.

13

MENU/SELECT

- Press to enter the menu.
- While in a menu, press to choose an item, or save a setting.

14

Down arrow icon

- While in a menu, press to scroll down.
- While viewing zoomed image, press and hold to move the zoomed image downward.

15

Antenna

16

Speaker

17

Power jack

18

Battery compartment cover

19

Stand

PARENT UNIT LIGHTS

LINK	<ul style="list-style-type: none">On when the parent unit is linked to the baby unit.Flashes when the link to the baby unit being viewed in Single CAM or Patrol mode is lost; or when the link to at least one baby unit being viewed in Split mode is lost.
	<ul style="list-style-type: none">On when the parent unit is connected to AC power, or the battery is charging.Flashes when the parent unit battery is low and needs charging.Off when the parent unit is disconnected from AC power.
	<div>It turns on:</div> <ul style="list-style-type: none">When the parent unit is talking to the baby unit; orWhen the parent unit is in Split mode.
TALK	<ul style="list-style-type: none">On when the parent unit is talking to the baby unit.

PARENT UNIT ICONS

Status icons

Connection status

- displays when strong signal strength is detected between the baby unit and the parent unit.
- or displays when moderate or low signal strength is detected between the baby unit and the parent unit.
- displays when the link between the baby unit and the parent unit is lost.

Lullaby

- Displays when the baby unit being viewed is playing lullaby.

Current view status

- Displays the number of the baby unit that is being viewed when in **Single CAM** and **Patrol** mode.
- Displays the baby unit number of the selected baby unit when in **Split** mode.

Patrol mode

- Displays when the parent unit is in **Patrol** mode.
- For VM350-2 only.

Split mode

- Displays when the parent unit is in **Split** mode.
- For VM350-2 only.

Night vision

- Displays when the baby unit being viewed has activated the night vision feature.

Zoom

- Displays when the current image on the parent unit has zoomed in.

Temperature alert tone

- Displays when the temperature alert tone is set on.

°F or °C

Real-time temperature

- Displays the real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. **57°F** or **14°C**).

Mute alert

- Displays when the parent unit is talking to the baby unit.
- Displays when **Split** mode is turned on.

9-level sound indicator

- (1 to 3 bars) indicates low sound level detected by the baby unit.
- (4 to 6 bars) indicates moderate sound level detected by the baby unit.
- (7 to 9 bars) indicates high sound level detected by the baby unit.

Speaker volume

- Displays the parent unit speaker volume level while adjusting.

Battery status

- animates when the battery is charging.
- displays solid when the battery is fully charged.
- displays when the battery is low and needs charging.

AC power without battery

- Displays when the parent unit is connected to AC power without the battery.

Main menu icons

Monitoring Mode

- You can select a monitoring mode (**Single CAM**, **Patrol** or **Split**).
- For VM350-2 only.

Alert Tone

You can set the parent unit to beep when

- the parent unit operates in low battery condition;
- the link between the parent unit and the baby unit is lost; or
- the baby unit detects sounds while in **Split** mode.

Language

- You can select a language (**English**, **French** or **Spanish**) to be used in all screen displays.

LCD

- You can change the brightness of the parent unit screen, or turn on the **Dim Mode** to save power.

Rename

- You can choose a specific name for the baby unit from a pre-defined name list.

VOX Sensitivity

- With this feature, you can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit.

Sound-activated Screen

- When the baby unit detects no sound, the parent unit screen stays off to save power. Once a sound is detected, the parent unit screen turns on automatically. It will then turn off again after 50 seconds of no sound detection.

Temperature

- You can choose to set the maximum/ minimum temperature and turn on the **Temperature alert tone**, so that the parent unit beeps whenever the room temperature detected by the baby unit falls outside of the desired temperature range.
- You can choose to display the temperature in Fahrenheit (°F) or Celsius (°C) on your parent unit.

Lullaby on CAM

- You can choose a lullaby or soothing sound to comfort your baby.

Volume on CAM

- You can adjust the volume of baby units which determines the lullaby volume and talkback volume transmitted from parent unit.

Warning icons and messages

No Link to CAM # *

The selected baby unit is out of range or is turned off.

Battery low at Parent Unit

The battery level of the parent unit is very low and needs to be recharged.

Battery empty. Powering off ...

The battery is empty and needs to be recharged.

Sound detected at CAM #

The sound level exceeds the threshold at CAM # in **Split** mode.

FOR CETL COMPLIANCE ONLY

Mesures de sécurité importantes <p>Lorsque vous utilisez votre appareil, vous devriez toujours suivre certaines mesures de précaution de base afin de réduire les risques d'incendie, d'électrocution et de blessures corporelles, dont ceux qui suivent :</p> <div><div>1</div><div>Observez toutes les instructions et mises en garde inscrites sur l'appareil.</div></div> <div><div>2</div><div>L'installation par un adulte est requise.</div></div> <div><div>3</div><div>Ce produit a été conçu pour être un dispositif d'appoint seulement. Il n'est pas le remplacement d'une supervision responsable et adéquate par un adulte et ne devrait pas être utilisé comme telle.</div></div> <div><div>4</div><div>Ce produit n'est pas conçu pour être utilisé en tant que moniteur médical.</div></div> <div><div>5</div><div>N'utilisez pas cet appareil près de l'eau ni de toute autre source d'humidité, par exemple, près d'une baignoire, cuve à lessive, évier de cuisine, dans un bain ou sous une douche, dans une piscine, dans un soussol humide ou une douche.</div></div> <div><div>6</div><div>MISE EN GARDE: Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour l'unité du parent. N'utilisez que le bloc-piles rechargeable inclus ou le bloc-piles de rechange (BT198555/8T298555). N'incinérerez pas les piles. Celles-ci risqueraient d'exploser. Lire les piles selon les renseignements suivant le scellé du PRISÉ.</div></div> <div><div>7</div><div>N'utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril. Adaptateur de l'unité du bébé : Sortie : 5V CC 600mA. Adaptateur de l'unité du parent : Sortie : 5V CC 1A</div></div> <div><div>8</div><div>Lorsqu'ils sont branchés dans une prise de courant, les adaptateurs secteur ont été conçus pour être orientés correctement, soit à la verticale ou au plancher. Les broches n'ont pas été conçues pour supporter le poids du bloc d'alimentation et le maintenir en place si celui-ci est branché dans une prise au plafond, sous une table ou dans le mur.</div></div> <div><div>9</div><div>Pour les PRODUITS À BRANCHE, À UNE PRISE DE COURANT, la prise de courant doit être installée près du produit, afin d'assurer une accessibilité sécuritaire à la prise de courant.</div></div> <div><div>10</div><div>Débrancher ce produit de la prise de courant avant de procéder au nettoyage. N'utilisez pas de nettoyeurs en aérosols. Utilisez un chiffon humide pour le nettoyer.</div></div> <div><div>11</div><div>Débrancher les cordons d'alimentation avant de remplacer le bloc-piles.</div></div> <div><div>12</div><div>Ne coupez pas les cordons d'alimentation pour remplacer les fiches, car ceci peut présenter un danger potentiel.</div></div> <div><div>13</div><div>Ne laissez aucun cordon de courant d'alimentation. N'installez pas cet appareil dans un endroit où l'on risque d'écraser le cordon d'alimentation ou de le piétiner.</div></div> <div><div>14</div><div>Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur l'étiquette. Si vous ne connaissez pas le type d'alimentation que vous possédez à votre domicile, consultez votre marchand ou votre compagnie locale d'électricité.</div></div> <div><div>15</div><div>Ne surchargez pas les prises de courant murales ni les rallonges électriques.</div></div> <div><div>16</div><div>Ne placez pas cet appareil sur un chariot, meuble, trépied, support de montage ni table chancelantes.</div></div> <div><div>17</div><div>Les trous et ouvertures du boîtier, situés à l'arrière de l'appareil ou sous celui-ci, servent à aérer l'appareil. Pour l'empêcher de surchauffer, ne bloquez sous aucun prétexte ces ouvertures et n'empêchez pas l'aération adéquate de l'appareil en le plaçant sur un lit, divan, tapis ou toute autre surface similaire. De même, ne le positionnez pas à proximité ni au-dessus d'une source de chaleur ou d'un calorifère. De plus, ne placez pas l'appareil dans un endroit où vous assurez qu'il y ait une bonne circulation d'air.</div></div> <div><div>18</div><div>N'enfoncez jamais d'objets à travers les ouvertures de cet appareil, car ils pourraient entrer en contact avec des points de tension dangereux ou causer des courts-circuits qui peuvent générer des incendies ou en risques d'électrocution. Ne renversez jamais de liquide dans ce produit.</div></div> <div><div>19</div><div>Afin de réduire les risques d'incendie, ne démontez pas cet appareil, mais apportez-le dans un centre de service autorisé. L'ouverture du boîtier ou le retrait de toutes pièces qui contiennent cet appareil, à l'exception de l'accès autorisé à certaines portes ou ouvertures, risque de vous exposer à des points de tension dangereux et de causer des incendies ou des électrocutions.</div></div> <div><div>20</div><div>Vous devriez tester la réception chaque fois que vous mettez l'appareil en fonction.</div></div> <div><div>21</div><div>Examinez les composantes afin de vérifier si celles-ci ne sont pas endommagées.</div></div> <div><div>22</div><div>Soyez avisé de la perte de la confidentialité lorsque vous utilisez les ondes publiques. Les conversations peuvent être entendues par d'autres moniteurs de bébé, des téléphones sans fil, des scanners, etc.</div></div> <div><div>23</div><div>Les enfants devraient être supervisés afin de vous assurer qu'ils ne jouent pas avec l'appareil.</div></div> <div><div>24</div><div>Le produit n'est pas conçu pour être utilisé par des personnes (incluant des enfants) aux capacités physiques, sensorielles ou mentales réduites ou qui manquent d'expérience et de connaissances, à moins qu'on leur ait donné suffisamment de maintenance ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité.</div></div>	
---	--

Mise en garde <div><div>1</div><div>Utilisez et entreposez le produit à une température entre 0 ° C (32 ° F) et 40 ° C (104 ° F).</div></div> <div><div>2</div><div>N'exposez pas cet appareil à des froids ou des chaleurs extrêmes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas près d'une source de chauffage.</div></div> <div><div>3</div><div>Le bloc-piles ne doit pas être exposé à la chaleur excessive telle que la lumière du soleil ou au feu.</div></div> <div><div>4</div><div>Assurez-vous que le moniteur et le cordon de l'adaptateur sont toujours hors de portée des enfants, à au moins 1 mètre (3 pieds) de l'enfant ou du berceau, pour éviter tout risque de strangulation.</div></div> <div><div>5</div><div>Né jamais placer le moniteur à l'intérieur du berceau ou du parc de bébé. Ne jamais couvrir le moniteur ou l'unité (s) portative avec un article tel une serviette ou une couverture.</div></div> <div><div>6</div><div>D'autres équipements électroniques peuvent produire des interférences sur votre moniteur vidéo et audio. Tenté d'installer votre moniteur vidéo ou audio à l'écart des appareils électroniques tels que des routeurs sans fil, radios, téléphones cellulaires, interphones, moniteurs, téléphones, ordinateurs personnels, électromagnétiques et téléphones sans fil.</div></div>	
---	--

Stimulateurs cardiaques implantés dans l'organisme <p>Les stimulateurs cardiaques (ne s'applique qu'aux dispositifs numériques sans fil) : L'organisme "Wireless Technology Research, LLC (WTR)", une firme de recherche indépendante, a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans fil portatifs et les stimulateurs cardiaques implantés dans l'organisme. Appuyée par l'Administration des aliments et drogues (FDA) des États-Unis, la firme WTR recommande aux médecins :</p>	
---	--

Avis aux détenteurs de stimulateurs cardiaques <ul style="list-style-type: none">Vous devriez maintenir les dispositifs sans fil à au moins six pouces du stimulateur cardiaque.Il ne doivent PAS placer le téléphone sans fil directement sur le stimulateur cardiaque, tel que dans une poche de chemise, lorsque celui-ci est en marche. L'étude effectuée par l'organisme WTR n'a pas identifié de risque pour les détenteurs de stimulateurs cardiaques causés par les gens qui utilisent des téléphones sans fil à proximité de leur corps.	
Champs électromagnétiques (EMF) <p>Ce produit de VTech est conforme à toutes les normes se rapportant aux champs électromagnétiques (EMF) standard. Si vous le manipulez correctement en suivant les instructions de ce guide, son utilisation sera sécuritaire pendant de nombreuses années, selon les meilleures évidences scientifiques dont nous disposons aujourd'hui.</p>	

Temperature

too high at CAM #

The temperature detected by the baby unit is higher/lower than the desired temperature alert range.

Temperature

too low at CAM #

The parent unit is turning on.

Powering on...

The parent unit is searching for baby units.

Auto Timer of lullaby is reset

The timer that determines the remaining play time for the lullabies is restarted.

AC power

The parent unit has just been connected to AC power.

No link to CAM #

The selected baby unit is out of range or is turned off.

Battery low at Parent Unit

The battery level of the parent unit is very low and needs to be recharged.

Battery empty. Powering off ...

The battery is empty and needs to be recharged.

Sound detected at CAM #

The sound level exceeds the threshold at CAM # in **Split** mode.

NIGHT VISION

The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and appears on the screen.

NOTES <ul style="list-style-type: none">It is normal if you see a short white glare on your parent unit screen as the baby unit is adapting to the dark environment.When the infrared LEDs are on, the images are in black and white. This is normal.
TIP <ul style="list-style-type: none">Depending on the surroundings and other interfering factors, like lightnings, objects, colors and backgrounds, the video quality may vary. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.

MOUNT THE BABY UNIT (OPTIONAL)

Your baby monitor comes ready for tabletop use. You can also choose to mount your baby monitor on the wall. See Mount the baby unit on dry wall (optional) in the **Quick Start Guide** for the wall mounting instructions.

GENERAL PRODUCT CARE

To keep this product working well and looking good, follow these guidelines:
<ul style="list-style-type: none">Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).DO NOT expose it to direct sunlight or moisture.Avoid dropping the product or treating it roughly.Clean with a soft cloth.DO NOT immerse the parent unit and the baby unit in water and do not clean them under the tap.DO NOT use cleaning spray or liquid cleaners.Make sure the baby unit and parent unit are dry before you connect them to the mains again.

LIMITED WARRANTY

What does this limited warranty cover? <p>The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.</p> <p>What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?</p> <p>During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or replacement to take approximately 30 days.</p> <p>How long is the limited warranty period?</p> <p>The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective product under the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repair or replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer.</p> <p>What is not covered by this limited warranty?</p> <p>This limited warranty does not cover:</p> <div><div>1</div><div>Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion, or</div></div> <div><div>2</div><div>Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or</div></div> <div><div>3</div><div>Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or</div></div> <div><div>4</div><div>Product to the extent that the problem is caused by use with non-VTech accessories; or</div></div> <div><div>5</div><div>Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or</div></div> <div><div>6</div><div>Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or rental purposes (including but not limited to Products used for rental purposes); or</div></div> <div><div>7</div><div>Product returned without a valid proof of purchase (see item 2 below); or</div></div> <div><div>8</div><div>Charges for installation or set up, adjustment of customer controls, or installation or repair of systems outside the unit.</div></div> <p>How do you get warranty service?</p> <p>To obtain warranty service in the USA, please visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.</p> <p>NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may solve your problem.</p> <p>Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no responsibility for damage or loss of the Product in transit. If the Product is covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.</p> <p>What must you return with the Product to get warranty service?</p> <div><div>1</div><div>Return the entire original package and contents, including the Product to the VTech service location along with a description of the malfunction or difficulty; and</div></div> <div><div>2</div><div>Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and</div></div> <div><div>3</div><div>Provide your name, complete and correct mailing address, and telephone number.</div></div> <p>Other limitations</p> <p>This warranty is the complete and exclusive agreement between you and VTech. It supercedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification. State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province. Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.</p> <p>Please retain your original sales receipt as proof of purchase.</p>	
--	--