Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news.

VC7100 DECT 6.0 accessory handset for use with VTech models VC7151/VC7152





vtech

User's manual

Congratulations

on purchasing your new VTech product. Before using this product, please read Important safety instructions.

This manual has instructions on how to set up and register your new handset. For instructions on using the handset, see the Abridged user's manual that came with your telephone base.

You may also view or download the online User's manual for a full set of installation and operation instructions at www.vtechphones.com. In Canada, visit

www.vtechcanada.com.




Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.

What's in the box

Your product package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary









Install the battery

• If the handset will not be used for a long time,

· To purchase a replacement battery, visit our

1 (800) 595-9511. In Canada, go to

www.vtechcanada.com or call

website at www.vtechphones.com or call

disconnect and remove the battery to prevent

Install the battery as shown below.

Use only supplied battery.

possible leakage.

1 (800) 267-7377.


- · Use only the adapters provided.

Connect the charger

Connect


MNOTES

· The adapters are intended for a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table, or cabinet outlet.



Charge the battery

Once you have installed the battery, the battery indicators show the battery status (see the following table).



ONOTES

- For best performance, keep the handset in the charger when not in use.
- · The battery is fully charged after 12 hours of continuous charging

The following table summarizes the battery charge indicators and actions to take.

Battery indicators	Battery status	Action
The screen is blank, or shows Place in charger and \Rightarrow flashes.	The battery has no charge or very little charge. The handset cannot be used.	Charge without interruption (at least 30 minutes).
The screen shows Low battery and □ flashes.	The battery has enough charge to be used for a short time.	Charge without interruption (at least 30 minutes).
The screen shows HANDSET X.	The battery is charged.	To keep the battery charged, place it in the telephone base or charger when not in use.

Before use

Add and register a handset

You can add new VC7100 cordless handset to your **VC7151** telephone system, Your telephone system supports a maximum of five handsets.

Register each handset with the telephone base before use. After charged, each expansion handset alternately displays To register HS, see manual. Charge the handset for at least 30 minutes before registering it to the telephone base.

To register a handset:

 Place the new/non-registered handset in the telephone base. The handset and telephone base show Registering... Please

The handset and telephone base show HANDSET X registered and you hear a beep when the registration process completes. The registration process takes about 90 seconds to complete.

Deregister all devices

To replace a handset or reassign the designated handset number of a registered handset, you must deregister all devices and then individually register each handset.

To deregister all devices:

- Press and hold /FIND HANDSET on the telephone base for about 10 seconds, when the telephone base shows Deregister all devices?.
- 2. Press YES or press //FIND HANDSET again within 2 seconds

The telephone base shows **Deregistered all** devices. All handsets show To register HS, **see manual.** when the deregistration process completes. The deregistration process takes about 10 seconds to complete.

Check for dial tone:

Press or on the handset or on the telephone base. If you hear a dial tone, the installation is successful.

If you do not hear a dial tone:

- Make sure the installation procedures described above are properly done.
- It may be a wiring problem. If you have changed your telephone service to digital service from a cable company or a VoIP service provider, the telephone line may need to be rewired to allow all existing telephone jacks to work. Contact your cable/VoIP service provider for more information.


Operating range

This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office.

When the handset is out of range, the handset displays Out of range OR no power at base and Put HS on base to power base alternately.

If there is a call while the handset is out of range, it may not ring, or if it does ring, the call may not connect well when you press or . Move closer to the telephone base, and then press or to answer the call. If the handset moves out of range during a telephone conversation, there may be interference. To improve reception, move closer to the telephone base.

Handset overview



1 - CHARGE light

2 - LCD display

3 - Right Soft key

- Press to review the sensor status when the phone is not in use. While in a menu, press to select a
- menu item; or save an entry or setting.

Left Soft key

• Press to enter the sensor mode menu when the phone is not in use. Press to return to the previous menu.

- 4 REDIAL/PAUSE
- Press repeatedly to review the redial list. • Press and hold to insert a dialing pause while entering a number.

5 - M/TALK/FLASH

- Make or answer a call.
- Press to put the current call on hold when you receive an incoming call.
- Answer an incoming call when you hear a call waiting alert.

Dialing keys

· Press to enter numbers or characters.

- Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the phonebook.
- Press and hold to set or dial your

· While you have set the dial mode to pulse and on a call, press to switch to tone dialing temporarily.

Oober

 Press to add a space when entering names.

- Press and hold to enter quiet mode setting menu
- Press repeatedly to show other dialing options when reviewing a caller ID log

- Make or answer a call using the handset speakerphone
- During a call, press to switch between the speakerphone and the earpiece.

8 – MUTE/DELETE

- Mute the microphone during a call.
- While editing names or numbers, press to delete a digit or character, or press and hold to delete all digits or characters
- Delete the playing message on the handset
- · Silence the ringer temporarily while the handset is ringing.

(PTT) menu to begin a PTT call when

the phone is not in use

- Press and hold while talking in a PTT

11 - MENU/SELECT

 While in a menu, press to select an item; or save an entry or setting.

12 - VOLUME/^/◎

- · Review the phonebook when the phone is not in use
- Increase the listening volume during a call or message playback.
- · Scroll up while in a menu, or in the phonebook, caller ID log, or redial list.

Move the cursor to the right when entering numbers or names

Review the caller ID log when the

- phone is not in use
- Scroll down while in a menu, or in the phonebook.
- caller ID log, or redial list. Move the cursor to the left when entering numbers or names.


13 - OFF/CANCEL

- Hang up a call. Silence the ringer temporarily while the handset is ringing.
- Press and hold to erase the missed call indicator while the phone is not in use.
- Press to return to the previous menu, or press and hold to return to idle mode. without making changes

14 - ARM/DISARM

 Press to turn on or off the sensor alert 15 - Microphone

Charger overview



1 - Charging pole

ECO mode

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.

General product care

Your cordless telephone contains sophisticated electronic parts, so it must be treated with care. Avoid rough treatment

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it. Avoid water

Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms.

Electrical storms

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use dampened cloth or cleaning solvents of any kind.

When you are not going to use the handset for some time, remove the rechargeable battery from the handset. Store the handset, the charger and the adapter in a cool and dry place.

Important safety instructions

injury, including the following 1. Read and understand all instructions.

- 3. Unplug this product from the wall outlet before cleaning. Do not use liquid or
- 4. Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or a swimming pool, or in a wet basement or shower.
- Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area
- the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power
- 8. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on. 9. Never push objects of any kind into this
- product through the slots in the telephone base or handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.

10. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is

- subsequently used 11. Do not overload wall outlets and extension
- 12. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
- When the power supply cord or plug is damaged or fraved
- If liquid has been spilled onto the product. If the product has been exposed to rain
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product to
- normal operation. If the product has been dropped and the telephone base and/or handset has been damaged.
- If the product exhibits a distinct change in performance
- 13. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from
- 14. Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the wall outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a wall outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might

include: medical use of oxygen without

- adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
- 15. Only put the handset of your telephone next to your ear when it is in normal talk mode.
- 16. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or
- cabinet outlet. 17. Use only the adapters included with this product. Incorrect adapter polarity or voltage can seriously damage the product. LPS or Class 2 Charger adapter: Input 100-240V AC 150mA 50/60Hz; Output: 6V

DC 400mA **SAVE THESE INSTRUCTIONS**

- **Battery** CAUTION: Use only the batteries indicated in this manual. There may be a risk of explosion if a wrong type of battery is used for the handset. Use only the supplied rechargeable battery or replacement battery pack (BT183342/BT283342) for the handset.
- Do not dispose of batteries in a fire. They may explode. Dispose of used batte according to the information in The RBRC® Do not dispose of the battery in a fire. Check

with local waste management codes for

- special disposal instructions. Do not open or mutilate the battery. Released electrolyte is corrosive and may cause burns or injury to the eyes or skin.
- The electrolyte may be toxic if swallowed. Exercise care in handling batteries in order not to create a short circuit with conductive

Charge the battery provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.

Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital

an independent research entity, led a

cordless telephones): Wireless Technology Research, LLC (WTR),

multidisciplinary evaluation of the interference

between portable wireless telephones and

interference Rechargeable batteries: Exercise care in

the U.S. Food and Drug Administration, WTR recommends to physicians that: **Pacemaker patients**

implanted cardiac pacemakers. Supported by

- Should keep wireless telephones at least six inches from the pacemaker Should NOT place wireless telephones
- breast pocket, when it is turned ON. · Should use the wireless telephone at the ear opposite the pacemaker.

directly over the pacemaker, such as in a

WTR's evaluation did not identify any risk to bystanders with pacemakers from other

persons using wireless telephones. **About cordless telephones**

on corded telepho

- **Privacy:** The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason. you should not think of cordless telephone conversations as being as private as those
- Electrical power: The telephone base of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.
- Potential TV interference: Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR often reduces or eliminates the
- handling batteries in order not to create a short circuit with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.

9 – Earpiece

- 10 PUSH TO TALK • Press to display the PUSH TO TALK
- Press and hold to begin a one-to-group

- VOLUME/~/CID
- · Decrease the listening volume during a call or message playback.

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

Cleaning your telephone

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and

- 2. Follow all warnings and instructions marked on the product.
- aerosol cleaners. Use a dry non-abrasive cloth for cleaning.
- where proper ventilation is not provided. This product should be operated only from company

• Nickel-metal hydride rechargeable batteries: Dispose of these batteries in a safe manner. Do not burn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury

The RBRC® seal

The RBRC® seal on the nickel-metal hydride battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada

The RBRC® program provides a convenient alternative to placing used nickel-metal hydride batteries into the trash or municipal waste, which may be illegal in your area.

VTech's participation in RBRC® makes it easy for you to drop off the spent battery at local retailers participating in the RBRC® program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY® for information on Ni-MH battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

RBRC® and 1 (800) 8 BATTERY® are registered trademarks of the Rechargeable Battery Recycling Corporation.



FCC and IC regulations

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

connected.

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment
- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of Communications may not be ensured when using this phone.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystande according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The base shall be installed and used such that parts of all persons' body are maintained at a distance of approximately 8 in (20

This Class B digital apparatus complies with Canadian requirement CAN ICES-3 (B)/NMB-3(B)

FCC Part 68 and ACTA

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXXX. This identifier must be provided to your telephone service provider upon request.

The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See the

installation instructions in the user's manual. The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your telephone service provider.

This equipment may not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone service provider or a qualified installer.

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents. For repair procedures, follow the instructions outlined under the Limited warranty. If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned. If this product is equipped with a corded or cordless handset, it is hearing aid compatible.

If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please: Remain on the line and briefly explain the reason for the call before hanging up. Perform such activities in off-peak hours, such as

Industry Canada

This device complies with Industry Canada licence-exempt RSS standard(s).

early morning or late evening.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this telephone

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five. This product meets the applicable Industry Canada

technical specifications.

RF radiation exposure statement

The handset complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The base should be installed and operated with a minimum distance of 8 in (20 cm) between the handset and all persons' body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposure of Humans to RF Fields

California Energy Commission battery charging testing instructions

This telephone is set up to comply with the energy-conserving standards right out of the box. These instructions are intended for California Energy Commission (CEC) compliance testing only. When the CEC battery charging testing mode is activated, all telephone functions, except battery

charging, will be disabled. When first purchased and properly installed for charging (see **Install the battery**), put the handset on the charger to charge. The CEC battery charging testing mode is activated while charging

If you have registered the handset to a telephone base, below are the testing instructions.

To activate the CEC battery charging testing mode: 1. Unplug the telephone base power adapter from the wall outlet. Make sure all handsets are plugged

- with charged batteries before proceeding 2. While you press and hold diffIND HANDSET, plug the telephone base power adapter back to the wall
- 3. After about 20 seconds, when the IN USE light starts flashing, release **//FIND HANDSET** and then press it again within 2 seconds.

When the phone successfully enters the energy conserving mode, all cordless handset screens display To register HS, see manual. When the phone fails to enter the CEC battery charging testing mode, repeat Step 1 through Step 3 above.

· The telephone base will be powered up as normal 9. N'insérez jamais d'objets à travers les fentes if you fail to press **I/FIND HANDSET** within 2 seconds in Step 3.

8. Ne déposez rien sur le cordon d'alimentation

sécuritaire, là où personne ne pourra trébucher

et ouvertures de cet appareil, car ils pourraient

toucher à des points de tension dangereux ou

court-circuiter des pièces, ce qui constituerait

N'échappez pas de liquides dans l'appareil.

10. Afin de réduire les risques d'électrocution, ne

à un centre de service qualifié s'il doit être

réparé. En enlevant le couvercle, vous vous

dangers similaires. Un remontage inadéquat

peut être à l'origine d'une électrocution lors

Débranchez l'appareil avant de procéder au

11. Ne surchargez pas les prises de courant et les

12. Débranchez cet appareil de la prise de courant

service à la clientèle de VTech dans les cas

Si du liquide a été échappé dans l'appareil.

normalement en respectant les instructions

de fonctionnement. Réglez uniquement

pourraient provoquer un dommage qui

réglages incorrects des autres commandes

pourrait exiger un travail exhaustif de la part

d'un technicien autorisé afin de rétablir le

les commandes indiquées dans le les

instructions de fonctionnement. Les

fonctionnement normal de l'appareil

et/ou le combiné a été endommagé.

13. Évitez d'utiliser un téléphone (autre qu'un sans

14. N'utilisez pas le téléphone pour rapporter une

circonstances, une flammèche pourrait être

sa performance.

l'origine d'une électrocution

• Si le produit a été échappé et que le socle

• Si le produit affiche une nette diminution de

fil) pendant un orage. Les éclairs peuvent être à

fuite de gaz à proximité de la fuite. En certaines

Si l'appareil a été exposé à une source

d'humidité telle que la pluie ou l'eau.

et communiquez avec le département de

Lorsque le cordon d'alimentation est

endommagé ou écorché.

Si le produit ne fonctionne pas

rallonges.

nettoyage. Utilisez un chiffon humide et doux.

d'une utilisation ultérieure de l'appareil.

exposez à des tensions dangereuses ou autres

démontez pas l'appareil, mais apportez-le plutôt

un risque d'incendie ou d'électrocution.

Installez cet appareil dans un endroit

sur la ligne d'alimentation ni le cordon

téléphonique modulaire.

To deactivate the CEC battery charging testing

- 1. Unplug the telephone base power adapter from the wall outlet, then plug it back in. Then the telephone base is powered up as normal.
- Register your handsets back to the telephone base. Refer to the Add and register a handset

For C-UL and cETL compliance only

Mesures de sécurité importantes

Afin de réduire les risques d'incendie, de blessures corporelles ou d'électrocution, suivez touiours ces mesures préventives de base lorsque vous utilisez votre téléphone

- Lisez et comprenez bien toutes les instructions.
- 2. Observez toutes les instructions et mises en garde inscrites sur l'appareil.
- 3. Débranchez ce téléphone de la prise murale avant de le nettoyer. N'utilisez pas de nettoyeurs liquides ni en aérosol. N'utilisez qu'un chiffon doux et légèrement humecté.
- 4. N'utilisez pas ce produit près de l'eau, tel que près d'un bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage ou d'une piscine, ou dans un sous-sol humide ou sous la douche.
- 5. Ne déposez pas ce téléphone sur un chariot, support ou table chancelants. L'appareil pourrait tomber et être sérieusement endommagé
- 6. Le boîtier de l'appareil est doté de fentes et d'ouvertures d'aération situées à l'arrière ou en dessous. Afin d'empêcher la surchauffe, ces ouvertures ne doivent pas être obstruées en plaçant l'appareil sur un lit, divan, tapis ou autre surface similaires. Ne placez pas cet appareil à proximité d'un élément de chauffage ni d'une plinthe électrique. De plus, ne l'installez pas dans une unité murale ou un cabinet fermé qui ne possède pas d'aération adéquate.
- Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur les étiquettes de l'appareil. Si vous ne connaissez pas le voltage de votre maison, consultez votre marchand ou votre fournisseur d'électricité.

- provoquée lorsque l'adaptateur est branché à une prise de courant, ou lorsque le combiné est déposé sur le socle. Ceci est un événement commun associé à la fermeture d'un circuit électrique. L'utilisateur ne devrait pas brancher le téléphone à une prise de courant, et ne devrait pas déposer le combiné chargé sur le socle, si le téléphone se trouve à proximité d'un endroit comportant des concentrations de gaz inflammables, à moins que la ventilation soit adéquate. Une flammèche dans un tel endroit pourrait provoquer un incendie ou une explosion. De tels environnements peuvent comprendre: des endroits où l'on utilise de l'oxygène médical sans ventilation adéquate
- 15. Ne placez que le combiné de votre téléphone près de votre oreille lorsqu'en mode de conversation.

naturel, etc.

des gaz industriels (dissolvants de nettoyage,

des vapeurs d'essence, etc.); une fuite de gaz

- Ces adaptateurs ont été conçus pour être orientés en position verticale ou montés au • Ils ne doivent PAS placer le téléphone sans fil sol. Les broches ne sont pas concues pour maintenir l'adaptateur en place si celui-ci est barnché dans une prise au plafond ou sous une table/armoire. Ils doivent utiliser le téléphone sans fil en
- 16. N'utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril. LPS ou Classe 2 Adaptateur du chargeur Entrée 100-120V CA 150 mA 50/60 Hz; Sortie: 6 V CC 400 mA **CONSERVEZ CES INSTRUCTIONS**

- MISE EN GARDE: Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour le combiné. N'utilisez que le bloc-piles rechargeable inclus ou le bloc-piles de rechange (BT183342/BT283342).
- N'incinérez pas les piles. Celles-ci risqueraient d'exploser. Jetez les piles usées selon les renseignements suivant le sceau du RBRC™D
- N'ouvrez pas et ne mutilez pas la pile L'électrolyte qui s'en échapperait est corrosif et pourrait causer des brûlures ou des blessures aux yeux ou à la peau. L'électrolyte est toxique si Sovez prudents lorsque vous manipulez les piles
- afin d'éviter les courts-circuits provoqués par des matériaux conducteurs.

Stimulateurs cardiaques implantés dans l'organisme Les simulateurs cardiaques (s'applique uniquement aux téléphones numériques sans fil):

L'organisme 'Wireless Technology Research, LLC (WTR)', une firme de recherche indépendante, a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans fil portatifs et les stimulateurs cardiagues implantés dans l'organisme. Appuyée par l'Administration des aliments et drogues (FDA) des États-Unis, la firme WTR recommande aux médecins:

Rechargez la pile incluse avec cet appareil, selon

les instructions et limites spécifiées dans ce guide

Avis aux détenteurs de stimulateurs cardiaques

- Ils doivent tenir le téléphone sans fil à une distance d'au moins six pouces du stimulateur cardiaque.
- directement sur le stimulateur cardiaque, tel que dans une poche de chemise, lorsque celui-ci est
- l'appuyant sur l'oreille qui se trouve dans la direction opposée au stimulateur cardiaque

L'étude effectuée par l'organisme WRS n'a pas identifié de risque pour les détenteurs de simulateurs cardiaques causés par les gens qui utilisent un téléphone sans fil à proximité de ceux-ci.

À propos des téléphones sans fil

- Alimentation électrique: Les mêmes caractéristiques qui constituent des avantages pour les téléphones sans fil affichent également des restrictions. Les appels téléphoniques sont transmis entre le combiné sans fil et le socle par le biais d'ondes radio ; il y a donc la possibilité que vos conversations téléphoniques sans fil soient interceptées par des équipements de réception radio se trouvant dans la portée du combiné sans fil. Pour cette raison, vous ne devez pas percevoir les communications téléphoniques sans fil comme étant aussi confidentielles.
- Alimentation électrique: Le socle de ce téléphone sans fil doit être branché à une prise électrique fonctionnelle. La prise électrique ne doit pas être contrôlée par un interrupteur mural. Les appels ne pourront pas être effectués du combiné sans fil si le socle est débranché ou mis hors tension ou si le courant est coupé.

Possibilité d'interférences aux téléviseurs:

- Certains téléphones sans fil fonctionnent sur des fréquences pouvant causer des interférences aux téléviseurs et aux magnétoscopes. Pour réduire ou prévenir de telles interférences, ne placez pas le socle du téléphone sans fil près ou sur un téléviseur ou magnétoscope. S'il y a présence de parasites, il est conseillé d'éloigner le téléphone sans fil du téléviseur ou du magnétoscope afin de réduire possiblement les interférences.
- Piles rechargeables: Manipulez les piles avec soin afin de ne pas les court-circuiter avec des bagues, bracelets ou clés. Les piles ou le conducteur peut surchauffer et causer des blessures. Respectez la polarité adéquate entre la pile et le chargeur.
- Les bloc-piles rechargeables à l'hydrure métallique de nickel: Jetez ces blocs-piles de manière écologique et sécuritaire. Ne les incinérez pas et ne les percez pas. Tel que les autres piles de ce type, elles pourraient dégager une matière toxique qui peut causer des blessures corporelles si elles sont brûlées ou percées

Limited warranty

What does this limited warranty cover?

the holder of a valid proof of purchase ("Consumer" of "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

The manufacturer of this VTech Product warrants to

What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?

During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or replacement to take approximately 30 days.

How long is the limited warranty period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to vou or (b) the time remaining on the original one-year warranty; whichever is longer.

What is not covered by this limited warranty?

This limited warranty does not cover:

- Product that has been subjected to misuse. accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion: or
- 2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or
- 3. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or Product to the extent that the problem is caused
- by use with non-VTech accessories; or 5. Product whose warranty/quality stickers, product serial number plates or electronic serial numbers
- have been removed, altered or rendered illegible; or 6. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
- 7. Product returned without a valid proof of purchase (see item 2 on the next column); or 8. Charges for installation or set up, adjustment of
- customer controls, and installation or repair of systems outside the unit.

How do you get warranty service? To obtain warranty service in the United States of

America, please visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or dial 1 (800) 267-7377.

NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation exclusion may not apply to you. and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product as proof of purchase. under this limited warranty. Transportation, delivery

or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty. or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.

What must you return with the Product to get warranty service?

- 1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or
- Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- Provide your name, complete and correct mailing address, and telephone number.

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or

Please retain your original sales receipt

Technical specifications

Frequency control	Crystal controlled PLL synthesizer	
Transmit frequency	1921.536-1928.448 MHz	
Channels	5	
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environment conditions at the time of use.	
Power requirements	Handset: 2.4V 400mAH 2xAAA Ni-MH battery Charger: 6V DC @ 400mA	

50 memory locations, up to

30 digits and 15 characters

50 memory locations; up to 24 digits

Phonebook:

Caller ID log:

and 15 characters

Designed to fit your home. VTech Communications, Inc.

A member of THE VTECH GROUP OF COMPANIES. VTech is a registered trademark of VTech Holdings Limited. Specifications are subject to change without notice. Copyright © 2015 for VTech Communications, Inc. All rights reserved. 08/15. VC7100_CIB_V2.0 Document order number: 91-007933-020-100

