

Go to [www.vtechphones.com](http://www.vtechphones.com) to register your product for enhanced warranty support and the latest VTech product news.

CS6859  
CS6859-2  
CS6859-3  
CS6859-4  
DECT 6.0 cordless telephone



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.



**vtech**


Abridged user's manual

**Congratulations**


on purchasing your new VTech product. Before using this product, please read **important safety instructions**. This abridged user's manual provides you with basic installation and use instructions. A limited set of features are described in abbreviated form. Please refer to the online User's manual for a full set of installation and operation instructions at [www.vtechphones.com](http://www.vtechphones.com).

**What's in the box**

Your product package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.



**Handset overview**



- 1 – Handset earpiece
- 2 – LCD display
- 3 – MENU/SELECT
  - Show the menu.
  - While in a menu, press to select an item, or save an entry or setting.
- 4 – OFF/CANCEL
  - Hang up a call.
  - Silence the ringer temporarily while the handset is ringing.
  - Press and hold to erase the missed call indicator while the phone is not in use.
  - Press to return to the previous menu; or press and hold to return to idle mode, without making changes.
- 5 – QUIET#
  - Press repeatedly to show other dialing options when reviewing a caller ID log entry.
- 6 – INT
  - Press to start an intercom conversation or transfer a call (for multi-handset models only).

**7 – Microphone**

- Make or answer a call using the handset speakerphone.
- During a call, press to switch between the speakerphone and the handset.

**9 – MUTE/DELETE**

- Mute the microphone during a call.
- Delete digits or characters while using the dialing keys.
- Silence the ringer temporarily while the handset is ringing.

**10 – TONE X**

- While you have set the dial mode to pulse and on a call, press to switch to tone dialing temporarily.

**11 – OPER 0**

- Press to add a space when entering names.

**12 – 1**

- Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the directory.
- Press and hold to set or dial your voicemail number.

**13 – TALK FLASH**

- Make or answer a home call.
- Answer an incoming home call when you hear a call waiting alert.

**14 – REDIAL/PAUSE**

- Review the directory when the phone is not in use.
- Increase the listening volume during a call.
- Scroll up while in a menu, or in the directory, caller ID log, or redial list.
- Move the cursor to the right when entering numbers or names.


**VOLUME/VOL**

- Review the caller ID log when the phone is not in use.
- Decrease the listening volume during a call.
- Scroll down while in a menu, or in the directory, caller ID log, or redial list.
- Move the cursor to the left when entering numbers or names.

**16 – CHARGE light**

- On when the handset is charging.

**Telephone base overview**



**1 – LCD display**

- Flashes when there is an incoming call, or another telephone sharing the same line is in use.
- On when the handset is in use.

**3 – MENU/SELECT**

- Show the menu.
- While in a menu, press to select an item, or save an entry or setting.

**FLASH**

- Answer an incoming home call when you hear a call waiting alert.
- Review the directory when the phone is not in use.
- Scroll up while in a menu, or in the directory, caller ID log, or redial list.
- Move the cursor to the right when entering numbers or names.

**CID**

- Review the caller ID log when the phone is not in use.
- Scroll down while in a menu, or in the directory, caller ID log, or redial list.
- Move the cursor to the left when entering numbers or names.


**OFF/CANCEL**

- Press and hold to erase the missed call indicator while the phone is not in use.
- Press to return to the previous menu; or press and hold to return to idle mode, without making changes.

**4 – X/DELETE**

- Press to delete the playing message.
- When the phone is not in use, press twice to delete all previously reviewed messages.
- Press to repeat the playing message.
- Press twice to play the previous message.

**Charger overview**



**1 – Charging pole**

**Display icons overview**

**Handset icons**

	The battery icon flashes when the battery is low and needs charging.
	The battery icon animates when the battery is charging.
	The battery icon becomes solid when the battery is fully charged.
	The handset ringer is off.
	There are new voicemail received from your telephone service provider.
	The ECO mode activates automatically to reduce power consumption when the handset is within range from the telephone base.
	There are new caller ID log entries.

**Telephone base icons**

	The telephone base ringer is turned off.
	There are new voicemail received from the telephone service provider.
	The message number currently playing, or the total number of messages recorded.
	The caller ID log entry you are reviewing is new. The message you are listening is new.

**Lights overview**

**Handset lights**

	On when the handset speakerphone is in use.
	On when the handset is charging in the telephone base or handset charger.

**Telephone base lights**

	On when the telephone line is in use. On when you are registering a handset. Flashes quickly when there is an incoming call. Flashes when another telephone sharing the same line is in use. Flashes when you are deregistering all handsets.
	On when the answering system is turned on.
	On when the mute function is turned on during a call.
	Flashes when there are new messages or memos in the answering system.
	On when the telephone base speakerphone is in use.

**Connect**

You can choose to connect the telephone base for desktop usage or wall mounting.


- Use only the adapters provided.
- Make sure the electrical outlets are not controlled by wall switches.
- The adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

**Mount the telephone base**

1. Unplug the telephone line cord (or the DSL filter) from the telephone wall jack. Unplug the power adapter from the electrical outlet. Slide the wall mount bracket up and remove it from the wall mount plate.
2. Press down on the tabs on the wall mount bracket on the telephone base to release it from tabletop orientation. Rotate the wall mount bracket down to wall mount position and then push it into the telephone base until it clicks into place.

**Install and charge the battery**

3. Plug the telephone line cord (or DSL filter) into the wall jack. Align the holes on the back of the telephone base with the standard wall plate. Slide the bracket down until it clicks securely in place. Connect the power adapter to the telephone base and an electrical outlet not controlled by a wall switch.



**Charge the battery**

Place the handset in the telephone base or the charger to charge.



**Before use**

After you install your telephone or power returns following a power outage, the handset or telephone will prompt you to set the date and time.

**Set date and time**

- Make sure you set the date and time including the year correctly; otherwise the answering system does not announce the correct day of the week for your recorded messages time stamp.
1. Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press SELECT.
  2. Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press ▼ or ▲ to choose AM or PM.
  3. Press SELECT to save.

**Check for dial tone:**

Press TALK FLASH. If you hear a dial tone, the installation is successful.

**If you do not hear a dial tone:**

- Make sure the installation procedures described above are properly done.
- It may be a wiring problem. If you have changed your telephone service to digital service from a cable company or a VoIP service provider, the telephone line may need to be rewired to allow all existing telephone jacks to work. Contact your cable/VoIP service provider for more information.

**Operating range**

This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance - which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office. When the handset is out of range, the handset displays **Out of range** or **no pwr at base**. If there is a call while the handset is out of range, it may not ring, or if it does ring, the call may not connect well when you press TALK FLASH. Move closer to the telephone base, and then press TALK FLASH to answer the call. If the handset moves out of range during a telephone conversation, there may be interference. To improve reception, move closer to the telephone base.

**Using the menu**

1. Press MENU when the handset or telephone base is not in use.
2. Press ▼ or ▲ until the screen displays the desired feature menu.
3. Press SELECT to enter that menu.
- To return to the previous menu, press CANCEL.
- To return to idle mode, press and hold CANCEL.

**Configure your telephone**

**Set language**

The LCD language is preset to English. You can select English, French or Spanish to be used in all screen displays.

1. Press MENU when the handset is not in use.
2. Scroll to Settings, and then press SELECT twice.
3. Scroll to choose English, Français or Español, and then press SELECT.
4. Press SELECT again to save.

**Set date and time**

Make sure you set the date and time including the year correctly; otherwise the answering system does not announce the correct day of the week for your recorded messages time stamp.


1. Press MENU when the handset is not in use.
2. Scroll to Set date/time, and then press SELECT.
3. Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press SELECT.
4. Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press ▼ or ▲ to choose AM or PM.
5. Press SELECT to save.

**Temporary tone dialing**

If you have pulse (rotary) service only, you can switch from pulse to tone dialing temporarily during a call.

1. During a call, press TONE X.
2. Use the dialing keys to enter the relevant number. The telephone sends touch-tone signals. It automatically returns to pulse dialing mode after you end the call.

**Telephone operation**



**Make a call**

- Press TALK FLASH or MUTE, and then dial the telephone number.

**Answer a call**

- Press TALK FLASH, MUTE, or any dialing key.

**End a call**

- Press OFF on the handset, or put the handset to the base or charger.

**Speakerphone**

- During a call, press MUTE on the handset to switch between speakerphone and normal handset use.

**Volume**

- During a call, press ▼/VOLUME/▲ on the handset to adjust the listening volume.

**Mute**

The mute function allows you to hear the other party but the other party cannot hear you.

**Call waiting**

When you subscribe to call waiting service from your telephone service provider, you hear an alert tone if there is an incoming call while you are on another call.

**Find handset**

Use this feature to find all system handsets.

**To start paging:**

- Press MUTE/FIND HANDSET on the telephone base. All idle handsets ring and display \*\* Paging \*\*.

**To end paging:**

- Press MUTE/FIND HANDSET again on the telephone base.

**Transfer a call using intercom**

While on an outside call, you can use the intercom feature to transfer the call from one handset to another.

1. Press INT on your handset or telephone base during a call.
2. The current call is put on hold. Use the dialing keys to enter a destination handset number.
3. To answer the intercom call, press TALK FLASH, INT or any dialing key on the destination handset; or press MUTE/SPEAKER, INT or any dialing key (0-9, QUIET#, or TONE X) on the telephone base.
4. From this intercom call, you have the following options:
  - You can let the destination handset join you on the outside call in a three-way conversation. Press and hold INT on the originating handset.
  - You can transfer the call. Press OFF, or place your handset back in the telephone base or charger. Your handset displays Transferred. The destination handset is then connected to the outside call.
  - You can press INT to switch between the outside call (Outside call displays) and the intercom call (Intercom displays).
  - The destination handset can end the intercom call by pressing OFF, or by placing the handset back in the telephone base or charger. The outside call continues with the original system handset.

**Join a call in progress**

You can use up to two system handsets at a time on a home line call. You can buy additional expansion handsets (CS6709) for this telephone base. You can register up to five handsets to the telephone base.

- When a handset is on a home call, press TALK FLASH or MUTE on another handset to join the call.
- Press OFF to exit the call. The call continues until all handsets hang up.

**Transfer a call**

While on an outside call, you can transfer the call from one handset to another.

1. Press MENU on your handset during a call.
2. Scroll to Transfer, and then press SELECT.
3. Use the dialing keys to enter a destination handset number.
4. To answer the intercom call, press TALK FLASH, MUTE, INT or any dialing key on the destination handset, or press MUTE/SPEAKER, INT or any dialing key (0-9, QUIET#, or TONE X) on the telephone base.

**Intercom**

Use the intercom features for conversations between two devices.

1. Press INT on your handset or telephone base when not in use.
2. Use the dialing keys to enter a destination device number.
3. To answer the intercom call, press TALK FLASH, MUTE, INT or any dialing key on the destination handset; or press MUTE/SPEAKER, INT or any dialing key (0-9, QUIET#, or TONE X) on the telephone base.
4. To end the intercom call, press OFF or place the handset back in the telephone base or charger.

**Answer an incoming call during an intercom call**

If you receive an incoming call during an intercom call, there is an alert tone.

- To answer a call, press TALK FLASH. The intercom call ends automatically.
- To end the intercom call without answering the outside call, press OFF. The intercom call ends and the telephone continues to ring.

## Redial list

Each handset stores the last 10 telephone numbers dialed. When there are already 10 entries, the oldest entry is deleted to make room for the new entry.

#### Review the redial list

- Press **REDIAL** when the handset is not in use.
- Press **▼**, **▲**, or **REDIAL** repeatedly until the desired entry displays.

#### Dial a redial list entry

- Press **TALK** or **▶** to dial.

#### Delete a redial list entry

When the desired redial entry displays, press **DELETE**.

## Directory

The phonebook can store up to 50 entries, which are shared by all handsets. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.

#### Add a directory entry

- Press **MENU** when the phone is not in use.
- Scroll to **Directory** then press **SELECT**.
- Press **SELECT** again to choose **Add contact**.
- Enter the number.
  - Use the dialing keys to enter the number (up to 30 digits).
- Press **SELECT** to move to the name.
- Use the dialing keys to enter the name (up to 15 characters). Additional key presses show other characters of that particular key.
- Press **SELECT** to save.

**While entering numbers and names, you can:**

- Press **DELETE** to erase a digit or character.
- Press **and hold DELETE** to erase the entire entry.
- Press **▼** or **▲** to move the cursor to the left or right.
- Press **and hold PAUSE** to insert a dialing pause (for entering phone numbers only).
- Press **0** to add a space (for entering names only).
- Press **TALK** to add **\*** (**\*** appears) or **\*\*\*#** to add **#** (**#** appears) (for entering phone numbers only).

<b>*5</b>	Hear a list of remote commands.
<b>6</b>	Skip to the next message (during playback).
<b>*7</b>	Record a new announcement.
<b>8</b>	End the call.
<b>0</b>	Turn the answering system on or off.

- Hang up or press **8** to end the call.

#### Remote access code

A two-digit security code is required to access the answering system remotely from any touch-tone telephone. The preset code is **19**. You can set the code from **00** to **99**.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **Remote code**, and then press **SELECT**.
- Use the dialing keys to enter a two-digit number.
  - OR-** Scroll to a desired two-digit number.
- Press **SELECT** to save and you hear a confirmation tone.

## Use the built-in answering system and voicemail service

You can use your answering system and voicemail service together by setting your answering system to answer before voicemail service answers as described below. To learn how to program your voicemail settings, contact your telephone service provider.

If you are on a call, or if the answering system is busy recording a message and you receive another call, the second caller can leave a voicemail message.

Set your answering system to answer calls at least two rings earlier than your voicemail service is set to answer. For example, if your voicemail service answers after six rings, set your answering system to answer after four rings. Some voicemail service providers may program the delay before answering calls in seconds instead of rings. In this case, allow six seconds per ring when determining the appropriate setting.

#### Review the directory

Entries are sorted alphabetically.

- Press **☺** when the phone is not in use.
- Scroll to browse through the directory, or use the dialing keys to start a name search (you can enter up to 3 characters for the search).
- When the desired entry appears, press **TALK** or **▶** to dial.

#### Dial a directory entry

- When the desired entry appears, press **TALK** or **▶** to dial.

#### Edit a directory entry

- When the desired entry displays, press **SELECT**.
- Use the dialing keys to edit the number, and then press **SELECT**.
- Use the dialing keys to edit the name, and then press **SELECT** to save.

#### Delete a directory entry:

- When the desired entry displays, press **DELETE**.
- When the screen displays **Delete contact?**, press **SELECT**.

## Speed dial

You can copy up to 9 directory entries into the speed dial locations (**0** and **2-9**) so that you can dial these numbers using fewer keys than usual.

The speed dial memory locations are stored in the telephone base and are shared by all handsets. Changes made to the speed dial entries on a handset apply to all.

#### Assign a speed dial entry

- Press **MENU** when the phone is not in use.
- Scroll to **Directory**, then press **SELECT**.
- Scroll to **Speed dial**, then press **SELECT**.
- Press **▼** or **▲** or the dialing keys (**0** or **2-9**) to choose the desired speed dial location.
- Press **SELECT**. The screen displays **Copy from DIR...** and then the first entry in the directory.
- Scroll to browse to the desired entry.
  - OR-** Use the alphabetical search to find the desired entry.

- Press **SELECT** to save. You hear a confirmation. The name (up to 12 characters) appears in the selected speed dial location.

NOTE

- If the directory is empty, when you press **SELECT** in Step 5, the screen displays **Directory empty**.
- If the speed dial location you selected is occupied, the new directory entry you selected replaces the old one. Take caution not to replace entries you do not wish to delete from the speed dial locations.

#### Reassign a speed dial entry

- Press **MENU** when the phone is not in use.
- Scroll to **Directory**, then press **SELECT**.
- Scroll to **Speed dial**, then press **SELECT**.
- Press **▼** or **▲**, or use the dialing keys to choose the speed dial location you want to reassign.
- Press **SELECT** twice. The screen displays **Reassign SD**.
- Press **SELECT**. The screen displays **Copy from DIR...** and then the first entry of the directory.
- Scroll to browse to the desired entry.
  - OR-** Use the alphabetical search to find the desired entry.
- Press **SELECT** to save. You hear a confirmation. The name (up to 12 characters) appears in the selected speed dial location.

- When the desired entry appears, press **TALK** or **▶** to dial.

When the speed dial location is empty, the screen displays the speed dial list. See **Assign a speed dial entry** to add a new entry.

#### Delete a speed dial entry

- Press **MENU** when the phone is not in use.
- Scroll to **Directory**, then press **SELECT**.
- Scroll to **Speed dial**, then press **SELECT**.
- Press **▼** or **▲**, or use the dialing keys to choose the desired speed dial location, then press **DELETE**. The screen displays **Clear SD #?**
- Press **SELECT** to confirm. You hear a confirmation tone.

NOTE

Deleting the speed dial entries does not affect the entries in the directory.

## Caller ID

If you subscribe to caller ID service, information about each caller appears after the first or second ring. If you answer a call before the caller information appears on the screen, it will not be saved in the caller ID log.

The caller ID log stores up to 50 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name.

If the telephone number has more than 15 digits, only the last 15 digits appear. If the name has more than 15 characters, only the first 15 characters are shown and saved in the caller ID log.

#### Review a caller ID log entry

- Press **CID** when the phone is not in use.
- Scroll to browse through the caller ID log. When the desired entry appears:
  - Press **#** repeatedly to show different dialing options.
  - Press **1** repeatedly if you need to add or remove 1 in front of the phone number.
  - Press **TALK** or **▶** to dial the displayed number.

### Dial a caller ID log entry

- When the desired entry appears, press **TALK** or **▶** to dial.

#### Save a caller ID log entry to the directory

- When the desired caller ID log entry displays, press **SELECT**.
- Scroll to **To Directory** then press **SELECT**.
- Use the dialing keys to modify the number, and then press **SELECT**.
- Use the dialing keys to modify the name, and then press **SELECT** to save.

- When the desired caller ID log entry displays, press **DELETE**.

#### Delete all caller ID log entries

- Press **MENU** when the phone is not in use. Scroll to **Caller ID log** and then press **SELECT**. Scroll to **Del all calls** and then press **SELECT** twice.

## Sound settings

#### Key tone

You can choose from different ringer tones.

- Press **MENU** when the handset is not in use.
- Scroll to **Settings**, and then press **SELECT**.
- Scroll to choose **Key tone**, and then press **SELECT**.
- Scroll to choose **On or Off**, and then press **SELECT** to save.

#### Ringer tone

You can choose from different ringer tones.

- Press **MENU** when the handset is not in use.
- Scroll to **Ringers**, and then press **SELECT**.
- Scroll to choose **Ringer tone**, and then press **SELECT**.
- Scroll to sample each ringer tone, and then press **SELECT** to save.

NOTE

If you turn off the ringer volume, you will not hear ringer tone samples.

#### Ringer volume

You can adjust the ringer volume level, or turn the ringer off.

- Press **MENU** when the handset is not in use.
- Scroll to **Ringers**, and then press **SELECT**.
- Press **SELECT** to choose **Ringer volume**.
- Scroll to adjust the volume, and then press **SELECT** to save.

NOTE

If the handset ringer volume is set to off, that handset is silenced for all incoming calls except paging tone.

#### Ringer volume (telephone base)

You can adjust the telephone base volume level by pressing **▼VOL-** or **▲VOL+** on the top of the telephone base when idle.

#### Temporary ringer silencing

When the telephone is ringing, you can temporarily silence the ringer of the handset without disconnecting the call. The next call rings normally at the preset volume.

- Press **OFF** or **MUTE** on the handset. The handset displays **🔇** and **Ringer muted** briefly.

#### Quiet mode

You can turn on the quiet mode for a period of time. During this period, all tones (except paging tone) and call screening are muted. When you turn on the quiet mode, the answering system turns on automatically.

- Press **and hold \*\*\*#** on the handset or telephone base when idle.
- Use the dialing keys (**0-9**) to enter the duration, and then press **SELECT** to save.


- To turn off the quiet mode, press **and hold \*\*\*#** on the handset or telephone base when idle.

## About answering system and voicemail service

For message recording, your telephone has a built-in answering system, and it also support voicemail service offered by your telephone service provider (subscription is required, and fee may apply).

The main differences between them are as follows:

Category	Built-in answering system	Voicemail from telephone service
Storage	Messages are stored in the telephone base.	Messages are stored in a server or system provided by your telephone service.
	Your messages will not be deleted automatically. You have to delete your messages manually.	Your messages may be automatically deleted after a period of time. Contact your telephone service provider for more details.
Method to retrieve messages	When you received new messages, the handset displays <b>XX new messages</b> and the message window on the telephone base flashes.	When you received new messages, the handset displays <b>📧</b> and <b>New voicemail</b> .
	To retrieve messages, usually there are two ways: <ul style="list-style-type: none"><li>Press a button on the telephone base; or</li> <li>Access remotely with an access code.</li></ul>	To retrieve messages, you need an access number and/or a passcode provided by your telephone service provider.



## Set your built-in answering system

Your answering system has various features, read below for the basic settings.

The answering system can record and store up to 99 messages. Each message can be up to three minutes in length. The total storage capacity for the announcement, messages and memos is approximately 14 minutes. The actual recording time depends on individual message characteristics.

Your answering system allows you to set your announcement, to save and delete messages, activate call screening, to set number of rings before pick up, to access remotely, and to control the recording time.

#### Turn the answering system on or off

The answering system must be turned on to answer and record messages.

**To turn on or off with the telephone base:**

- Press **ⓁANS ON** on the telephone base to turn the built-in answering system on or off.

#### To turn on or off with the handset:

- Press **MENU** when the phone is not in use.
- Scroll to highlight **Answering sys**, and then press **SELECT**.
- Scroll to highlight **Answer on/off**, and then press **SELECT**.
- Scroll to highlight **Answer: On or Answer: Off**, and then press **SELECT** to save. You hear a confirmation tone.

#### Default announcement

The telephone is preset with a greeting that answers calls with "Hello, please leave a message after the tone." You can use this preset announcement, or replace it with your own.

#### Record your own announcement

The announcement can be up to 90 seconds in length.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** and then press **SELECT** twice.
- The handset announces, *"To play, press 2. To record, press 7."*
- Press **7** to record. The handset announces, *"Record after the tone. Press 5 when you are done."* After the tone, speak towards the handset microphone. Then, press **5** when done.

#### Play the announcement

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** and then press **SELECT** twice.
- The handset announces, *"To play, press 2. To record, press 7."*
- Press **2** to play the announcement.

#### Delete the announcement

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** and then press **SELECT** twice.
- The handset announces, *"To play, press 2. To record, press 7."*
- Press **3** to delete your own recorded announcement.

#### Set number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5 or 6 rings; or toll saver. If you choose toll saver, the answering system answers a call after 2 rings when you have new messages, or after 4 rings when you have no new messages.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **# of rings** then press **SELECT**.
- Scroll to choose **2, 3, 4, 5, 6** or **Toll saver**.
- Press **SELECT** to save and you hear a confirmation tone.

#### Message alert tone

When the message alert tone is set to on, and there is at least one new message, the telephone base beeps every 10 seconds. The message alert tone is preset to off.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **Msg alert tone** then press **SELECT**.
- Scroll to choose **Tone: On** or **Tone: Off**.
- Press **SELECT** to save and you hear a confirmation tone.

#### Recording time

You can set the recording time limit for each incoming message.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **Recording time** then press **SELECT**.
- Scroll to choose **3 minutes, 2 minutes** or **1 minute**.
- Press **SELECT** to save and you hear a confirmation tone.

## Use your built-in answering system

#### New message indication

When there are new answering system messages, The handset displays **XX new messages** and the message window on the telephone base flashes.

#### Message playback

When there are new answering system messages, The handset displays **XX new messages** and the message window on the telephone base flashes.

- Dial your telephone number from any touch-tone telephone.

When the system plays your announcement, enter the two-digit security code.

- You can enter one of the following remote commands.

Command	Description
<b>1</b>	Play all messages.
<b>2</b>	Play new messages.
<b>3</b>	Delete the current message (during playback).
<b>33</b>	Delete all old messages.
<b>4</b>	Repeat the current message (during playback).
<b>5</b>	Stop.

- To playback messages at the handset:** Press **MENU** to choose **Play messages**. Press **SELECT**.

#### Options during playback:

- Press **▼/VOLUME▲** to adjust the message playback volume.
- Press **6** to skip to the next message.
- Press **4** to repeat the message. Press **4** during the time and day announcement to hear the previous message.
- Press **3** to delete the playing message.
- Press **OFF** to stop the playback.
- Press **◀▶** to switch between speakerphone mode and handset mode.

## Delete all old messages at the telephone base

**To delete all old messages at the telephone base:** Press **X/DELETE** twice when the phone is not in use.

#### To delete all old messages on a handset:

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys**, and then press **SELECT**.

- Scroll to **Delete all old**, and then press **SELECT**.
- Press **DELETE** twice. You hear a confirmation tone.

### Remote access

A two-digit security code is required to access the answering system remotely from any touch-tone telephone. The preset code is **19**. You can use this preset code, or set your own.

- Dial your telephone number from any touch-tone telephone.
- When the system plays your announcement, enter the two-digit security code.
- You can enter one of the following remote commands.

Command	Description
<b>1</b>	Play all messages.
<b>2</b>	Play new messages.
<b>3</b>	Delete the current message (during playback).
<b>33</b>	Delete all old messages.
<b>4</b>	Repeat the current message (during playback).
<b>5</b>	Stop.

<b>Avoid water</b>	Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.
<b>Electrical storms</b>	Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms.
<b>Cleaning your telephone</b>	Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use dampened cloth or cleaning solvents of any kind.

## Frequently asked questions

Below are the questions most frequently asked about touch-tone telephones. If you cannot find the answer to your question, visit our website at **www.vtechphones.com** or call **1 (800) 595-9511** to customer service. In Canada, go to **www.vtechcanada.com** or call **1 (800) 267-7377**.

My telephone does not work at all.	Make sure the telephone base is installed properly, and battery is installed and charged correctly. For optimum daily performance, return the handset to the telephone base after use.
The display shows <b>No line</b> . I cannot hear the dial tone.	Disconnect the telephone line cord from your telephone and connect it to another telephone. If there is no dial tone on that other telephone either, then the telephone line cord may be defective. Try installing a new telephone line cord. <p>If changing telephone line cord does not help, the wall jack (or the wiring to this wall jack) may be defective. Contact your telephone service provider.</p> <p>You may be using a new cable or VoIP service, the existing telephone jacks in your home may no longer work. Contact your service provider for solutions.</p>
The display shows <b>To register HS...</b> and <b>...see manual</b> alternately. The handset does not work at all.	The handset is deregistered from the telephone base. Place the handset in the telephone base to register it back. The handset shows <b>Registered</b> and you hear a beep when the registration process completes. This process takes about 90 seconds to complete.
	The handset is deregistered from the telephone base. The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

## Limited warranty

#### What does this limited warranty cover?

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

features may save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.

**What must you return with the Product to get warranty service?**

- Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
- Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- Provide your name, complete and correct mailing address, and telephone number.

#### Other limitations