vtech®

MyVTech Soother App

User's Guide

Table of Contents

Home screen

- Toddler lock
- Favorite mode
- Settings
- Main Menu
- Audio play
- Night light
- Night light brightness
- Control panel
- Soother battery indicator
- Projection
- Clock (Snap timer and Alarm)
- OFF timer
- Routine
- Sleep information

Control Audio Favorite Routine

Night light

The night light can illuminate in different colors to calm your baby in a dark room. On the **Home screen**,

- Drage the ☀ Brightness bar to adjust the night light brightness.

- Tap ⚙ to enter the Night light panel, you can turn on or turn off the night light, adjust the brightness, and select the effect and the color.

Audio play

On the **Home screen**, tap 🎵 or tap **Audio** in the Main Menu to enter the Audio play panel.

- Drage the 🔊 Volume bar to adjust the volume of the audio.

- Tap 📖 to play Story, tap 🎵 to play Classical music, tap 🎵 to play Lullaby, tap 🎵 to play Natural Sound, and tap 🎙 to play a Recording sound or Record a sound.

- You can adjust the audio volume and select the play mode on these panels.


Projection

You can create a personal meaning for each projection image, such as play time, sleep time, wake time...

On the **Home screen**, tap 🎨 to enter the Projection panel.

- Turn on or turn off the projection and select a projection effect for your baby.

Favorite mode

Use favorite mode to preset your customized night light color, brightness and effects, sound and volume, and projection effects.

- Tap [icon] to enter the favorite mode editing panel, tap **+** to add a new mode, and tap [icon] to edit. You can add up to 8 favorite modes.
- Tap **Favorite** in the Main Menu to view and select your favorite mode.


Favorite   Edit

Click here to add
new favorite mode.

Routine

Set the time period and customize the night light, audio and projection to plan your baby's everyday life, such as morning exercise, meal time, sleep trainer...

- Tap **Routine** in the Main Menu to view routines.
- Set the Start time, End time and Repeat time or set the Toddler Lock on or off during the time period on this panel.
- Tap **Actions** to add the night light, audio and projection mode for each routine.


Click here to create
new routine.

Timer

Select the time period 30 minutes, 1 hour, 2 hours, 3 hours or 4 hours to turn the soother off.

- Tap **Contorl** to go to the Contorl panel, tap [icon], select the time and tap **Start** to start the timer.

Clock

Set the **Nap Timer Alert** duration (1 - 30 minutes) and play mode, alarm, and the nap timer (30 minutes, 1 hour, 2 hours, 3 hours or 4 hours) to turn the soother off.

- Tap **Control** to go to the Control panel, tap [icon], then select Nap Timer or Alarm.
- In Nap Timer setting panel, tap Timer Alert Settings, select the Night light, Audio and projection mode for the Timer Alert, then tap **Start**.

Settings

Turn on or off the Toddler Lock and the Ear Protection, set the Magic Key and find the general settings of the soother.

- Tap [icon] to go to the general Settings panel.
- You can turn on the Toddler Lock on this panel, or tap [icon] to temporarily disable all buttons on Soother.

Settings   Toddler Lock