
VM3252 VM3252-2





vtech Quick start guide








I ransmit trequency

Frequency control



The Heart Beat sound file was created by Zarabadeu, and is used under the Creative Commons license. The Crickets At Night sound file was created by Mike Koenig, and is used under the Creative Commons license. The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license. The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license

etnemeriuper rewoq	Parent unit/baby unit power adapters: I. VTech, VT05EUS06050; or Z. Tenpao, S003GU0600050; Rated output: 6V DC @ 500mA Parent unit battery: 3,6V Ni-MH battery (Corun)
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range maximum power allowed by TCC and IC. Actual operating range of use.
rcp	2.8" Color LCD (QVGA 320x240 pixel)
Channels	35

TECHNICAL SPECIFICATIONS

IMPORTANT SAFETY INSTRUCTIONS

The applied nameplate is located at the bottom of the When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- Follow all warnings and instructions marked on the
- Adult setup is required 3. CAUTION: Do not install the baby unit at a height
- This product is not a substitute for adult supervision of the infant. Supervising the infant is the parent's or caregiver's responsibility. This product could cease operating, and therefore you should not assume it will continue working properly for any given period of time. Further, this is not a medical device and should not be used as such. This product is intended to assist you in supervising your baby
- 5. Do not use this product near water. For example, do not use it next to a bath tub, wash bowl, kitchen sink, aundry tub or swimming pool, or in a wet basement
- 6. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected high or low extreme temperature and low air pressure a of light allowed externe emperative and low all pleasure at gh altitude during use, storage or transportation. Disposa f battery into fire or a hot oven, or mechanically crushing or cutting or the battery can result in an explosion. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the information in **The RBRC*** seal.
- Use only the adapters included with this product. ncorrect adapter polarity or voltage can seriously damage the product.
- Baby unit power adapter: Output: 6V DC 500mA; Parent unit power adapter: Output: 6V DC 500mA. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet
- For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily
- . Unplug this product from the wall outlet before cleaning Do not use liquid or aerosol cleaners. Use a damp cloth Do not cut off the power adapters to replace them with other plugs, as this causes a hazardous situation.
- Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or crimped. This product should be operated only from the type of power source indicated on the marking label. If you
- are not sure of the type of power supply in your home consult your dealer or local power company.
- 14. Do not overload wall outlets or use an extension cord. 15. Do not place this product on an unstable table, shelf, stand or other unstable surfaces
- 16. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat
- Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid

- 18. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the product other than specified access doors may expose you to dangerous voltages or other risk: ncorrect reassembling can cause electric shock when the product is subsequently used.
- 19. You should test the sound reception every time yo n on the units or move one of the components. 20. Periodically examine all components for damage. There is a very low risk of privacy loss when using
- certain electronic devices, such as baby monitors, cordless telephones, etc. To protect your privacy, nake sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you will not use it for some time. Children should be supervised to ensure that they do not play with the product.
- 23. The product is not intended for use by persons including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SAVE THESE INSTRUCTIONS

- Use and store the product at a temperature between 32°F and $104^{\circ}\text{F}.$
- Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source.
- Batteries should not be exposed to excessive heat such as bright sunshine or fire.
- Make sure the baby unit(s) and the adapter cord(s) are always out of reach of the baby, at least 3 feet away from the baby or crib, to avoid a possible strangulation hazard.
- Never place the baby unit(s) inside the baby's crib or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket.
- Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices is possible: wireless routers, radios, cellular elephones, intercoms, room monitors, televisions

Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless

personal computers, kitchen appliances and


Wireless Technology Research, LLC (WTR), an independe research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians

Pacemaker patients Should keep wireless devices at least six inches from the

- Should NOT place wireless devices directly over the pacemaker, such as in a breast pocket, when it is turned
- WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices. Electromagnetic fields (EMF) This VTech product complies with all standards regardir electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the

product is safe to be used based on scientific evidence

WHAT'S IN THE BOX




CONNECT THE BABY MONITOR

Install the battery

The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, make sure you use both battery and AC power at the same time. With the battery alone, the parent unit can cordlessly run for a short time only.

- Use only the battery supplied with this product.
- If the parent unit will not be used for a long time, disconnect and remove the battery to prevent possible leakage



Press down on the battery compartment cover to pull






Replace the battery

To replace the battery, press down on the battery compartment cover and pull it out, then follow the steps above to install the battery.

Connect the baby monitor

- Use only the power adapters supplied with this product.
- Make sure the baby monitor is not connected to the switch controlled electric outlet Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are
- Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.
- not designed to hold the weight of baby monitor, so do not connect them to any ceiling, underthe-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.




Charge the parent unit battery


When you have connected and turned on the parent unit, the battery will be charged automatically

- Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon becomes solid **###** \cdot It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time,
- turn the parent unit off while charging. • The standby time varies depending on the sensitivity level you set, your actual use and the age of


POWER ON OR OFF THE BABY MONITOR



POSITIONING THE BABY MONITOR



- 3, and the maximum volume is level 5. If you experience high-pitched screeching noise from your baby monitor while positioning:
- Make sure your baby unit and parent unit
- are more than 1 meter (3 feet) apart, OR




· To avoid interference from other electronic devices, place your baby monitor at least 3 feet (1 meter) away from devices such as wireless routers, microwaves, cell phones and computers.

4 STATUS CHECK

Once you power on both your baby unit and parent unit, your parent unit

displays image from the baby unit, and the LINK LED light turns on.



baby unit turns on

Basic operation - Parent unit

Adjust speaker volume

unit speaker volume. The sound sensitivity setting also affects

Press VOL+ / VOL- to adjust your parent




the speaker volume. For details, refer to Sound sensitivity and sound activation.

2475 MHz 2405 - 2475 MHz

Crystal controlled PLL synthesizer


Saby unit: 2405 - 2475 MHz

Press \bigoplus to zoom in or out.



Talk to your baby unit

Press and hold **TALK** and speak to your parent unit. Your voice is transmitted to the baby unit. Release **TALK** when finish talking and hear your baby again.



Turn off the screen

Press and hold LCD ON/OFF to switch off the screen. You can still hear sound from the selected baby unit.



兴 TIP

• Press any keys on the parent unit to turn on the screen again.

Use the menu


Press MENU to enter the menu, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.

While in the menu:


- Press ◀ or ▶ to scroll among the menu options.
- Press **SELECT** or \blacktriangle to enter the desired submenu. Press ▲ or ▼ to select an item.
- Press **SELECT** to confirm your selection.
- Press
 or
 to exit the submenu.

\$ 1 0 0 0

OVERVIEW - PARENT UNIT



OVERVIEW - BABY UNIT



NEED HELP?

1 (800) 267-7377 [in Canada] for help.

For operations and guides to help you using your video monitor, and for latest information and supports, go and check the online help topics and online FAQs.



moving your device closer or further away until it is clear. You can also call our Customer Support at 1 (800) 595-9511 [in US] or

Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to trigger the redirection of the - If the QR code is not clearly displayed, adjust your camera's focus by



VM3252

■ PARENT UNIT ICONS

Status icons

- Yill or Yil displays when strong signal strength is detected between the baby
- ullet $oxed{Y_{i}}$ or $oxed{Y_{i}}$ displays when moderate or low signal strength is detected between

Patrol mode

- Displays when the parent unit is in PATROL mode.

- 2 or Displays the baby unit number of the baby unit that is being viewed.

- Displays when the baby unit being viewed has activated the night vision

· Displays when a lullaby is playing.

|||||| 6-level sound indicator


- Displays the sound level according to the scales of loudness when there is sound transmitted from the baby unit.
- IIIIII (5 to 6 bars) indicates high sound level detected by the baby unit (e.g.


- Displays when the parent unit speaker volume is set to zero. • Displays when the parent unit is talking to the baby unit.

- animates when the battery is charging. **IIII** displays solid when the battery is fully charged.
- displays when the battery is low and needs charging.



You can set a specific time to screen off your parent unit.







automatically. It will then turn off again after 50 seconds of no sound detection. **VOX** sensitivity

With this feature, you can choose to hear sounds from the baby unit all the time, or



You can select, play, or stop a lullaby.



You can monitor your baby in PATROL mode.

Warning icons and messages

/Battery low at Parent Unit






The parent unit is searching for baby units or the link









The parent unit is connected to AC power.





NOTE







the baby unit and the parent unit.

For VM3252-2 only

23 or

· Displays when the current image on the parent unit has zoomed in.



Displays when talking back to the baby units from parent unit

• II (1 to 2 bars) indicates low sound level detected by the baby unit. • IIII (3 to 4 bars) indicates moderate sound level detected by the baby unit.


 Displays the real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. **57°F** or **14°C**).


AC power without battery

Displays when the parent unit is connected to AC power without the battery.

• Displays the parent unit speaker volume level while adjusting.























You can choose to set the maximum/minimum temperature and turn on the




When the baby unit being viewed detects no sound, the parent unit screen stays off to save power. Once a sound is detected, the parent unit screen turns on






The battery is empty and needs to be recharged.













Main menu icons

You can change the brightness of the parent unit screen.







Patrol mode







between the baby unit and the parent unit is lost.



The temperature detected by the baby unit is lower than

The temperature detected by the baby unit is higher than the desired temperature alert range.

PARENT UNIT LIGHTS

On when the parent unit is linked to the baby unit.





- On when the parent unit is connected to AC power, or the battery is
- Flashes when the parent unit battery is low and needs charging.
- Off when the parent unit is disconnected from AC power.



• On when the speaker volume of the parent unit is turned off; or when the parent unit speaker is talking to the baby unit.

On when the parent unit is talking to the baby unit.



Adjust the sound sensitivity of the baby unit

You can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. The VOX sensitivity level is preset to the highest level.




VOX SENSITIVITY LEVEL	Highest	High I	Medium I	Low I	Lowest I
DESCRIPTION	The parent unit speaker is constantly on, and you will hear all sounds (including background noises) from your baby's room.	The parent unit speaker turns on for soft babbling and louder sounds from your baby. It remains quiet when your baby sleeps soundly.	The parent unit speaker turns on for loud babbling and louder sounds from your baby. It remains quiet when your baby makes soft sounds.	The parent unit speaker turns on for crying and louder sounds from your baby. It remains quiet when your baby makes soft sounds.	The parent unit speaker turns on for loud crying or screeching sounds from your baby. It remains quiet when your baby makes soft sounds.

Sound activated screen

When sound activation is on, the parent unit screen stays off to save power when the baby unit detects no sound. Once the baby unit detects sounds that are louder than the chosen sound sensitivity level, the parent unit screen turns on automatically. It will then turn off again after 50 seconds of no sound detection.





The dim mode is to help you save the parent unit power. Your parent unit display will dim automatically after 10 minutes of inactivity, in which there is neither key pressed nor alert






■ Note

• While the screen is dimmed, any keypress or alert message will trigger the screen to return to the preset brightness level. After 10 minutes of inactivity, it will resume to dim mode.

NIGHT VISION



The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and 🔾 ppears on the screen.

■ Notes


- It is normal if you see a short white glare on your parent unit screen as the baby
- unit is adapting to the dark environment When the infrared LEDs are on, the mages are in black and white. This is

Depending on the surroundings and other interfering factors, like lightings objects, colors and backgrounds, the display resolution may vary. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry

FOR VM3252-2 ONLY

Status check - Two baby units

If you are viewing baby unit 21, the POWER LED light of baby unit 11 turns on. As baby unit **2** is not being viewed, its **POWER** LED light flashes.





■ Note

 \cdot If you power on only one baby unit, your parent unit may display $\P_{m{\Theta}}$ and the LINK LED light flashes. Press to switch to the baby unit you have powered on.

Change different views - Patrol

Press **MENU** when the parent unit is idle. Press ◀ or ▶ to choose , then press **SELECT** or ▲. Press ∇ or \triangle to choose \bigcirc N, then press **SELECT** to confirm your selection.







Change different views - Single-cam

Press CAM to switch to another camera in **SINGLE-CAM** mode.








MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)

Items to purchase

You will need to purchase the following items separately to mount your baby unit:




 The types of screws and anchors you need depend on the composition of the wall.




· Check for reception strength and camera angle before drilling the holes.

Use a pencil to mark two holes in parallel. Make sure they are the same distance apart as the wall mount holes on the baby unit.




If you drill the holes into a stud, go to step 3 If you drill the holes into an object other than


a stud, insert the wall anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the wall.



tighten the screws until only 1/4 inch



Align the wall mount holes on the baby unit with the screws on the wall. Slide the baby unit down until it locks



Adjust the camera angle.

Q_{8∆} Frequently asked questions

Below are the questions most frequently asked about the baby monitor

	Why does the baby monitor not respond normally?	 Try the following (in the order listed) for common cure: Disconnect the power to the baby units and the parent unit. Remove the batteries in the parent unit. Then, install the batteries again. Wait a few seconds before connecting power back to the baby units and the parent Turn on the baby units and the parent unit. Wait for the parent unit to synchronize with the baby units. Allow up to one min for this to take place.
p b u	Why don't the power-on light of the baby unit and parent	Perhaps the parent unit is not connected to the power. Insert the appliance plug ir the parent unit and put the adapter in a wall socket. Then, press and hold $\textcircled{0}$ to sw on the parent unit and to establish connection with the baby unit.
	unit go on when I switch	Perhaps the baby unit is not connected to the power. Insert the appliance plug into

Why does the parent

Why does the parent

Why can't I establish a

connection lost every now

and then? Why are there

sound interruptions?

other sounds?

my baby cry?

unit beep?

baby unit and put the adapter in a wall socket. Then, slide the **(b)ON/OFF** switch to **ON** to switch on the baby unit and to establish connection with the parent unit. Why doesn't my parent Make sure the power is not controlled by a wall switch. unit charge while Make sure the battery is correctly installed in your parent unit. connected to AC powe You may have used the battery for a long time. Replace a new battery.

Why is my screen in The screen is in black and white during night-time or in a dark room when the night black and white? vision feature is activated. This is normal. During night-time or in a dark room, the surroundings and other interfering factors, blurry display on my like lightings, objects, colors and backgrounds may affect the image quality on your screen when viewing my parent unit screen. Adjust the baby unit's angle or place the baby unit at a higher level

baby at night? to prevent glare and blurry display. The parent unit and baby units may be too close to each other. Why does the baby monitor produce a Move the parent unit away from the baby units until the noise stops: OR high-pitched noise? Turn down the volume of your parent unit.

baby unit to set to a higher level.

The baby units may be out of range. Move the parent unit closer to the baby units (but The parent unit may not have enough charge for the parent unit to perform normally.

Charge the battery in the parent unit until the battery icon becomes solid The temperature of your baby's room may be too high or too low.

The baby unit also picks up other sounds than those of your baby. Adjust the VOX sensitivity level to a lower level or lower the parent unit speaker volume. unit react too quickly to

The parent unit speaker volume may be too low. Press **VOL+** to increase the volume. Why don't I hear a sound/Why can't I hear You may have set a low VOX sensitivity level. See Adjust the sound sensitivity of the

The baby units may be out of range. Move the parent unit closer to the baby units (but connection? Why is the not less than 3 feet). Other electronic products and wireless products may cause interference with your baby monitor. Try installing your baby monitor as far away from these devices as

If you power on only one baby unit, your parent unit may display \P_{Θ} , and the **LINK** LED light flashes. Press G_{AM}^{CM} to switch to the baby unit you have powered on.

THE RBRC® SEAL



The RBRC® seal on the Ni-MH battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada.

The RBRC® program provides a convenient alternative to placing used Ni-MH batteries into the trash or municipal waste, which may be illegal in your area.

VTech's participation in RBRC® makes it easy for you to drop off the spent battery at local retailers participating in the RBRC® m or at authorized VTech product service centers. Please call (800) 8 BATTERY for information on Ni-MH battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

RBRC® and 1 (800) 8 BATTERY® are registered trademarks of the Rechargeable Battery Recycling Corporation.

FCC and IC regulations

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications ever, there is no guarantee that interference will not occur in a $\acute{
m p}$ articular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following meas

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receive
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

To ensure safety of users, the ECC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The baby unit shall be installed and used such that parts of all persons' body are maintained at a distance of approximately 8 in (20 cm) or more. The transmitter and antenna of the parent unit shall be held at least 1 in (2.5 cm) from your

This Class B digital apparatus complies with Canadian requirement: CAN ICES-3 (B)/NMB-3(B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications. RF radiation exposure statemen

The baby unit complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The baby unit should be installed and operated with a minimum distance of 8 in (20 cm) between the baby unit and all persons' body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies also with Industry Canada RSS-102 with respect

CALIFORNIA ENERGY COMMISSION BATTERY CHARGING TESTING MODE

This baby monitor meets the California Energy Commission (CEC) regulations for energy consumption. Your baby monitor is set up to comply with the energy-conserving standards right out of the box. Follow the instructions to install and charge the battery. The CEC battery charging testing mode is activated while charging. Even if the parent unit is paired to baby units, the CEC battery charging testing mode is activated while it is powered off and charging.

FOR CETL COMPLIANCE ONLY

La plaque signalétique appliquée est située au bas du socle de l'unité du bébé. orsque vous utilisez votre appareil, vous devriez toujours suivre certaines mesures de précaution de base afin de réduire les isques d'incendie, d'électrocution et de blessures corporelles,

- Observez toutes les instructions et mises en garde inscrites
- l'installation par un adulte est requise. MISE EN GARDE: N'installez pas l'unité du bébé à une hauteur supérieure à 2 mètres.
- Ce produit ne remplace pas la surveillance adulte du ce produir le emplace pas la surveniante adunie du nourrisson. La supervision du nourrisson est la responsabilité du parent ou de la personne qui s'occupe de l'enfant. Ce produit pourrait cesser de fonctionner et, par conséquent, vous ne devriez pas présumer qu'il continuera de fonctionner correctement pendant une période de temps donnée. De plus, il ne s'agif pas d'un instrument médical et ne devrait pas être utilisé comme tel. Ce produit est destiné à vous aider à superviser votre bébé superviser votre bébé.
- N'utilisez pas cet appareil près de l'eau ni de toute autre source d'humidité, par exemple, près d'une baignoire, cuve à lessive, évier de cuisine, dans un sous-sol humide ni près d'une piscine, dans un sous-sol humide ou une
- fournies. Il existe un risque d'explosion si un autre type de batterie est utilisé pour l'unité Parents. N'incinérez pas les silos et les controls de la control de la con is. Celles-ci risqueraient d'exploser. Jetez les piles usees on les renseignements suivant **le sceau du RBRC**®. N'utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril. Adaptateur de l'unité du bébé : Sortie : 6V CC 500mA Adaptateur de l'unité du parent : Sortie : 6V CC 500mA
- rectement, soit à la verticale ou au plancher. Les broches nf pas été conçues pour supporter le poids du bloc limentation et le maintenir en place si celuici est branché as une prise au plafond, sous une table ou dans un Pour les PRODUITS À BRANCHER À UNE PRISE DE
- OURANT, la prise de courant doit être installée près du roduit, afin d'assurer une accessibilité sécuritaire à la prise Débranchez ce produit de la prise de courant avant de procéder au nettoyage. N'utilisez pas de nettoyants en aérosols. Utilisez un chiffon humide pour le nettoyer.
- Débranchez les cordons d'alimentation avant de remplace Ne coupez pas les cordons d'alimentation pour remplacer les fiches, car ceci peut présenter un danger potentiel.
 Ne laissez aucun objet reposer ni appuyer sur le cordon d'alimentation blimtalle pas est passei dans un ordenit.
- d'alimentation. N'installez pas cet appareil dans un endroit où l'on risque d'écraser le cordon d'alimentation ou de le Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur l'étiquette. Si vous ne connaisse pas le type d'alimentation que vous possédez à votre domicile, consultez votre marchand ou votre compagnie locale d'électricité.
- Ne surchargez pas les prises de courant murales ni les rallonges électriques. Ne placez pas cet appareil sur un chariot, meuble, trépied, support de montage ni table chancelants.
 Les trous et ouvertures du boîtier, situés à l'arrière de
- l'appareil ou sous celui-ci, servent à aérer l'appareil. Pour l'empêcher de surchauffer, ne bloquez sous aucun rour l'empecner de surchautrer, ne bloquez sous aucun prétexte ces ouvertures et n'empêchez pas l'aération adéquate de l'appareil en le plaçant sur un lit, divan, tapis ou toute autre surface similaire. De même, ne le positionnez pas à proximité ni au-dessus d'une source de chaleur ou d'un calorifère. De plus, ne placez pas l'appareil dans un endroit avant de vous assurer qu'il v ait une bonne irculation d'air.
- N'enfoncez jamais d'objets à travers les ouvertures de cet appareil, car ils pourraient entrer en contact avec des points de tension dangereux ou causer des courts-circuits qui peuvent dégénérer en incendies ou en risques

d'électrocution. Ne renversez jamais de liquide dans ce

- pas cet appareil, mais apportez-le dans un centre de service autorisé. L'ouverture du boîtier ou le retrait de toutes pièces que contient cet appareil, à l'exception de l'accès autorisé à certaines portes ou ouvertures, risque de vous exposer à des points de tension dangereux ou d'autres dangers. Un remontage incorrect peut par la suite présenter des risques d'électrocution.
- Vous devriez tester la réception chaque fois que vous mettez l'appareil en fonction.
- Examinez les composantes afin de vérifier si celles-ci ne Il existe un très faible risque de perte de confidentialité avec certains appareils électroniques (autres écoute-bébés, téléphones sans fils etc.). Pour l'éviter, s'assurer que le produit n'a jamais été utilisé avant l'achat, réinitialiser l'unité de façon périodique, éteindre l'écoute-bébé quand il n'est pas en cours d'utilisation.
- pas en cours d'utilisation.

 Les enfants devraient être supervisés afin de vous assurer qu'ils ne jouent pas avec l'appareil.

 Le produit n'est pas conçu pour être utilisé par des personnes (incluant des enfants) aux capacités physiques, sensorielles ou mentales réduites ou qui manquent d'expérience et de connaissances, à moins qu'on leur ait donné suffisamment de supervision ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité.

CONSERVEZ CES INSTRUCTIONS Mises en garde

- Utilisez et entreposez le produit à une température entre 0 $^{\circ}$ C (32 $^{\circ}$ F) et 40 $^{\circ}$ C (104 $^{\circ}$ F).
- N'exposez pas cet appareil à des froids ou des chaleurs extrémes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas prés d'une source de chauffage. Le bloc-piles ne doit pas être exposé à la chaleur excessive telle que la lumière du soleil ou au feu.
- Assurez-vous que le moniteur et le cordon l'enfant ou du berceau, pour éviter tout risque
- Ne jamais placer le moniteur à l'intérieur du berceau ou du parc de bébé. Ne jamais couvrir le moniteur ou l'unité (s) portative avec un article tel une serviette ou une D'autres équipements électroniques peuvent produire des D'autres equipements electroniques peuvent produire des interférences sur votre moniteur vidéo et audio. Tentez d'installer votre moniteur vidéo ou audio à l'écart des appareils électroniques tels que des routeurs sans fil, radios, téléphones cellulaires, interphones, moniteurs, téléphones, ordinateurs personnels, électroménagers et téléphones
- Stimulateurs cardiaques implantés dans l'organisme Les simulateurs cardiaques (ne s'applique qu'aux dispositifs
- numeriques sans 11):
 L'organisme 'Wireless Technology Research, LLC (WTR)', une firme de recherche indépendante, a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans fil portatifs et les stimulateurs cardiaques implantés dans l'organisme. Appuyée par l'Administration des aliments et l'organisme. Appuyée par l'Administration des aliments et drogues (FDA) des États-Unis, la firme WTR recommande aux médecins: Avis aux détenteurs de stimulateurs cardiaque
- ouces du simulateur cardiaque ne doivent PAS placer le téléphone sans fil directe L'étude effectuée par l'organisme WRS n'a pas identifié de risque pour les détenteurs de simulateurs cardiaques causés pai les gens qui utilisent dispositifs sans fil à proximité de ceux-ci.

Vous devriez maintenir les dispositifs sans fil à au moins six

Champs électromagnétiques (EMF)
Ce produit de VTech est conforme à toutes les normes se rapportant aux champs électromagnétiques (EMF) standard. Si vous le manipulez correctement en suivant les instructions de ce quide, son utilisation para sécuritaire pendant de problemance. guide, son utilisation sera sécuritaire pendant de nombreuses années, selon les meilleures évidences scientifiques dont nous

LIMITED WARRANTY

What does this limited warranty cover? The manufacturer of this VTech Product warrants to the

holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and

What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?

During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or replacement to

How long is the limited warranty period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective Product under the terms of repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer

What is not covered by this limited warranty?

This limited warranty does not cover:

- Product that has been subjected to misuse, accident. shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
- 2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or 3. Product to the extent that the problem experienced is
- antenna systems; or 4. Product to the extent that the problem is caused by use with non-VTech accessories; or

5. Product whose warranty/quality stickers, product serial

number plates or electronic serial numbers have been

caused by signal conditions, network reliability, or cable or

- removed, altered or rendered illegible; or 6. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including
- but not limited to Products used for rental purposes); or 7. Product returned without a valid proof of purchase (see item 2 below); or
- 8. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the

How do you get warranty service?

To obtain warranty service in the USA, please visit our In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features ma save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are esponsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty. Transportation, delivery or handling charges are epaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not

What must you return with the Product to get warranty

covered by this limited warranty.


- the Product to the VTech service location along with a description of the malfunction or difficulty: and
- 2. Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- 3. Provide your name, complete and correct mailing address, and telephone number.

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or ral communications related to this Product. VTech provide no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification. State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/ provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please retain your original sales receipt as proof

Insert the screws into the holes and of the screws are exposed.



into place.

